

CHARGING

1. Using a USB Type-C cable (included), insert the jack into the port on back of unit and then plug the USB connector into USB port on the power source.
2. Charge the device until the red LED indicator turns off.
3. Always disconnect the cable when charging is finished.

BLUETOOTH® CONNECTION

- Turn on your device's Bluetooth from the Bluetooth menu and select "MV_REVIVE" speaker.



BUTTON FUNCTIONS



Short press: Alarm clock setting mode

When the digits are flashing, confirm the setting value. When the alarm rings, pressing any key other than the alarm key enters snooze mode (**short press** the alarm key to cancel snooze mode). Five minutes before the alarm goes off, the orange light automatically turns on and gradually brightens (simulating the effect of a sunrise).
Long Press: Alarm On/Off



Short press: Clock Setting Mode

When the digits are flashing, confirm the setting value. **Long Press:** Switch between 12-hour and 24-hr format. In 12-hr mode, AM/PM is displayed.



Short Press: Sleep Timer Function

Short press once for a 30-minute timer, press again for a 60-minute timer, press again for a 90-minute timer. The screen displays the sleep timer duration. Before the sleep timer ends, the light gradually dims until it turns off (simulating the effect of a sunset).



Short Press: Increase Volume In music playback mode and in white noise mode. **Increase digits** in clock/alarm setting mode.

Long Press: Next Track In music playback mode and in white noise mode. **Rapidly increase digits** in clock/alarm setting mode.



Short Press: Decrease Volume In music playback mode and in white noise mode. **Decrease digits** in clock/alarm setting mode.

Long Press: Previous Track In music playback mode and in white noise mode. **Rapidly decrease digits** in clock/alarm setting mode.



Short Press: Switch Mode

Clock Mode/Bluetooth Mode/White Noise Mode (default is Clock Mode when powered on). When connected to Bluetooth, the time automatically syncs with the phone time.



Short Press: Play/Pause Music In Bluetooth mode and in white noise mode.



Long Press: Power On/Off Power On Status: 1. Clock mode (in 12-hr format). 2. Warm light on. 3. Display screen on, showing the clock.



Short Press: Light Mode Switch

Warm Light/White Light/Seven-color Circulation /Seven-color Breathing/Seven-color Change /Red/Blue/Green/Purple/Orange/Cool Light.
Long Press: Light On/Off

TROUBLE SHOOTING



No power

- Recharge your speaker using the USB Type-C cable. If the problem persists, try using another USB Type-C cable.

No response from the unit

- Check if both devices are paired and connected to each other.
- Restart the device and try to reconnect.



MVMT

MVMT and MVMT logo are trademarks of JME & CO @2024. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by JME & CO is under license. All other trademarks and trade names are those of their respective owners.

Distributed by JME & CO., New York, NY 10018 USA
©2024 JME & CO, NYC, LLC. All Rights Reserved.
Designed in New York. Made in China. hello@jmeandco.com

FCC ID:2A3ZO-240010A



FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1- This device may not cause harmful interference.
- 2- This device must accept any interference received, including Interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help or assistance.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Electronic and electrical devices disposal

This symbol indicates that electrical and electronic device is to be collected separately.



- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- If the device use batteries, they must be removed from the device and disposed in a appropriate collection center.
- If the batteries cannot be removed, do not attempt to do it yourself since it must be done by a qualified professional.
- Separate collection and recycling helps conserve natural resources and prevent negative consequence for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

SPECIFICATIONS

Model No: MA1114

Working Distance: Approx. 33 ft

Playback Time: 3-4 Hours (at 70% volume)

Frequency Range: 2.40 - 2.48GHZ

Output Power: 10 W

Speaker Impedance: 4 Ω / 84dB

Speaker Unit: 45mm / 3W X 2

Lithium Battery: 3.7V/1800mAh

MVMT



INFO

REVIVE

Sunrise Simulator & Sleep Support
Alarm Clock / Speaker

IMPORTANT: PLEASE READ BEFORE USING THIS PRODUCT