# 对折线

### (TOLL-FREE CUSTOMER SUPPORT (877) 269-8490)

n tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are desigainst harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and

ference cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCCR and designs are subject to change without any notice or obligation on the part of the manufacturer.

ations not expressly approved by the party responsible for compliance could void the user's authority to operate this c evice complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful rence, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### LIMITED WARRANTY

Walker's warranties this product to the original purchaser to be f

6

### Return bottom portion to Walker's, Inc. - PO Box 535189 - Grand Prairie, TX 75053-5189


### **Warranty Registration**

Model:	Date of Purchase:	
Purchased From		
City:	_State:	Zip:
Primary Use:		
Your Name:		
Address:		
City:	_State:	Zip:
Email Address:	Serial #:	

### **Getting Started**

- 1. Before attaching the Walkie Talkie, rotate the position of the rubber USB-C cover. Pull the rubber audio jack cover and fold away from the housing.
- 2. Attach the walkie talkie to your FireMax by lining up the audio jack with the audio jack port, then lining up the USB-C connector. Slide Walkie Talkie in then press towards muff cup to snap into place.







4. Press and hold the power button for two seconds to turn on the headset and walkie talkie

### Walkie-Talkie Overview



# **FRONT**

## **Functions**

Press and hold the power button for 2 seconds to turn the head set and walkie talkie on or off

## Ambient Volume Adjust:

Press the volume up or down buttons to the right of the LCD screen to change the volume of the ambient pass-through

NOTE: When Ambient volume reaches minimum there will be a double beep. When Ambient volume reaches maximum there will be a double beep

Press the volume up or down buttons to the left of the LCD screen to change the walkie talkie speaker volume

When walkie talkie speaker volume reaches minimum there will be a double beep. When walkie talkie speaker volume reaches maximum there will be a double beep

# Frequency Modes

Press the Mode button to cycle through the following frequency modes

- Universal: General use with no filter applied
- Clear Voice: Emphasizes human vocal frequencies
- High Frequency: : Low frequencies reduced and high frequencies are boosted, amplifying noises such as bushes rustling or branches cracking.

  Power Boost: Amplified version of Universal

## Radio Operation

Press the Power/Menu button one time to enter the menu. "CH" will display. Press the up or down buttons until the desired channel appears on the screen. The Firemax Walkie Talkie supports standard GMRS/FRS channels 1 through 22. Press the Power/Menu butter four more times to exit the menu.

All radios in your group must be set to the same channel. Position the microphone about 1 inch away from your mouth. To talk, press and hold the Push-to-Talk (PTT) button and speak. The PTT icon will flash on the screen while transmitting. Release PTT button when finished.

Selecting a sub-channel will cause you Razor Walkie Talkie to only receive transmission from other radios set to the same channel and sub-channel. This allows multiple groups to communicate on the same channel independently. Note that other radios will receive transmissions from your channel regardless of sub-channel.

Press the Power/Menu button two times to enter the sub-channel menu. "SUB" will displayed

Press the up or down buttons to scroll through and select any of 99 subchannels. Press the Po exit the menu. Alternatively, the menu will exit after a few seconds of inactivity.

## Voice Activated Transmit (VOX)

Voice Activated Transmit (VOX) can be enabled for hands-free operation. When activated, the unit will autowearer is speaking. PTT is still available while VOX is enabled.

1. Press the Power/Menu button three times to enter the VOX menu. "VOX" will be displayed.

Press the up or down volume buttons to scroll through the available options. OF disables VOX and is the default setting. LO is for low sensitivity and is meant for environments with external noise such as wind. HI is for high sensitivity ideal for low wind areas or indoors.

3. Press the Power/Menu button two more times to exit the menu. Alternatively, the menu will exit after a few seconds of inactivity.

# FCC & IC Warning



To ensure that your expose to RF electromagnetic energy is Within the FCC/IC allowable limits for occupational use, always Adhere to the following guidelines:

- DO NOT operate the radio without a proper antenna attached, as this may damaged the radio and may also cause you to exceed FCC/IC RF exposure limits, a proper antenna is the antenna supplied with this radio by the manufacturer or antenna specifically authorized by the manufacturer for use with this radio.

  DO NOT transmit for more than 75% of total radio use time (75% duty cycle). Transmitting more than 75% of the time can cause FCC/IC RF exposure compliance requirements to be exceeded. The radio is transmitting when the "TX indicator" lights red. You can cause the radio to transmit by pressing the "PTT" switch.

  Only and must attach Good Sportsman's headphone (FireMax Walkle Talkle) to install.

  This device was tested simulation typical 0mm to head.

To avoid electromagnetic interference and/or compatibility conflicts, turn off your radio in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy

The information listed above provides the user with the information needed to make him or her aware of RF exposure, and what to do to as-sure that this radio operates within the FCC/IC RF exposure limits of this radio. This equipment must be installed and operated in accordance with provided instructions and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance. The SAR limit adopted by US/Canada is 1.6 W/kg averaged over 1 grams of tissue. The highest SAR value for this device type when properly wom on the body is 0.142 W/kg.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The information listed above provides the user with the information needed to make him or her aware of RF exposure, and what to do to assure that this radio operates with the FCC RF exposure limits of this radio. This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of an integral Antenna and maximum 3.5dBi gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.