


207.0 mm

## Solekick™ MagClick™ 15W Wireless Charging Stand

### Instruction Manual

Item: 5077-09 Model: XY-OT038



### Features:

1. Mobile Phone Stand Board
2. LED Indicator
3. Integrated Cable with Type C tip
4. Wireless Charging Surface
5. Magnetic Surface (remove the film before use)

### What's included:

- 1 x Wireless Charging Stand
- 1 x Integrated Type-C charging cable
- 1 x Instruction Manual

### Tech Specifications

- Type-C Input: DC 5V/2A; 9V/2A
- Wireless Output: 5W/7.5W/10W/15W

### Instructions:

#### 1. Wireless Charging Mobile phones and other electronic devices:

- Connect the Type-C tip(3) of the charging pad to a power source. LED indicator will glow BLUE&RED for 4 seconds then turn RED to indicate the wireless charger is in standby mode and ready to begin charging.
- Place the wireless charging supported mobile device on the wireless charging surface(4). LED will glow BLUE when device is charging.
- Phone will begin to charge automatically.
- Once fully charged remove the device.

**\*\* Note:** When wireless charging, if the LED indicator flash BLUE the device is either NOT a wireless charging device or there is an object between the device and charging surface interfering with the charging process.

#### 2. Wireless Charging with Magnetic Surface:

- If your wireless charging compatible device contains magnets, it will attach to the magnetic surface(5) of the stand for better alignment to secure wireless charging.
- This item is also compatible with other items, the magnetic function just won't work.

#### 3. Phone Holder Function:

- If your device contains magnets, it will attach to the surface to hold your device vertically or horizontally.
- If your device does not contain magnets, you will need to pull out the stand board(1) to hold it.

### SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed:

1. Read all the instructions before use.
2. Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C).
3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for more than 7 hours at a time.
4. To reduce the risk of injury, close supervision is required when the product is used near children.
5. Do not expose the device to moisture.
6. Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
7. Do not use the device if damaged or modified.
8. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
9. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
10. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
11. To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
12. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. You must remove attachments from the phone before charging on this device.

13. The strong magnetic fields of neodymium magnets can damage items such as television, computer monitors, credit cards, bank cards, computers, diskettes and other data carriers, video tapes, mechanical watches, hearing aids, loud speakers and VCRs. Pace-makers may be damaged or switch to "Test Mode" in the presence of a strong magnetic force, if a pace-maker or other electrical body implant is in use, keep a minimum of 3 feet distance.

### FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
- Warning:  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Name of the Distributor:

Leedsword Inc  
Address of the Distributor:  
400 Hunt Valley Road,  
New Kensington,  
PA 15068 USA.  
WWW.PCNA.COM  
FCC ID: 2ADK3-OT038  
Made in China



20.0 mm

29.3 mm