# ES22 User manual

There you very must be showing the ESSI Blookseth carphone. To have a print represent, please and the menual parellally letters use.

# **Button definition** Short press on L earphone or R earphone. SO is the state of recovery Short press three times on the right side earbud : Short press three times on the left side earhud:



Short press twice on the left side earbuds



long press left or right earthusts for 5 seconds





# Operations

# Bluetooth connection

# TWS Mode:

al Automatic boot, automatic paring.



b. When the pairing is successful.




# C Connect mobile phone



# Single earbud mode:

Take out any exphore of the left or right from the charging case the LEO Hidicator will binking alternatisty



b ameriamone for pairing

The later cast expects for EXXX with a proof physics for paining. The devices will prompt November 1, the paining M. Mullimettel. and the light on the extracts. Sometimes of the extracts.



# Automatic reconnection:

After the arabatic is aucromobally domained to the becomes device. The next time the earliests of current on, it can undomatically connect back to the terminal device that was committed test time.

# Incoming call

al. incoming call



b. Answering / Years up the phone



# Charging






# Charge the earbuds

- Earbuds will prompt out low battery voice alert once the batery level is too low.
- Put the LRearbuds in the charging base and cbse the charging base cover, the earbuds will automatically enter the charging mode and the light display.
- Earbuds full charge time: 1.5 hours, the charging indicator light turis off after the earphone is fully charged.



# Reset to factory default



- You can resetearbuds to factory default if you encounter pairing problems.When the earbuds off, tap and hold for 10 seconds to reset them to factory default Put them back to the charging base and take out again for painng.
- 2. Put the earbuds into the charging base, long press the reset button of the charging base, also can reset to factory default After resetting take out the earbuds for repairing.

## FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digitaldevice, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonableprotection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

# FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

# **Technical Parameters**

- 1.Chip solution:Actons
- 2.Input charging voltage and curent:5V/1000MA
- 3.Battery type: buit-in rechargeable ithium battery 4.Battery capacity earbud battery 40mAh, charging base battery 400mAh
- 5.Frequency response range:20HZ-20KHZ 5.Sensitivity: 99+- 3dB
- 6.Bluetooth version: V5.0
- 7.Working range:10M
- 8. Working hours: Earbuds: 4H; charging base: charging gycle: 4 tmes

# ATTENTION

re and hardware updated, at the technical data and the mode of operation manual coud be changed without portor notice.

# Security warning:

- 1.Please store and use the produc under normal temperature, do not expose

- 1.Please store and use the produc under normal temperature, do not expose this apparatus to the rain or moisture.

  2.Do not throw away or disassemble for repair as it may cause safety problem 3.Built-in ithium battery,do not discard or put titinto a fre
  4.Foryour health and to extend the life of the product, beter not to keep maximum volume on, to avoid injury of your hearing.
  5.In any emergency, Cut off the powerimmediately
  6.To always have a better performance,please charge in time once the battery is low. is low.