
User Manual



AIR PURIFIER

NO.AZ5100VC



- · Please read this manual carefully before use.
- · The company reserves the right to interpret these instructions.
- · The product's appearance may vary from the images shown.



READ AND SAVE THESE INSTRUCTIONS IMPORTANT SAFETY NOTES

This product should be used only as specified in this manual. Any other use may result in serious injury.

When using electrical appliances, always follow basic safety precautions to reduce the risk of fire, electric shock, or personal injury, including the following:

Before Use

- WARNING: To reduce the risk of fire or electric shock, do not use this unit with a solid-state speed control device.
- Connect the power plug to a power source that matches the specified voltage.
- To avoid fire or electric shock hazards, always hold the plug when unplugging. Do not pull
 the power cord.
- To prevent damage to the power cord, electric shocks, or fire hazards, do not pull, bend, twist, or intentionally damage the power cord.
- Do not use the unit if the power cord, plug, or socket is damaged. Contact the manufacturer or a qualified technician for a replacement.
- To prevent electric shocks or fire hazards caused by a damaged power cord, do not place heavy objects on it.
- Do not touch the power plug with wet hands to avoid the risk of electric shock.

In Use

- Remove the plastic layer from the filter before use. Do not operate the unit without a filter.
- Do not drop or insert any objects into the unit's openings.
- Do not block the air inlet or outlet.
- Do not place near hot objects (e.g., stoves or areas with open flames).
- Pull the plug immediately if any malfunction occurs, such as smoking or unusual odors.
- To ensure proper airflow and efficient purification, keep enough space around the air purifier.

Restrictions On Use

- Do not use the unit in areas with open flames or flammable chemicals.
- Do not use the unit in areas with propane, gas, natural gas, or other flammable substances to avoid electric shock, fire, or damage.
- Do not use the unit while using bug spray.
- To prevent electric shock, fire hazards, or other damage, do not use the unit in damp, unstable, or high-temperature areas, such as bathrooms or similar environments.
- This appliance has a polarized plug (one blade is wider than the other) to reduce the risk of
 electric shock. It is designed to fit into a polarized outlet only one way. If the plug does not
 fit fully, reverse it. If it still does not fit, contact a qualified electrician. Do not attempt to
 bypass this safety feature.

SAFETY INFORMATION

Cleaning Notice

- Do not clean and reuse the composite filter. Do not clean the unit with corrosive chemical cleansers.
- Use a soft cloth to clean the unit to prevent damage or malfunction of the sensors.
- To prevent damage, electric shock, or fire, do not clean the unit with ethyl alcohol or organic solvents.
- To prevent electric shock or fire, turn off the power and remove any foreign objects from the plug when cleaning or not using the unit.

Storage


- Store the unit in a dry place.
- Keep it away from flammable or combustible materials.
- Cover it with the protective bag.

Tips


- Not suitable for use by individuals with disabilities, sensory impairments, cognitive disorders, or children without supervision.
- Do not set, lean on, or push against the unit to avoid injury.
- Unplug the unit before moving it.
- If the power cord or any part of the unit is damaged, it must be replaced by the manufacturer, a service agent, or a similarly qualified person to prevent hazards.
- Do not use the unit and contact the supplier to replace the filter if it generates a peculiar smell while running.

PRODUCT DETAILS

Product List



Product Structure



OPERATION GUIDE



- O POWER (short touch) turn the unit on/off
- POWER (touch and hold for 3 sec when the unit is on)- turn on Wi-Fi
- (2) SPEED select from 3 fan speeds and Auto Mode
- SLEEP turn off the light and set the unit to low speed for low noise operation
- (3) TIMER set the unit to turn on/off within 1-12 hours
- TIMER (touch and hold for 3 sec) reset the filter replacement timer

After plugging in, the unit enters standby mode.

Air Quality Indication

Green ·····•	Perfect	:	Blue	 Good
Yellow	Normal		Red	 Poor



Touch and hold the "TIMER" + "POWER" buttons for 3 seconds to reset the filter.

A.When the filter indicator light turns red, the filter needs to be replaced.




In power-on mode, touch and hold the "CHILD LOCK" button for 3 seconds to activate the child lock function. The indicator light will turn on.

A. Once activated, other buttons will be disabled.



When the filter indicator light turns red, it's time to replace the filter.

1.Turn off the unit and unplug the power cord.





2.0pen the filter cover After turning off the unit, locate the buckle on the filter cover and pull it out.



3.Remove the composite filter and place the used filter in a bag to prevent contamination.

A. The pre-filter can be cleaned and reused.

B. The composite filter that has reached the end of its service life cannot be reused, even if cleaned. Please dispose of it as non-burnable waste.

4.Align the new filter with the filter slot in the purifier, install it, and then close the cover.

5.Turn the power on by touching the "POWER" button, then touch and hold the "TIMER+POWER" buttons for 3 seconds to reset the filter replacement timer.

COMMON TROUBLESHOOTING

If your air purifier is not functioning properly, please check the following before requesting a repair.

Phenomenon	Possible Cause	Solution	
1. The machine does not start.	a.The power plug is not connected. b.The filter cover is not properly installed.	a.Reinsert the power plug b.Properly install the filter cover.	
2. There is sme ll in the outlet.	a.There are many sources of pollution in the room. b.The filter is heavily polluted.	a.Open the windows to ventilate the room. b.Replace the filter with a new one.	
3. Dust purification is ineffective, and air quality shows no improvement.	a.The filter is not installed. b.The unit is placed in a narrow space or near obstacles. c.The filter is too dirty.	a.Install the filter. b.Remove obstructions or change location. c.Clean or replace the filter.	
4. The running noise is too loud.	a.The unit is not installed firmly enough. b.There is debris inside the unit.	a.Contact the after-sales service center. b.Remove any debris.	
5. The buttons are not working.	a. The child lock be enabled.	a.Touch and hold the "Child Lock" button for 2 seconds to deactivate it.	
6.The filter doesn't fit.	a. The filter is reversed.	a.Adjust the filter to the correct direction. Align the filter with the bottom groove and install it properly.	

Note: If the issue persists after performing the above checks, please contact the authorized repair shop or technical service center. Do not attempt to disassemble or repair the unit yourself, as this may cause injury or further damage to the device.

WARNING: To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer).

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example– use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.