

SOUNDPEATS Q说明书

颜色: K 尺寸: 90x84mm

材质: 封面100克书纸、内页80克书纸



Package Content

Specifications

Bluetooth Version	Bluetooth 5.0
Maximum Working Range	About 10m (no obstacle)
Play Time	7 hours
Earbuds Charging Time	1.5 hours
Case Charging Time	2 hours
Charging Case Recharge Earbuds	2 times
Earbuds Dimension	35.2*18.7*24.2 mm

Product Diagram

Button Control

Power On	Auto: Open up the case lid Manually: Press and hold the MFB for 1.5s
Power Off	Auto: Place back the earbuds into charging case and close the lid Manually: Press and hold the MFB for 10s
Play / Pause	Double tap the MFB
Volume -	Single tap the left MFB
Volume +	Single tap the right MFB
Previous Track	Press and hold left MFB for 1.5s
Next Track	Press and hold right MFB for 1.5s
Answer / Hang Up Phone Call	Double tap the MFB
Reject Phone Call	Press and hold the MFB for 1.5s
Switch Between Two Calls	Press and hold the MFB for 2s
Manually Enter Pairing Mode	Place back the earbuds into the charging case and open the lid, Press and hold the charging case button for 3s
Activate Voice Assistant	Triple tap MFB on right earbud

Wearing

Getting Started

Pairing

1. Open up the case lid while the case is with enough power left and make sure the earbuds is in the charging case, the left and right earbuds will pair to each other automatically with a prompt suggests successfully connected. Then pls press and hold the button of the charging case for 3S until the indicator of the charging case starts to flash and the earbuds prompt "Pairing", then the earbuds enter pairing mode.

2. Activate the Bluetooth on your device and hit "SOUNDPEATS Q" on the bluetooth list to connect. The earbuds will prompt "Connected" after connecting successfully.

3. SOUNDPEATS Q earbuds can remember previously paired device. To reconnect to one device, you only need to activate the Bluetooth in the device and take out both earbuds, the earbuds will automatically connect to each other, and then pair to the device. If they don't re-pair automatically, please choose the pairing name to connect again.

4. Mono mode: SOUNDPEATS Q earbuds support working with either earbud only after successfully connected.

Factory Reset

(Try the following steps if you fail building re-connection between two earbuds, or fail building connection between earbuds and device.)

1. Clear the pairing record between the earbuds and all your devices.

2. Place back both earbuds into the charging case and open up the case lid. Press and hold the charging case button for 10s.

Charge

SOUNDPEATS Q earbuds are provided with a charging case for easy carrying and charging. It can recharge both earbuds for around 2 times.

Charge the earbuds

The earbuds have been partially charged at the factory. Pls make sure they are fully charged before using for the first time.

1. Place back the earbuds in correct charging slots and make sure the contactors connect.

2. Charging starts with the indicators staying on, and ends with the indicators going out.

Charge the case

The charging indicators will turn to red when the battery of the case is low, please charge the case then.

Method 1:

1. Use a Type-C adapter to charge the case (current not over 1A).

2. Please charge the earbuds and case at least once per 3 months when not in use for a long time.

Method 2:

1. Place the charging case directly above the wireless charger.

2. Please charge the earbuds and case at least once per 3 months when not in use for a long time.

Warranty and Support

We warrant this device 12 MONTHS from date of the original purchase for manufacturer defects.

@ support@soundpeatsaudio.com

@ www.soundpeatsaudio.com

Please scan the QR code to check the detailed PDF manual in more details.

<https://soundpeatsaudio.com/downloads/>

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.