




## ULTRA S



### Guía Rápida

Google, Android, Google Play, YouTube y otras marcas son marcas de Google LLC.

#### Conoce tu Bmobile ULTRA S





- |  |                            |
|--|----------------------------|
| 1. Conector de auricular (jack 3.5 mm) | 6. Micrófono               |
| 2. Cámara frontal                      | 7. Conector USB            |
| 3. Auricular                           | 8. Botón Encendido-Apagado |
| 4. Pantalla LCD                        | 9. Botones de volumen      |
| 5. Altavoz                             | 10. Cámara Trasera         |
|  | 11. Flash LED              |

#### Antes de encender cargue por 24HRS



Nota: La imagen del cargador puede variar según la zona de venta. Dependiendo la zona, región, operación o donde se adquiriera este producto, puede tener o no disponible la función de DUAL SIM.

#### Inserte la tarjeta SIM y tarjeta de memoria



#### Siga estos pasos:

**Encienda el teléfono presionando el botón de encendido**

Para escuchar RADIO conecte sus auriculares y busque su emisora de radio favorita.

Para escuchar MUSICA desde la tarjeta de memoria ingrese desde el reproductor de audio.

Puede tomar FOTOS ingresando a la CAMARA que se encuentra en el menú principal.

Puede enviar MENSAJES DE TEXTO desde el menú principal.

Para navegar por internet use el acceso directo al NAVEGADOR en el menú principal.



Descarga el Manual de Usuario




## ULTRA S



### Quick Start Guide


Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC.

### Know your Bmobile ULTRA S





- |  |                  |
|--|------------------|
| 1. Earphone connector<br>(jack 3.5 mm) | 6. Microphone    |
| 2. Front Camera                        | 7. USB connector |
| 3. Receiver                            | 8. Power button  |
| 4. LCD Screen                          | 9. Volume button |
| 5. Speaker                             | 10. Back Camera  |
|  | 11. LED Flash    |

### Before turning it on, charge your phone for 24 Hrs



Note: The image may change depending on the sales area. Depending on the area, region or operation, where this product is acquired, the function DUAL SIM may or may not being available.

### Insert the SIM card and the memory card



### Follow these steps:

Turn on your phone by long pressing the Turn On / Turn Off Button

To listen to the RADIO plug your headphones and find your favorite radio station.

To listen to music from the memory card, enter from the audio player.

You can take the PHOTOS by entering the CAMERA in the main menu.

You can send TEXT MESSAGES from the main menu.

To browse on the internet, use the BROWSER on the main menu.



Download the User manual

#### 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Absorption Rate (SAR) information:

This mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device was tested for typical body-worn operations with the back of the handset kept 1.0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

#### Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.