


86mm

86mm

无线耳机说明书



1 ID示意图



2 简单操作说明

① Android系统 / IOS系统设备配对耳机

1. 打开耳机充电仓上盖，耳机自动开机。
2. 打开手机：设置>蓝牙>打开(菜单可能因设备不同而不同)。
3. 选择“V51”，如果手机要求输入密码，请输入四个零（0000）。
4. 手机显示连接成功后即可使用。

② 关机

1. 放入充电仓合盖5秒后关机
2. 开机3分钟无设备连接，自动关机

3 功能定义说明

① 通话状态下功能定义

来电铃声	手机铃声
来电接听	单击左/右耳
挂断电话	单击左/右耳
来电拒接	双击左/右耳

② 音乐状态下功能定义

播放/暂停	单击左/右耳
上一曲	三击左/右耳
下一曲	双击左/右耳

③ Siri/语音助手

长按左/右耳2秒唤醒

④ 主从切换

左右耳随意回连手机，自由切换，开机秒回连。

⑤ 入耳检测

TWS配对成功后第一只耳机入耳提示“咚”，第二只无提示音。

4 提示音说明

提示项	提示音说明
连接手机	提示音：“咚”

断开手机	提示音：“咚”
触摸提示	提示音：“滴”
低电提示	提示音：“滴”“滴”

5 充电仓定义与参数

① 充电仓指示灯状态

序号	状态	电量指示灯(10%以上)	电量指示灯(10%以下)
1	开盖	绿灯亮8秒	橙灯亮8秒
2	耳机出/入仓检测	绿灯呼吸一次灭灯	橙灯呼吸一次灭灯
3	充电	橙灯亮8秒	
4	充满电	/	

② 充电仓参数

序号	功能	描述
1	电池容量	300mAh
2	充电方式	Type-C
3	充电电压/电流	5V 1A
4	充电时间	约1.5小时
5	续航能力	约3~4次（双耳充电）
6	工作温度/存储温度	-10℃~+45℃ / -20℃~+65℃

6 耳机参数


序号	项目	参数规格
1	产品名称	无线耳机
2	电池容量	30mAh
3	充电电流（双耳）	30mA
4	频响范围	20Hz-20KHz
5	产品阻抗	32Ω
6	灵敏度	114±3dB
7	产品尺寸	30.75*19.78*16.25mm
8	蓝牙接收距离	10米(标准环境下)
9	产品重量	3.3g(不含充电仓)
10	蓝牙版本	V5.3
11	支持协议	HFP/HSP/A2DP/AVRCP
12	工作频率	2.4GHz频段(2.4000-2.4835GHz)
13	耳机充电时间	约1小时
14	续航时间	通话时长：约4.5小时(双耳通话) 连续音乐播放：约5.5小时(50%音量) 整机待机时间：200天
15	充电电压/电流	5V 1A
16	产品工作温度	-10℃~+45℃
17	产品存储温度	-20℃~+65℃

7 注意事项


- ✦ 请在常温环境中存放及使用本产品；
- ✦ 请勿将本产品暴露在雨中或潮湿环境中；
- ✦ 请勿丢掷，避免因跌落造成产品损坏；
- ✦ 请勿拆解，修理和改造本产品；
- ✦ 请勿使用化学溶剂擦拭本产品；
- ✦ 请勿随意丢弃，或置于高温(温度高于60度)与火中，以免引起危险。



Wireless Earbuds User Manual



1 ID Diagram



2 Instructions

① Pairing the Earbuds with Android system/IOS system

1. Open the top cover of the charging case, the earbuds will automatically turn on
2. Turn on your phone: Settings>Bluetooth>Turn on (menu may vary by device)
3. Select "V51", if the phone asks for a password, enter four zeros (0000)
4. The mobile phone can be used after the connection is successful

② Power off

1. Put the earbuds into the charging cast and close the lid for 3 seconds to shut down;
2. Auto-power off in 3 minutes without connecting the device.

3 Function Description

① About Call

Incoming call rings	It comes with ringtone
Answer a call	Press left/right earbud once
Hang up a call	Press left/right earbud once
Reject a call	Double press on the left/right earbud

② About Music

Play / Pause	Click left/right earbud once
Previous song	Triple press the left/right earbud
Next song	Double press on the left/right earbud

③ Siri/Voice assistant

Long press the left/right earbud for 2s to wake up

④ Both earbuds can be switched freely

The left and right earbud can be connected to the mobile phone at will, switch freely, and connect back in seconds after booting

⑤ In-ear Test

After TWS pairing is successful, the first earphone will sound "Dong", and the second earphone will not sound

4 Prompt tone description

Items	Prompt tone
Connected	Prompt tone: "dong"

Disconnected	Prompt tone: "dong"
Touch	Prompt tone: "beep"
Low battery alarm	Prompt tone: "beep""beep"

5 Charging case definition and specification

① Indicator light on the charging case

No.	State	Battery indicator (more than 10% battery)	Battery indicator (less than 10% battery)
1	Open the lid	Green light on for 8s	Orange light on for 8s
2	Earphone out/in	Green light flashes 1 time it has no light effect	Orange light flashes 1 time it has no light effect
3	Charging	Orange light on for 8s	
4	Full charged	/	

② Charging case specification

No.	Function	Description
1	Battery	300mAh
2	Charging port	Type-C
3	Charging voltage/current	5V 1A
4	Charging time	about 1.5 hours
5	Recharging times	Recharge both earbuds 3-4 times
6	Working/Storage temperature	-10℃~+45℃ / -20℃~+65℃

6 Earphone Specification

No.	Items	Specifications
1	Product name	Wireless Earbuds
2	Battery	30mAh
3	Charging current (dual-earbuds)	30mA
4	Frequency response range	20Hz-20KHz
5	Impedance	32Ω
6	Sensitivity	114±3dB
7	Size	30.75*19.78*16.25mm
8	Available distance	10 meters (standard environment)
9	Weight	3.3g(exclude charging case)
10	BT version	V5.3
11	Supporting protocol	HFP/HSP/A2DP/A/RCP
12	Transmission frequency	2.4GHz(2.4000-2.4835GHz)
13	Charging time	About 1hours
14	Working time	Call time: about 4.5 hours Music time : about 5.5 hours (50 % volume) Standby time: 200 days
15	Charging voltage/current	5V 1A
16	Working temperature	-10℃~+45℃
17	Storage temperature	-20℃~+65℃

7 Precautions

- ✦ Please store and use this product in a normal temperature environment
- ✦ Do not expose this product to rain or moisture
- ✦ Do not throw , to avoid product damage due to falling
- ✦ Do not disassemble, repair or modify this product
- ✦ Do not use chemical solvents to wipe this product
- ✦ Do not discard it at will, or place it in high temperature (temperature higher than 60 degrees) and fire to avoid danger

小六代杰里（非弹窗、非降噪）说明书

材质：105g双铜

尺寸：86*86mm

印刷：正反印+4C

折叠方式：风琴折



FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.