

CQL1899-TWS Bluetooth Speaker

Instruction Manual (Read before proceeding)

Power:

- Please charge the Bluetooth device fully before its first use.

To charge the battery:

- Using a Micro USB Charging Cable (included), insert the USB power cable into the micro USB port located on the back side of the device. Connect the other end of the USB cord into a powered USB source such as a computer, laptop or USB AC adapter.

The LED indicator will turn RED while charging and turn off when fully charged.

Setting Up the Vortex Bowl

1. Pour the included glitter into the included vortex bowl. Place the included magnet into the bowl.
2. Fill the vortex bowl with water until the water line is about 1cm from the top.
3. Place the cover on top of the vortex bowl, making sure it seals completely. Place the sealed vortex bowl on top of the speaker base.

Powering On /Off

Move the power switch to the ON position to power the speaker, LED lights & glitter vortex ON. When powered ON, the speaker will enter Bluetooth pairing mode, and will automatically reconnect to a previously-paired device in range with Bluetooth enabled.

Move the power switch to the middle position to power only the speaker on.

Move the power switch to the OFF position to power the speaker and glitter vortex OFF.

Note: If you remove the vortex bowl while the vortex is in motion, you will need to power the speaker off and on again to re-enable the vortex.

Bluetooth Speaker Operation

- Turn on the unit by pushing the switch to left position. The LED indicator turns blue and flash quickly which indicates the speaker is in pairing mode and searching for your Bluetooth mobile device.
- Open the Bluetooth function on your device and search the speaker named “AR1020”. After selecting this speaker, your device will pair without a password. (If required, enter the password “0000” to finalize the pairing). The Blue light will begin to be solid blue after pair is complete.
- Start playing music on your device. Keep your device within 33feet (10 meters) of your speaker.
- Adjust the volume of your device to a comfortable level.
- Turn off the unit when not in used.

True Wireless TWS Pairing Two Speakers

If you have 2 AR1020 Vortex Speaker, they can be paired to each other and used together.

1. Make sure both speakers are connected to power
2. Power Both speakers ON at the same time
3. After a moment, the speaker will automatically pair to each other, and a tone will be heard. You may now pair the speaker pair to your device following the instruction.

Using the light

- The glitter in the watery chamber sparkling automatically together with the cycles through LED colors after power on.
- When music comes in, LED light response to the music.

Caution:

- This is not a toy. Please keep away from small children.
- Please keep away from water / heat.
- Low power may cause poor connection even no working of Bluetooth.
- Do not over charge the battery.

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
3. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.