

## Quick Guide



- |   |                        |
|---|------------------------|
| 1. Volume Up/Previous Song  | 4. Indicator Light     |
| 2. Power ON/OFF / Multi-function, Call, Answer, Redial, Hang Up, Play/Pause | 5. Charging Port       |
| 3. Volume Down / Next Song  | 6. Line-in             |
|   | 7. Built-in Microphone |

## CHARGING THE HEADPHONES

These headphones have an internal rechargeable battery. The battery must be fully charged prior to use. Charging time is approximately 3hrs. Your headphones cannot be used while charging

Red Light ON – Charging  
Blue Light ON – Fully charged

## PAIRING THE HEADPHONES TO BLUETOOTH DEVICE

Make sure Bluetooth functionality is available on your smartphone. Specific pairing procedures will be different depending on different smartphones. For more detailed information, please refer to your smartphone's Help and/or User Guide.

- If no device connection is made within 5 minutes of the headphones being switched on, the headphones will automatically be turned off to save power.
- After a successful pairing, the devices will memorize and/or save each other's information. Therefore, there will be no need to pair a second time.

1. Keep the distance between the smartphone and the headphones within 3' (for pairing only).
2. Press the multifunction button for two seconds and the headphones will turn on. You'll hear 'Power ON' prompt and the blue light will turn on.
3. The device will automatically go into pairing mode, you'll hear 'Pairing' prompt as the blue and red lights alternately flash.
4. Activate the Bluetooth function of the smartphone and search for Bluetooth devices. Select "Tzumi-Headphones" in the device list that is displayed.
5. On some devices you'll need to press "Yes" or "Enter" key to confirm the pairing.
6. After a successful connection, the blue light on the headphones will flash every few seconds.

## HEADPHONES CONTROLS

### Making and receiving calls

You can use your earbuds in various ways for handling calls.

Answer a call \_\_\_\_\_ Press during an incoming call

End a call \_\_\_\_\_ Press during a call

Redial last number \_\_\_\_\_ Press twice

### Music Controls

Play music \_\_\_\_\_ Press

Pause/resume music \_\_\_\_\_ Press

Go to next song \_\_\_\_\_ Press and hold

Go to previous song \_\_\_\_\_ Press and hold

Power ON/OFF \_\_\_\_\_ Press and hold

### Changing the volume

When needed, adjust the volume by pressing the keys (up) or (down) during a call or when listening to music.

tzumi® Bluetooth Stereo Wireless Headphones Distributed by tzumi® Inc. NY, NY, 10016  
©Copyright 2020 tzumi® All Rights Reserved. Made In China. The Bluetooth trademarks are owned by Bluetooth SIG, Inc. Other trademarks and trade names in this document are those of their respective owners. © 2020 Bluetooth SIG, Inc. Subject to change without prior notice.

尺寸: 127\*151mm  
材质: 128g双铜正反面印刷

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.