

## Instructions of Remote Control

1. Please pull out the insulation tape from the remote control before starting to use it.
2. Press the button to select functions. The functions are :



**ON /OFF:** turn on/OFF the lights



Touch outside upper half arc color disk 50% brightness



Touch inside upper half arc color disk 100% brightness



Touch outside lower half arc color disk 50% brightness



Speed+



Warm white/White



6 Multi /7 Multi



Speed-



Warm white 5 Multi/White



Warm white Red



Warm white Green



Red Green

**Demo:** Demo All Functions

**Fading:** Fading on every colors

**Glittering :** Glittering on every colors

**Meteor:** Meteor on every colors

**Twinkle:** Twinkle on every colors

**Flashing:** Flashing on every colors

**Fireworks:** Fireworks on every colors

**Waves:** Waves on every colors





## Instructions of 1 button control

1. Press ON/OFF button, select lighting functions below cycle.

Function : **ON/OFF** button, turn on or turn off the lights.

### FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.