



Wireless Earphones




Q36 QuickGuide

English


www.adesso.com

①

CONTENTS



Overview



④

LIMITED WARRANTY

Adesso® provides a one year limited warranty for all of its products against defects in materials and workmanship.

During this period, Adesso® will repair or replace any product which proves to be defective. However, Adesso® will not warrant any product which has been subject to improper handling, abuse, negligence, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso® and products where the sealed assembly trace has been broken. If you discover a defect, Adesso® will, at its option, repair or replace the product free of charge, provided you return it during the warranty period with freight charges pre-paid to Adesso®. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

SUPPORT

FAQ's <http://www.adesso.com/faqs>

Email Support: support@adesso.com

Telephone Support:

Toll Free: (800) 795-6788

9:00AM to 5:00PM PST Monday - Friday

②

Usage Instructions

1. Pairing the earbuds with your smartphone



Step 1: The earbuds would turn on automatically once they are taken out from the charging case, or long touch the panels of both earbuds to turn on manually.
Step 2: Both of the earbuds would automatically pair with each other within 5 seconds. Once they are paired with each other, The earbuds will have a prompt sound. The left earbud will play: Left Channel, and the right earbud will play: Right Channel, which means they are ready to pair with your smartphone.

Step 3: Now switch on Bluetooth in your smartphone and search for nearby devices and pair with the name: **Xtream T2**, with voice prompt 'Connected' after the pairing succeed. Enter '0000' if prompted for password.

The earbuds would re-connect with smartphone automatically after first pairing.

Notes:

The L or R earbud can be used alone to pair with your smartphone, and thus only mono sound is available.

2. During Music Playback

2.1 Touch the L or R panel ONCE to Play / Pause the track

2.2 Touch the L or R panel TWICE to skip to Next track

2.3 Touch the L or R panel THREE TIMES to skip to Prev. track

2.4 ANC: Touch the L or R panel FOUR TIMES to switch among Transparency/ ANC ON / ANC OFF modes

⑤

INTRODUCTION

Experience the ultimate audio freedom with our Wireless Earbuds, featuring Bluetooth 5.3 technology for seamless connectivity and lossless sound. These Stereo Earbuds boast a Dual Mic Call function, ensuring crystal-clear conversations even in noisy environments. Compact in design, they fit snugly in your ears for all-day comfort. Effortlessly control your music and calls with intuitive Touch Control, while the ergonomic design ensures a secure fit during your busiest days. Elevate your listening experience with these high-performance earbuds.

SPECIFICATIONS

- Connectivity: Bluetooth
- Charging: USB-C or Wireless Charging
- Driver: 10 mm
- Music Playback: 6 - 7 hours
- Wireless Range: 10 meters
- Control Method: Touch
- Batteries: Earbuds 40mAh / Charging Case 300mAh
- Microphone: x4
- ANC & ENC: Supported
- Operating temperature: 0°C — 40°C
- Case Dimensions: 2.2"x 1.12"x 1.73" (56 x 28.5 x 44 mm)
- Weight: 0.09 lbs (41g)

REQUIREMENTS

Devices with Bluetooth

③

2.5 Long touch the L or R panel for 3 seconds to trigger the Siri or Google Assistant.

3. During Calls

3.1 Touch the L or R panel ONCE to attend the incoming call / end the call.

3.2 Touch the L or R panel for 2 seconds to reject the incoming call.

With total 4 mics for perfect calls (ENC): The earbuds will reduce the wind and noise interference, so your words always come through loud and clear.

4. Charge the Earbuds & Charging Case

4.1 Put the earbuds in the charging case, the earbuds power off and start charging automatically.

4.2 When the Case is charging, the case White LED indicator blinks, and White LED glows when the case is fully charged.

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Keep product out of the reach of children and pets to avoid chewing and swallowing.
3. Please protect your ears against loud volume. Loud volume can damage your ears.
4. Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
5. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
6. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.

⑥

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.