

1



2



3



4




5



6

ABOUT DEVICE




01 / SHORTCUT KEYS

FN+Q	Switching to bluetooth connection 1
FN+W	Switching to bluetooth connection 2
FN+E	Switching to 2.4GHz wireless connection
FN+R	Switching to USB connection
FN+F1	Play/Pause
FN+F2	Stop
FN+F3	Prev. Track
FN+F4	Next Track
FN+F5	Mute
FN+F6	Volume Down
FN+F7	Volume Up
FN+F12	Switching to customize profile
FN+L-WIN	WIN key lock/unlock
FN+PRINT	Step to through lighting mode
FN+INS	Turn on the lighting
FN+DEL	Turn off the lighting
FN+PageUp	To change effect direction
FN+PageDown	To change effect direction
FN+UpArrow	Increase effect brightness
FN+DownArrow	Decrease effect brightness
FN+LeftArrow	Increase effect speed
FN+RightArrow	Decrease effect speed

02 / INDICATOR LIGHTS

Indicator Light	Normal Indicator Status *	Wireless Connection Status Indicator **
①	Number Indicator Light	
②	Cap Lock Indicator	Bluetooth device 1 connection status indicator
③	Windows Key Lock Indicator	Bluetooth device 2 connection status indicator
④	Configuration profile indicator	2.4GHz wireless connection status indicator
⑤	Battery indicator	

03 / WIRELESS SWITCH



ON OFF

04 / LIGHTING

Static Mode Wheel Mode Wave Mode

Breath Mode Twinkle Mode Reactive Mode

Laser Mode Ripple Mode Custom Mode

BLUETOOTH CONNECTION

1 Turn on wireless switch.

2 Enter Bluetooth mode by pressing FN+Q/W.

3 The corresponding indicator light flashes quickly upon initial use. Search for K610w/K620w on a device that supports Bluetooth low energy technology and complete the pairing according to the on-device prompts. The corresponding indicator light will be on for 3 seconds and then revert back to the normal indicator status. If re-pairing is needed, long press FN+Q/W for 3 seconds until the indicator light flashes quickly, and then users can proceed with re-pairing.

USB WIRED CONNECTION

1 Plug in the USB cable.

2 Press FN+R to enter USB wired connection mode.

2.4GHz WIRELESS CONNECTION

1 Turn on wireless switch.

2 Plug in the wireless receiver.

3 Press FN+E to enter 2.4GHz wireless connection mode, after which the device will connect automatically. The indicator light will be on for 3 seconds and then revert back to the normal indicator status.

USB WIRED CONNECTION


1 Plug in the USB cable.

2 Press FN+R to enter USB wired connection mode.

LEARN MORE

Check www.durgod.com and download "Durgod Zeus Engine" to get:

- The latest firmware updates
- Entire key customization
- Macro editing function
- On-board and cloud storage of configuration profiles
- The latest information on Durgod products



REGULATORY AND COMPLIANCE INFORMATION

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interfere by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and consider removing the re-configuration statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Hereby, Zhuhai Hoki Technology LTD., CO declares that the radio equipment type DURGOD K610/K620w Wireless Mechanical Keyboard and Infinite Wireless Receiver are in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://www.durgod.com>


CAUTION:

- (1) Risk of fire or explosion or defect the safeguard of equipment if the battery is replaced by an incorrect type. Replace only with the same or equivalent type.
- (2) Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery that can result in an explosion.
- (3) High or low extreme temperatures or low air pressure at high altitude that the battery can be subjected to during use, storage or transportation.
- (4) Leaving the battery in an extremely high temperature and/or low air pressure surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

保修服务卡

产品型号	
购买日期	
用户姓名	
联系电话	
通讯地址/邮编	
产品S/N码	

质量检测合格



厂址: 珠海市华夏电子科技有限公司
地址: 珠海市香洲区南屏科技园屏北一路6号高裕丰大厦8楼



封底



封面

保修服务指南

■ 感谢您对DURGOD (杜伽) 的信任与支持

DURGOD将为您提供一年的产品免费保修服务, 请勿擅自涂改本保修服务卡, 以维护您的合法权益。如蒙服务或技术支持, 请咨询相关经销商或与我们联系。

■ 我们承诺

对保修期间内及在保修服务范围内的产品, DURGOD将按照本服务政策进行维修、更换或退货在合理的时间内免费为您恢复产品的正常使用功能; 对超出保修期和保修服务范围之外的产品, DURGOD将按照本服务政策提供有偿维修服务。


■ 保修服务时须提供

- 申请保修的DURGOD产品或附件。
- 有效的购买凭证。

■ 质保不包含一下原因导致的问题和损坏:

- 产品正常使用磨损。
- 由于人为原因造成的损坏, 包括但不限于因跌落、挤压、碰撞造成的损坏, 因液体泼洒、化学品质蚀、异物进入内部造成的损坏。
- 因使用、保养、维护不当造成的损坏。
- 产品经任何未经授权方拆卸、维修、批发号去除、涂改难以辨认。
- 产品超出保修期。
- 因不可抗力损坏。

了解设备




01 / 快捷键

FN+Q	切换蓝牙设备1
FN+W	切换蓝牙设备2
FN+E	切换2.4无线模式
FN+R	切换USB模式
FN+F1	播放/暂停
FN+F2	停止
FN+F3	上一曲
FN+F4	下一曲
FN+F5	静音
FN+F6	音量减
FN+F7	音量加
FN+F12	调用预设配置文件
FN+L-WIN	WIN键功能锁定/解锁
FN+PRINT	灯光模式循环切换
FN+INS	打开全键灯光
FN+DEL	关闭全键灯光
FN+PageUp	灯光动态方向切换
FN+PageDown	灯光动态方向切换
FN+UpArrow	灯光亮度等级调高
FN+DownArrow	灯光亮度等级调低
FN+LeftArrow	灯光动态速度等级调减
FN+RightArrow	灯光动态速度等级调增

02 / 指示灯

指示灯	正常指示状态 *	无线功能状态 **
①	数字键盘指示灯	
②	大小写指示灯	蓝牙设备1连接状态指示灯
③	解锁 (Fn+Win) 指示灯	蓝牙设备2连接状态指示灯
④	配置文件指示灯	2.4G 无线连接状态指示灯
⑤	电量指示灯	

03 / 无线开关



ON OFF

04 / 灯光模式

常亮模式 呼吸模式 渐亮模式 渐暗模式

旋转模式 波浪模式 涟漪模式 自定义模式

蓝牙设备连接

1 无线开关处于ON的状态。

2 按下FN+Q / W进入蓝牙模式。

3 初次进入蓝牙模式, 对应的指示灯闪烁, 在支持蓝牙低功耗技术的设备上搜索设备, 根据设备提示完成配对, 对前指示灯常亮3秒后恢复至正常指示状态。如需要重新配对, 长按FN+Q/W 3秒直至对应指示灯快闪, 则可重新进行配对。

2.4G 无线连接

1 无线开关处于ON的状态。

2 插上无线接收器。

3 FN+E进入2.4G无线模式, 设备自动完成连接, 对应指示灯常亮3秒后恢复至正常指示状态。

USB有线连接


1 插上USB数据线。

2 FN+R进入USB模式。

获取更多

访问 www.durgod.com, 下载DURGOD ZEUS ENGINE, 您将获得:

- 最新的固件升级
- 全部按键自定义
- 宏编程功能
- 配置文件能缓存与云存储
- 最新的产品咨询



QUICK START GUIDE

一 用户指南

七折页 含保修卡

尺寸: 68X125(h)mm

