
尺寸:100x85mm







暂停/播放:短按一下MFB键 上一曲:播歌状态下按两下L耳MFB键 下一曲:播歌状态下按两下R耳MFB键 音量加:长按右耳MFB键 音量减:长按左耳MFB键 接听电话:来电时单击MFB键 挂断电话:通话时单击MFB键 来电拒接:来电时双击MFB键 取消通话:拨号时单击MFB键 呼叫Siri:不播歌状态按3下左或右MFB键 取消Siri:不播歌状态按1下左或右MFB键

1.初次开始使用的情况下,当耳机从充电仓里取出 耳机就会自动开机。 放回充电仓耳机就会开始充电并自动关机。

2.当耳机不使用时,放回充电仓自动关机。

耳机在配对状态下,4击MFB键。将耳机放入 充电仓,耳机会自动关机并开始充电。取出耳机后,耳机 会自动开机,重置就完成。

1.从充电仓拿出开机 3.打开手机/平板的设置---蓝牙---打开蓝牙---搜索---YYK-Q71---配对/连接--播放音乐。

打开电脑设置-设备-蓝牙和其他设备-开启蓝牙--添加蓝牙 或其他设备-搜索蓝牙设备YYK-O71-配对/连接-播放音乐。 注意:如果电脑没有蓝牙,请插入蓝牙适配器,下载蓝牙驱动

如何给耳机充电

1.把耳机放入充电仓内,耳机就会自动关机然后开始充电, 充电仓显示灯亮起,说明充电仓正在给耳机充电。 2.耳机充电时红灯常亮,充满蓝灯常亮充电仓灭灯。

给充电仓充电

请使用手机适配器给充电仓充电,可以使用电脑Type-c线 或者其他Type-c接口的充电器进行充电。

高质量的耳机,为了延长使用寿命,请参考以下说明: 1.请本品远离高温、高湿、腐蚀环境。 2.请防止本品被撞击,跌落,弯曲,浸泡等。 3.请不要拆耳机或者充电座。 3.请不要拆耳机或者充电座。
4.请不要拆革机或者充电座。
6.如果它引任何不适感或者疼痛。请停止使用本品。
6.使用由受监管的制造商认证的DC 5V-1A适配器。
反复充电机取电机会导致电池性能随时间降低,这对所有可充电电子产品来说都是正常的。

产品包装内有

1.蓝牙耳机2个 2.充电座1个 3.Type-c充电线1条 4.说明书1本


User Manual

—Product description—



YYK-Q71 Clip on Wireless headset

Wireless Version: V5.3 Talk time: about 6 hours Music playing: about 6 hours Standby time: 80 hours Communication distance:>10m Charging time of headset: about 1 hour Headset battery capacity: 30MAH Battery capacity of charging chamber: 300MAH Frequency characteristic: 2.40ghz-2.48-ghz Support agreement:A2DP1.3/HFP1.6 HSP1.2/AVRCP1.6/D11.3



Pause/play:Briefly press the MFB key

Last song: Press the Lear MFB key twice when playing the song

Next song: Press the Rear MFB key twice when playing the song

Sound plus: Press and hold the right ear MFB key

Sound reduction: Press and hold the MFB key on

Answer the call: Click MFB key when calling

Hang up the phone: Click MFB key during call

Call rejection: Double-click MFB key when calling

Cancel call: Click MFB key when dialing

Call Siri: Press the left or right MFB key 3 times in the state of not playing songs

Cancel Siri:Press the left or right MFB key once when the MFB key is not playing songs

1. When the headset is taken out of the charging chamber for the first timeThe headset will turn on automatically

Put the headset back in the charging chamber and it will start charging and automatically shut down.

2. When the headset is not in use, put it back into the charging chamber and turn it off automatically.

When the headset is in pairing status, press the MFB key 4 times. Put the headset inThe headset will automatically shut down and start charging. After removing the headset

It will start automatically and the reset will be completed.

- 1. Take out the charging chamber to start the machine
- Automatic headset pairing
 Open the settings of mobile phone/tablet --- Bluetooth
- Open Bluetooth --- Search--
- YYK-Q71 --- pairing/connecting --- playing music.

omputer/laptop pairing metho

Turn on PC settings - Devices - Wireless and other devices - Turn on Wireless - Add WirelessthOr other devices - search Wireless device YYK-Q71 - pair/connect- play music.Note: If the computer does not have Wireless, please insert the Wireless adapter and down load the Wireless driverThen it can be used normally.

- 1. Put the headset into the charging compartment, and the headset will automatically shut down and start charging, The display lamp of the charging compartment lights up, indicating that the charging compartment is charging the headset.
- 2. The red light is always on when charging the headset, and the blue light is always on when charging the headset. The charging chamber

Please use the mobile phone adapter to charge the charging chamber. You can use the computer Type-c cableOr other chargers with Type-c interface.

For high-quality earphones, please refer to the following instructions to 1. Please keep away from high temperature, high humidity and corrosive environment.

- environment.

 2. Please prevent the product from being hit, dropped, bent, soaked, etc.

 3. Please do not remove the headset or charging stand.

 4. Please do not allow the product to be overcharged all the time, so as to reduce the service life of the product.

 5. If it causes any discomfort or pain, please stop using this product.

 6. Use a 0 EV-JA adapter certified by a regulated manufacturer.

 Repeated charging and discharging of the headset will cause the battery performance to decrease over time, which will affect all rechargeable Electronic products are normal.

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the

FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/
TV technician for help.

FCC RF Radiation Exposure Statement:

- 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- 2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance **5mm** between the radiator and your body.