



Hyper-K Wireless Ultralight Gaming Mouse

P/N 44028

Quick User Guide

PACKAGE CONTENTS

- 1x Hyper-K Wireless Ultralight Gaming Mouse
- 1x USB Micro Receiver
- 1x USB Charging Cable
- 1x Quick User Guide

ONLINE SUPPORT

Monoprice™ is pleased to provide free online support. For order related issues, contact the Customer Service department through the Live Chat link on our website **www.monoprice.com** or via email at **support@monoprice.com**

For technical issues, contact the Technical Support department through the online chat button on our website **www.monoprice.com** or by sending an email to **tech@monoprice.com**

Check the website for support times and links.



CHARGING

1. When the internal battery charge is low, the scroll wheel LED will flash red.
2. Plug one end of the included USB Charging Cable into the mouse, then plug the other end into a USB power source. The scroll wheel LED will flash blue while charging is in progress. You can use the mouse while it is charging.
3. When charging is complete, the scroll wheel LED will change to a solid color corresponding to the selected DPI setting.

WIRED/WIRELESS OPERATION

To use the mouse in wired mode, simply plug one end of the included USB Charging Cable into the mouse, then plug the other end into an available USB port on your computer. Wired operation offers better and smoother performance than wireless mode. If the USB Micro Receiver is not plugged into your computer, the scroll wheel LED will flash blue during wired operation.

The mouse is automatically in wireless mode when it is not plugged into your computer. For best results, plug the USB Micro Receiver into an available USB port on your computer, then ensure that the mouse and the Receiver are as close as possible to each other, with no obstructions to interfere with the wireless signal.


DPI INDICATIONS

When not indicating charging or wired operation status, the scroll wheel LED changes color, depending on the selected DPI setting. The following table shows the corresponding colors for each DPI setting.

LED Color	DPI Setting
Red	800
Green	1600 (default)

LED Color	DPI Setting
Blue	3200
Purple	6400
Yellow	12000
Cyan	16000

PRODUCT OVERVIEW



SPECIFICATIONS

P/N	44028
Sensor	PixArt® PAW 3335
DPI Settings	800, 1600, 3200, 6400, 12000, 16000
Scroll Wheel LED Colors	Red, Green, Blue, Purple, Yellow, Cyan
Polling Rate	Up to 1000Hz
Acceleration	40g
Compatible Operating Systems	Windows® XP/2000/Vista®/7/8/10, macOS®
Button Life	20 million presses
Nominal Input Power	5 VDC, 30mA
Battery Capacity	400mAh
Operating Time	Up to 50 hours without LED
Charging Time	About 3 hours
Dimensions (LxWxH)	4.9" x 2.6" x 1.5" (126 x 66 x 39 mm)
Weight	2.5 oz. (70g)

REGULATORY COMPLIANCE

Notice for FCC



This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Modifying the equipment without Monoprice's authorization may result in the equipment no longer complying with FCC requirements

for Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Notice for ISED Canada

This device complies with ISED Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Monoprice™, Dark Matter™, the Dark Matter logo, and all Monoprice logos are trademarks of Monoprice Inc.

USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

PixArt® is a registered trademark of PixArt Imaging Inc.

Microsoft®, Windows®, and Vista® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Apple®, Mac®, and macOS® are trademarks of Apple Inc., registered in the U.S. and other countries.