Guaranteed for Life

E-filliate warrants to the consumer that the product and all accessories provided in the sales package ("Product") are free from material defects in material and workmanship when used normally and in accordance with operation instructions.

E-filliate will repair or replace (at E-filliate's option), without charge, a Materially Defective Product. If we repair or replace a Materially Defective Product under the terms of this warranty, this warranty also applies to repaired or replacement Products. If we repair this Product, we may use new or refurbished replacement parts. If we choose to replace this Product, we may replace it with a new or refurbished Product of the same or similar design. E-filliate will return repaired or replacement Products to you in working condition. We will retain defective parts, or equipment. Repair or replacement of Product is your exclusive remedy.

This warranty does not cover Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion, or Product that has been damaged due to repair, alteration or modification by anyone other than an E-filliate authorized representative.

Customer Service:

We're here to help. If you have a problem with this product or have questions on how to use it, please contact E-filliate Inc. You do not need to contact the retailer from whom the product was purchased. Please contact one of our service representatives before shipping merchandise to us.

www.efilliate.com support@efilliate.com

(800) 592-7031 toll-free (916) 858-1000 (916) 858-1009 FAX

11321 White Rock Road Rancho Cordova, CA 95742 USA

Customer service representatives are available 8 a.m.-5 p.m. PT, M-F

Wireless Earphones w/built-in Mic

User Manual FCC:ID 2ADH6-1909018C

Thank you for purchasing the wireless earphones. The earphones allow the user to listen to audio wirelessly from up to 32 feet (10m) from a paired phone or tablet.

Please read these instructions carefully. It is recommended that you completely charge the earphones before using them for the first time. See "Charging the Wireless Earphones".



Package Contents

- Wireless earphones
- Extra ear fin cushions
- Type C charge-in cable
- User manualCollar Clip

FCC ID: 2ADH6-1909018C

Please note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Important Safety Information

- This product is IPX4 water resistant so it is designed to prevent perspiration or water droplets from affecting the performance during proper use.
- The earphones should not be submerged in liquid or used in areas with excessive moisture.
- Avoid operating or storing the earphones near fire, on stoves, or inside sealed cars in hot weather. Exposing them to fire may cause the earphones to generate heat or ignite.

Charging the Wireless Earphones

- Charge the wireless earphones by connecting Type C charging cable to the earphones' charging port.
- Plug the USB connector into a USB port on any USB power adapter.
- When charging, a red light on the adapter will be illuminated. Once the light turn blue, the adapter is fully charged. Battery is fully charged in about 1.5 hours.

Controller Functions

- On/off: Press and hold the key for 3 seconds to turn on/off.
- Music or video pause: Press the key to pause playback, and press the key again to resume playback.
- Volume increase: Click the + key.
- Volume decrease: Click the key.
- Next song: Press & hold the + key.
- Previous song: Press & hold the key.
- Answer/hang up: During an incoming call, press the key for two seconds and then release it.

Please note, this controller uses the player app's available functions. The controller's functionality may vary depending on the player app being used.

Pairing the Adapter

For best results, place the earphones within 3 ft of your phone or tablet during pairing.

Press and hold the key on the earphone controller for about three seconds, and then release it when the red and blue lights blink alternately. The earphones are now in pairing mode.

Enable the Bluetooth function of your phone or tablet, search the Bluetooth devices and select "**Wireless 9018**" for pairing and connection.

FCC statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.