

EVOLUTION 2

BLUETOOTH HEADPHONES




Quick Start Guide

Item # MZX667



Make sure the following items are included in your package.



For a look at the various buttons and parts of your headphones, view the graphic below.



1. Previous Song/Volume +
2. Next Song/Volume -
3. Microphone
4. Micro USB Charging Port
5. Line-In
6. Power Button, LED Light

Charging Your Headphones

These headphones include a Micro USB cable that can be connected to your computer or charging adapter to charge the internal battery. Plug the Micro USB end of the included cable into the Micro USB port under the ear cup of the headphone.

Plug the other end into a USB port on your computer or USB charging adapter. The LED indicator will be RED while charging. Once fully charged, the indicator light will turn off. Depending on how drained the battery is, a full charge will take 2-3 hours. A fully charged battery has enough power to last for 12 hours talking and/or music time, and up to 200 hours standby time.

Note: These headphones feature a built-in lithium ion battery. Please charge for at least 4 hours before using for the first time, to help condition the internal battery.

Powering ON/Powering OFF Your Headphones:

Press and hold the Power button for approximately two seconds to power on your headphones. The LED indicator will turn BLUE briefly. The headphones will enter pairing mode, and the LED will flash BLUE rapidly. When the headphones are connected to a device and ready for use, the LED will stay lit BLUE.

Once powered on, you can press and hold the Power button again for approximately three seconds to power off your headphones. The LED indicator light will briefly turn RED before powering off.

NOTE: In order to save power, your headphones will automatically power off if left unpaired and idle for over three minutes.

Pairing Your Headphones With A Bluetooth Device

Ensure that your device is powered on.

To pair the headphones with a device it has not been previously paired with, first power on the headphones following the previous steps. Your headphones will enter pairing mode.

Turn on the Bluetooth on your phone or tablet, and search for available devices.

Select "EVOLUTION 2" from the list of found devices on your Bluetooth device.

When Bluetooth is paired successfully, there will be a prompt tone, and the flashing BLUE light will slowly blink.

Note: If your headphones have been previously paired with another device, they will automatically connect to it if it is powered on and in range of the headphones.

Using Your Headphones Wired

You can use these headphones with the included AUX cable. Connecting the headphones with the AUX cable will disable the wireless functionality.

Wearing Your Headphones

For the best sound performance and a secure, comfortable fit, be sure that the ear cups rest gently on your ear, and the frame sits securely on top of your head.

Storing Your Headphones

The ear cups of your headphones can fold in, making it easy to store when not in use.



Listening To Music

Play/Pause

Press the Power button to play or pause music from your audio device.

Next/Previous Song

Quickly press the Next Song or Previous Song buttons to advance to the next song, or go back to the previous one.

Increase/Decrease Volume

Press and hold the Volume Up or Volume Down buttons to increase or decrease the volume.

NOTE: Music will automatically pause when a call is dialed out, or when there is an incoming call. It will resume when the call ends.

Using Your Headphones During Phone Calls

Making a Call

To make a call, use your mobile phone as you would normally while the headphones are connected via Bluetooth. The audio will come through the headphones seamlessly.

Answering an Incoming Call

To answer an incoming call, quickly press the Power button.

Ending a Call

To end a call, quickly press the Power button, and the call will be disconnected.

Adjusting Volume

By pressing the Volume Up or Volume Down buttons you can increase or decrease the volume of the phone call.

EVOLUTION 2

BLUETOOTH HEADPHONES



Quick Start Guide

Item # MZX667



Maintenance and Care

Before using your headphones, examine the ear cups to make sure they are clean. Similarly, inspect the ports and jacks of your headphones to make sure they are clear of dust and debris before charging or inserting the AUX cable.

Use a soft, moist cloth to clean the cushions of your ear cups. Do not allow moisture to get inside the ear cups. If necessary, use a small amount of dish soap diluted with water to clean more stubborn stains. Never use any harsh chemicals or detergents. Make sure your headphones are dry before using.

When your headphones are not in use, they should be stored in a cool, dry place.

Never tug or yank on the USB cable or AUX cable while connected to your headphones. Connect and disconnect these cables as carefully as possible.

Never expose your headphones to high temperatures, extreme cold, high humidity or excessive moisture or water.

Altec Lansing One Year Warranty Card

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-855-292-4087 or Visit our website at www.alteclansing.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ___ Reorient or relocate the receiving antenna.
- ___ Increase the separation between the equipment and receiver.
- ___ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ___ Consult the dealer or experienced radio/TV technician for help.

JUST LISTEN.



Technical Support

For technical support issues, please visit our website at www.alteclansing.com. You can find manuals and FAQ's at the website. Can't find what you are looking for? Call 1-855-292-4087 to access our technical support information on the phone.