



MARATHON

TRUE WIRELESS EARBUDS+CHARGING CASE

User's Manual for MI-E051T-101

True Wireless Earbuds | Charging Case | USB Type-C Charging Cable

IMPORTANT Please read before using this product

Charge It

EARBUDS

- Checking the "R" and "L" indicators on the charging case, place the right and left earbuds into the corresponding slots so that the magnetic metal charging contacts line-up correctly.
- The LED indicators on the earbuds will glow red and the charging indicators on the case will glow blue. Your earbuds are now charging.
- Once your earbuds are fully charged the LED indicators will turn solid blue. After approximately 5 minutes the LED indicators will turn off.

CASE

- When the case is charging, the led light will slowly flash red. When charge is complete, the red light will turn solid.

* **Note: the case can charge the earbuds while charging itself.**

Pair & Connect with a New Device

- MARATHON will turn on automatically once it is removed from charging case. It will blink alternately red and blue indicating that it is in pairing mode.
- Open the Bluetooth® menu on your smartphone and search for new devices.
- When you see "MERKURY E051T" listed, tap it to connect.
- Once connected with your device, there will be a BEEP from the earbuds.


Reconnect to Bluetooth®

- You only need to pair your Bluetooth® device with these earbuds once.
- With your device's Bluetooth® feature turned on and in range, power on the left & right earbuds.
- They will automatically connect to each other and to your smartphone.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device and select "MERKURY E051T" from the list of paired Bluetooth® devices.

Play

- Connect your device to the earbuds via Bluetooth® (see "Pair & Connect with a New Device.")
- Open your favorite music app and press play.
- Control the music tracks and volume from your device or from the on-ear controls on the earbuds. Touch the button once to play/pause music & answer calls.
- Press the "+" or "-" button to change tracks.
- Press & hold the volume button to raise/lower the volume on the earbuds.
- All audio, including music, games, videos, and notifications will be routed through the earbuds.

Product Diagram



- 1 Charging Input
- 2 LED Indicator
- 3 Ear tips
- 4 Multifunctional Touch Button (MTB)
- 5 +Volume / Next Song
- 6 -Volume / Previous Song

Multi-Funtion Touch Button

Touch Once

- Play/pause music, answer/end phone calls.

Touch & Hold


- Reject a phone call.

Touch & Hold (3-5 Sec.)

- Power on the earbuds and automatically reconnect with last connected Bluetooth device, or power off the earbuds.

Controls Diagram

(On Right Side)



- Press:** Decrease Volume
- Press & Hold (2-3 sec.):** Previous Track
- Press:** Increase Volume
- Press & Hold (2-3 sec.):** Next Track
- Power On/Off**
- Play/Pause Music**
- Answer/End Calls**

QUICK PAIRING GUIDE FOR NEW DEVICES




IMPORTANT: Please follow these directions in the proper order to ensure the earbuds pair and connect properly.


1. Marathon will turn on automatically once it is removed from charging case. It will blink alternately red and blue indicating that it is in pairing mode.
2. On your smartphone open the Bluetooth® menu, power on your Bluetooth® setting and search for new devices.
3. When you see "MERKURY E051T" listed, tap it to connect.
4. Once connected with your device, there will be a BEEP from the right earbud.

Note: If your device asks for a passcode to connect, enter "0000".

Charging Case Diagram



- 1 Charging Case
- 2 Charge-Out
- 3 Charge-In Port
- 4 LED Charging Case Indicator



Troubleshooting

No power	Recharge your earbuds using the included USB Type-C cable. Try using a different USB Type-C cable.
Music is not playing over Bluetooth	Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the earbuds to reconnect your Bluetooth® device.
Bluetooth® device will not reconnect with the earbuds	Navigate to your Bluetooth® settings menu on your Bluetooth device, tap "MERKURY E051T," and select "Forget." Now follow the steps to pair your device again.

Specifications

Specifications: Frequency Response: 20Hz to 20KHz	Bluetooth® Information: Bluetooth® Specification: V5.0 Operating Distance: 30 Ft. (10 Meters)
Battery Information: Built-in Battery: Lithium Charging Input: USB Type-C Battery Capacity: 300mAh Music playing time: Up to 3 Hours* Charging time: Approx. 1 hours	*Approximate Playback time depends on individual use and may be more or less than the time specified.

FCC Notice:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

This device complies with RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

