



fabric air mouse

BCOMFMS

QUICK START GUIDE

Package Contents:

- 1x Universal Fabric Wireless Mouse
- 1x USB Dongle Receiver
- 1x User Manual

* Requires 1x AA Battery (Not Included)

Features:

- The wireless silent mouse is designed to provide a super silent gaming and work experience.
- Low power consumption.
- Advanced 2.4Ghz wireless technology provides operating distance up to 33 feet away.
- Universally compatible with Mac® OS / Windows XP / 7 / 8 / 10 / Linux.

Instructions:

- Remove USB receiver found inside mouse battery compartment.



- Plug USB receiver into your computer or laptop's USB-A Port. Make certain that the mouse is powered on



- Insert one AA battery (not included) in the mouse battery compartment. If you are using a PC, allow the software driver download to computer. Once the software driver has been installed successfully, the mouse should be ready to use. Note: some computers enable the use of the center button on the top of the mouse to adjust the mouse DPI. If your computer does not support this feature, the mouse will operate at 800 dpi.

- To conserve battery power, turn the power off when not in use.

FCC Statement

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Digital Gadgets Limited Warranty Statement

This Limited Warranty covers only the accessory components packaged with this product. This Limited Warranty does not include failure caused by improper installation, operation, cleaning or maintenance, accident, damage caused by extreme temperature, humidity or extreme electrical stress, misuse, abuse, modifications to the product, software faults, normal wear and tear or any other event, act, default or omission outside of Digital Gadgets' control or if the unit casing has been opened. Any attempt to repair this product will void your limited warranty.

To obtain warranty service, please contact Digital Gadgets for specific instructions at the telephone number below. Dated, documented proof of the original purchase is required. Digital Gadgets customer service representatives are available by calling 866-843-6460

Mac® are trademarks of Apple Inc., registered in the U.S. and other countries. All other trademarkst and trade names are owned by their respective owners. © 2019 by Digital Gadgets, LLC

MADE IN CHINA

Specifications:

- Dimension: 2.8" x 4.5" x 1"
- Weight: 0.1lbs (2.2oz) (62g)
- Materials: ABS, Electronic Components
- Interface: USB 2.0
- Wireless Tecs Technology: 2.4Ghz
- Number of Buttons: 3
- Output Volts/Current: DC 1.5V/10mA

Support

If you are having problems with your product, please contact customer support before contacting your retailer.

Digital Gadgets: 866-843-6460

Digital Gadgets Limited Warranty Statement

Digital Gadgets warrants this product against defects in workmanship and material for a period of 12 months from the original date of purchase. If the product fails during normal and proper use within the warranty period, Digital Gadgets will repair or replace any products or parts determined to be defective in workmanship or material at its option. All components repaired or replaced by Digital Gadgets' service will be under warranty for the remaining warranty period.

Safety Instructions:

Congratulations on your purchase of this Wireless Fabric Mouse. To get the most from your product, please take a few minutes to read these instructions.

- Always follow basic safety precautions

Care and maintenance instructions

While cleaning the product, you should first remove battery. Use only a dry soft cloth to wipe the product. Never allow water or any other liquids to get inside the product while cleaning. Remove battery if you are not using it for an extended period of time. Avoid using harsh cleansers or detergents.