







## Important safety instructions

- This equipment should be used in an environment where the ambient temperature is between 5 °C (41 °F) and 35 °C (95 °F).
- Do not expose the unit to rain or moisture and keep it away from liquids. In case of splashing water or other liquid on the device, switch off the device immediately and wait for it to be completely dry before turning it on again.
- Do not expose the device to direct sunlight
- Do not use strong solvents, liquid detergents, or other chemicals on or near the surface of the machine to prevent corrosion or damage to the surface of the machine.
- Do not expose the unit to a dusty environment.
- · Do not use the appliance during a gas leak.
- Do not expose the unit to strong magnetic or electric fields.
- You can route the device to airport X-ray detectors. However, it is recommended that you do not route your device through magnetic sensing gantries or expose it to portable detectors.
- · Do not place objects on the device.
- Do not place the device on an uneven or unstable surface.
   Be sure to protect the device from falling or other shock that may damage it.
- · Do not leave the device on or in charge on the knees or other body parts to avoid the risk of heat-related injury.

  Switch off the appliance before transporting it or covering it with a material that
- does not allow for optimal air circulation.
- · Do not use power cords, accessories, or other damaged devices with your We recommend the exclusive use of accessories (power supply, cables ...)
- supplied with the device. Use only original batteries. Replacing the battery with an incorrect battery may
- · Do not disassemble, modify, or repair the unit yourself, as this may void the
- warranty.
- Please save your important content regularly to avoid data loss.
   Our company rejects any resposability in the event of loss or deletion of items contained in the device due to improper use of the hardware or software, lack of maintenance or any other accidental event.

5



## WARNING

NOTICE RISK OF ELECTRIC SHOCK. DO NOT OPEN



CAUTION: TO AVOID THE RISK OF FIRE AND SHOCK ELECTRICAL, DO NOT REMOVE COVER OR HOOD BACK OF PRODUCT. IF THE UNIT MUST BE REPAIRED, ADDRESS EXCLUSIVELY QUALIFIED PERSONNEL.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of an uninsulated "dangerous test" inside the product, which is of sufficient magnitude to constitute a



In the documentation supplied with the device, the exclamation point within an equilateral triangle is intended to alert the user to the presence of important instructions regarding use and maintenance.



At full volume, prolonged listening to the portable audio device can damage the user's hearing.

## Legal notice and copyright notice

This product has been manufactured and sold under the responsibility of byybuo.

All other trademarks and logos are property of their respective owners.



## FCC ID:2AXUI-T10

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These

limits are designed to provide reasonable protection against harmful interfer-

ence in a residential installation. This equipment generates, uses and can

frequency energy and, if not installed and used in accordance with

instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the

encouraged to try to correct the interference by one or more of the following

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

WARRANTY CARD Model Name BYYBUO\_SmartPad\_T10 Product Serial No Date of purchase Customer's Details Name Address in full Telephone No. Dealer Name & Address Customer's signature & Date Dealer's signature with rubber stamp





Designed by BYYBUO, Assembled in PRO