


Bluetooth speaker

User Manual



Charging the battery:

1. Insert the charging cable into the micro USB input port, connect the USB plug into 5V USB terminal. The LED indicator will turn on.
2. After charging completed, the LED indicator will turn off.

Note: when music sound becomes smaller and you hear the warning tone "Di Di", please charge the speakers in time.

Bluetooth pairing for music & phone call:

1. Turn on both speakers, the speakers will have voice prompt and the indicator will flash, then double click one of them, they will pair with each other after 3 seconds (For the second time, both speakers will pair themselves automatically). When successfully paired, both speakers will have voice prompt, one speaker's indicator will flash and another one's will keep lightening.
2. Activate the Bluetooth of your devices and search for the pairing name "M3", and then click to pair the speakers with your devices. When succeeding in pairing, there will be voice prompt as well. When you re-connecting, the speakers will connect with your device automatically.

CAUTION:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTION:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

3. Open the music app in your Bluetooth devices to play music and the color LED indicators will keep flashing; one click the button to control play/pause/get through/hang up phone call.

4. Turn off the speakers by pressing the "⏻" for 2 seconds

Note: about the speaker's using environment.

1. Bluetooth connection and transmission may be affected by the surrounding environment like trees, metal and some other materials, for they can absorb or block the signal, so the distance of data transmission may be influenced as well.

2. Please make the speaker fully charged at first time using to make sure it will work well (When the speaker's power gets slower, the sound will be not as good as the sound in normal case.)

3. Please do not expose the speaker into the high temperature environment.

Specification:

Power Rating	3W
Frequency Response	20HZ-20KHZ
THD	<1%
S/N	>80DB
Speaker Parameter	4 Ω 3W diameter 36mm
Battery	3.7V/ 400mAh
Bluetooth Version	Bluetooth V4.2
Product Size	50x33mm
Product Weight	70g

in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.