

# 说明书尺寸: 910 x 85mm


MINISO

USER MANUAL

MODEL: E21016A

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY

Product Parts



Product Parameters

BT Version	V5.0	Frequency Range	20Hz-20KHz
BT Pairing Name	MINISO-E21016A	Sensitivity	105±3
Function	Media player, phone call	Charging Port	TYPE-C
Input	DC 5V	Transmission Distance	≤10M
Battery Capacity	200mAh	Charging Time	2.5h
Music Playback Time	8h	Talk Time	8h
Standby time	100h	Impedance	32Ω

Functions

Function	Instruction
Turn On	Press play button for 3 seconds, the light blinks red and blue
Turn Off	Press play button for 3 seconds, the light blinks red and blue
Pairing Mode	Open the Bluetooth of the equipment and search for the pairing name: MINISO-E21016A, the blue light blinks slowly and earphones enter pairing mode
Previous Track/ Volume -	Short press "Volume -" button to go to previous track, long press "Volume -" to lower volume, blue light blinks slowly

Next Track/ Volume +

Short press "Volume +" button to go to next track, long press "Volume +" to raise volume, blue light blinks slowly

Play

Press play button, blue light blinks slowly

Pause

Press play button, blue light blinks slowly

Answer Call

Press play button, blue light blinks slowly

Hang Up Call

Press play button, blue light blinks slowly

Cancel Call

Double press play button, blue light blinks slowly

Reject Call

Long press play button, blue light blinks slowly

AUX Port

You can listen to audio from external devices by plugging the audio cable

Cautions

1. Reasonable control of the volume and time of usage is required to avoid hearing damage.

2. For your safety, do not use it in potentially hazardous condition.

3. Do not listen to music, call up or answer the phone while driving to avoid danger caused by distraction.

4. Keep it out of reach of children to avoid danger caused by improper use.

5. Do not throw to avoid damage caused by dropping.

6. Do not store or use it under -20°C or above 45°C to avoid shortening the lifespan of earphones and battery.

7. Do not modify, disassemble or repair the product.

8. Irreplaceable battery, it should be disposed of according to local rules & regulations or be recycled by professional institute. Do not throw away or toss into fire.

9. When not in use for a long time, charge the earphones once every 3 months to extend its lifespan.

10. Avoid contact with water and other liquids to prevent them from penetrating into the product.

11. Do not throw into fire to avoid the danger of explosion.

Troubleshooting

1. Fail to pair the wireless earphones with your cellphone.

Solution: Check if the earphones are in pairing mode, and whether the phone BT function is on. Check the list on your phone, remove the earphones from the list, follow the instructions of user manual to pair the earphones with your phone again.

2. Cannot turn on the wireless earphones.

Solution: Check the battery to see if it is low.

3. Can the battery of the wireless earphones be replaced?

Answer: No. The lithium polymer battery in the earphones is irreplaceable.

4. The wireless earphones got disconnected with the phone within 10 meters.

Solution: BT is wireless so that it is very sensitive to objects between the earphones and the connected device. Check if there are any metal or other objects that may affect the connection within the effective distance.

5. Cannot hear audio playing when the earphones are connected to the computer or phone.

Solution: Check whether the computer's audio output is already connected to wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.

6. Can I operate the Apps of my phone through the earphones after connecting the wireless earphones to the phone?

Answer: Some apps may not support being operated through the earphones due to their settings.

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.