PRODUCT MANUAL

— Packaging items

- >Wireless headphone
- > Manual
- > Charging cable

Precautions

- > Store and use this product in a normal temperature environment;
- > Do not expose this product to rain or moisture;
- > Do not throw, to avoid damage caused by falling products;
- > Do not disassemble, repair and modify this product;
- > Do not use chemical solvents to wipe the product;
- > Do not arbitrarily discard or put in the fire, so as not to cause danger!

三、 Tips

In order to achieve the best sound quality headphones, please wear your headphones normally, do not disassemble the hardware yourself, use dry, soft cotton and so on. We recommend that you take the following precautions:

- 1, please listen to the appropriate volume of music, to prevent the adverse effects of hearing.
- 2, do not use the product in the exposed liquid, wet or moisture in the environment. 3, when the temperature exceeds the specified temperature range $0 ext{ } ext{$

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

四、Instructions

NO	Function	Headset state	Operation	Prompt	Indicator ligh
1	Power on	Power off	Press MFB button for 1 second	"Power on"	The blue ligh flashes after long time brig
2	Power off	Power on	Press MFB button for 3second	"Power off"	The red light stayed on fo about a secor
3	Successfully connected to mobile phone	Standby	1	"Connected"	Blue light flash about once ev 3 seconds
4	Disconnect from mobile phone	Connect the standby	I	"Disconnected"	/
5	Auto pairing	Power off	1	"Connected"	Blue light flash about once ev 3 seconds
6	Volume Adjustment	In a call/music	Long press the volume "V+"、"V-"	/	1
7	Last song	In the play	Press "V-"	1	1
8	Next song	In the play	Press "V+"	1	1
9	Music play/pause	In the play	Press MFB	1	Blue light flash about once ev 3 seconds
10	Income call	In call	1	dudududu	/
11	Answer call	In call	Press MFB	1	/
12	Reject call	In call	Long press the MFB for about 2 seconds	1	
13	Redial last number	Standty	Double press MFB	1	/
14	Hang up the phone	In call	Press MFB	1	/
15	SD card pattern	On state	Insert TF card	SD MODE	Blue lights fla
16	FM pattern	On state	Double press "V+"	FM MODE	Blue lights fla
17	FM auto search pattern	FM pattern	Double press MFB	1	Blue lights on