



User Manual

Wireless Mouse



E100

Product Function



A Left Button

B Right Button

C Scroll Wheel

D DPI Switch Button


E Low Battery Indicator Light

F Power Switch


G Battery Compartment

H Receiver Slot


USB Installation




1. Open the battery cover.



2. Install the battery and slide the power switch to "ON".



3. Take out the receiver.



4. Plug the USB receiver into the USB port of the computer.

Parameters

Specification:

Sensor: Optical
Mouse DPI: 800/1200/1600 dpi
Mouse Click Lifespan: 5000,000 times
Voltage: 1.5V
Connection Distance: 15m
Working voltage: 1.5V
Working current: 20mA
Polling Rate: 500Hz
Dimension: 109.86x60.53x32.54mm
Weight: 65.0g±5.0g
Battery: 1AA alkaline battery (not included)

System Requirement:

Windows 7, Windows 8, Windows 10 or later
Mac OS X 10.10 or later
Android 4.3 or later

Package List

► Wireless Mouse

► USB Receiver

► User Manual

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

06.11.01.1132
E100深圳市融创致远 说明书60x95mm展开240x95mm 80克书写纸 黑色单面印刷 风琴折