




PRODUCT MANUAL FOR WIRELESS KEYBOARD (MODEL : R703-0389)

IMPORTANT PRODUCT INFORMATION GUIDE

WHAT'S INSIDE

- Wireless Keyboard (Model: RZ03-0389)




- A. Function keys
- B. Macro keys
- C. Volume control keys

- D. Media keys
- E. On-the-fly macro record key
- F. Gaming mode key
- G. Backlight control keys
- H. Sleep mode key
- I. Charging/data port (USB Type C)
- J. Power indicator
- K. Mode switch (2.4 / OFF / BT)
- L. Wireless USB dongle compartment
- M. Kickstand

- 2.4GHz wireless USB dongle



- Type A to Type C cable



- Important Product Information Guide

WHAT'S NEEDED

PRODUCT REQUIREMENTS


- PC with a free USB Type A port or Bluetooth 4.0 connectivity

RAZER SYNAPSE REQUIREMENTS

- Windows® 7 64-bit (or higher)
- Internet connection for software installation

LET'S GET YOU COVERED

You've got a great device in your hands, complete with a 2-year limited warranty coverage. Now maximize its potential and score exclusive Razer benefits by registering at razerid.razer.com




Got a question? Ask the Razer Support Team at support.razer.com

GETTING STARTED

CHARGING YOUR WIRELESS KEYBOARD

Connect your keyboard to a powered USB port using the Type A to Type C cable to charge your keyboard. While charging, the power indicator will be in solid red; and then turn solid green when fully charged.



i For best results, fully charge your keyboard before using it for the first time. It takes approximately 2 hours to fully charge your keyboard. You may continue using the keyboard while plugged in.

When your keyboard is not charging, the power indicator will only briefly display its battery status.


Mode	Charged	Low	Critical*
2.4 / BT	Green	Yellow	Blinking Red
OFF	None		

*Critical status indicates that the keyboard's battery is less than 3%. This lighting sequence will repeat until the battery is drained or the keyboard is being charged.


CONNECTING YOUR WIRELESS KEYBOARD

2.4 GHZ HYPERSPEED MODE

- 1 Set the mode switch to 2.4.




- 2 Remove the wireless USB dongle from the dongle compartment and connect it to your computer.






BT MODE


- 1 Set the mode switch to BT.



- 2 To activate pairing mode, hold down the "FN" modifier key and press the "Windows" key. Your Wireless Keyboard can pair up to 5 devices using its profiles. You can cycle through each profile by pressing the "Windows" key and it will change color based on the current selected profile.

Profile	Designated color	
1	White	
2	Red	
3	Green	
4	Blue	
5	Cyan	

3. Enable Bluetooth on your device and select BlackWidow Mini Hyperspeed from the list of devices found. The device will pair with your keyboard and the connection will be registered on the active profile.



Searching for accessories...


Before pairing your Bluetooth devices,
make sure they're in pairing mode




Your keyboard will reconnect to the last paired device after it has been powered on again. To switch devices, simply press the keys that correspond to the device's profile number.

WIRED MODE

- 1 Set the mode switch to OFF.



- 2 Connect your Razer device to the USB port of your computer.














i Install Razer Synapse 3 when prompted or download the installer from razer.com/synapse.


USING YOUR BLACKWIDOW MINI HYPERSPEED

KEYBOARD FUNCTIONS

Pressing the “fn” modifier key plus keys with 2 functions will activate their secondary functions.

Function keys	Secondary function description
	The audio volume controls allow you to mute (), decrease () and increase () the audio output.
	The media keys allow you to play/pause () the current track, return to the previous track () or skip to the next track ().
	The LED control keys allow you to decrease () or increase () the brightness of your keyboard's LEDs.


ON-THE-FLY MACRO RECORDING



Follow these steps to create an OTF Macro Recording:


- 1 Press the key combination to start recording.
- 2 The OTF Macro record key will light up to show that the device is ready to record.
- 3 Type the keys you want to record.
- 4 Press the key combination to stop the recording or the ESC key to cancel recording. The OTF Macro record key will start blinking to show that the device has stopped recording and is ready to save.
- 5 Press the desired Macro key where you want to save your recording.

GAMING MODE



The Gaming Mode disables the Windows Key function to avoid accidental usage. You can also choose to disable the Alt + Tab and Alt + F4 functions by changing the Gaming Mode settings in Razer Synapse 3. The Game mode key will light up when Gaming Mode is active.

CHROMA EFFECTS



Holding down the "fn" modifier key, control key, and pressing any of the number keys will change the lighting on your keyboard. Listed below are the corresponding Chroma effect you will get for each number key.

Number key	Chroma Effect	Additional settings
1	Off	N/A
2	Static	Press the number key again to cycle through different colors
3	Breathing	Press the number key again to cycle through different colors
4	Spectrum cycling	N/A
5	Wave	Press the number key again to change direction
6	Reactive	Press the number key again to cycle through different colors
7	Starlight	Press the number key again to cycle through different colors

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Wireless Keyboard, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for support.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

COMFORT

Research has shown that long periods of repetitive motion, improper positioning of your computer peripherals, incorrect body position, and poor habits may be associated with physical discomfort and injury to nerves, tendons, and muscles. Below are some guidelines to avoid injury and ensure optimum comfort while using your Wireless Keyboard.

1. Position your keyboard and monitor directly in front of you with your mouse next to it. Place your elbows next to your side, not too far away and your keyboard within easy reach.
2. Adjust the height of your chair and table so that the keyboard and mouse are at or below elbow height.
3. Keep your feet well supported, posture straight and your shoulders relaxed.
4. During gameplay, relax your wrist and keep it straight. If you do the same tasks with your hands repeatedly, try not to bend, extend or twist your hands for long periods.
5. Do not rest your wrists on hard surfaces for long periods.
6. Use a wrist rest to support your wrist while gaming.
7. Customize the keys on your keyboard to suit your style of gaming in order to minimize repetitive or awkward motions while gaming.
8. Do not sit in the same position all day. Get up, step away from your desk and do exercises to stretch your arms, shoulders, neck and legs.

If you should experience any physical discomfort while using your keyboard, such as pain, numbness, or tingling in your hands, wrists, elbows, shoulders, neck or back, please consult a qualified medical doctor immediately.

MAINTENANCE AND USE

The Wireless Keyboard requires Mini Hyperspeed™ maintenance to keep it in optimum condition. Once a month we recommend you unplug the device from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2021 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, and "For Gamers. By Gamers.", are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Razer is under license.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Wireless Keyboard (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.



Li-ion

This equipment is for home use, and has acquired electromagnetic conformity registration, so it can be used not only in residential areas, but also other areas.

BATTERY INFO

Risk of fire or explosion or defeat the safeguard of equipment if the battery is replaced by an incorrect type. Replace only with the same or equivalent type. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. High or low extreme temperatures or low air pressure at high altitude that the battery can be subjected to during use, storage or transportation. Leaving the battery in an extremely high temperature and/or low air pressure surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.



EU PRODUCT AND BATTERY DISPOSAL INFORMATION

BATTERY WARNING

The Wireless Keyboard contains a Li-ion rechargeable battery. In general, the life expectancy of such batteries is dependent upon usage. If you suspect that the Li-ion rechargeable battery inside the Wireless Keyboard may be drained (has a low charge), try charging it. Caution: Do not open, mutilate, or expose to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause batteries to leak or explode, resulting in personal injury. Battery life varies with usage.



STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

ENGLISH

STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Razer (Europe) GmbH, declares that this Wireless keyboard: RZ03-0389, USB Dongle: DGRFG7) is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU & 2015/863/EU.

Wireless Keyboard

Radio Frequency: Bluetooth

Frequency Band: 2400MHz-2483.5MHz

RF Power: <10dBm

Radio Frequency: 2.4Ghz SRD

Frequency Band: 2400MHz-2483.5MHz

RF Power: <10dBm

Software/Firmware: V1.0

USB Dongle

Radio Frequency: 2.4Ghz SRD

Frequency Band: 2400MHz-2483.5MHz

RF Power: <9dBm

Software/Firmware: V1.0

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.