

r Wi-Fi Smart Plug	Indoor Wi-Fi Smart Plug		
	Step 4 The device is added, and the device nickname can also be changed in this interface.		
The state of the s			
and the second second	•		
and a second second	100		
	I		
Select your device type. In this case Socket (Wi-Fi)			
In this case Socket (WI-FI)			
Your device WiFi network will be the default network			
Your device WiFi network will be the default network displayed. Simply add your WiFi password or choose another network. After confirming our neassword bit confirm and your	USE THE AUTO SCAN FEA	TURE TO ADD A PRODUCT	
	USE THE AUTO SCAN FEA	TURE TO ADD A PRODUCT	
displayed. Simply add your WiFi password or choose another network. After confirming your password hit confirm and your	USE THE AUTO SCAN FEAT	TURE TO ADD A PRODUCT	
displayed. Simply add your WiFi password or choose another network. After confirming your password hit confirm and your	USE THE AUTO SCAN FEAT	TURE TO ADD A PRODUCT	
displayed. Simply add your WiFi password or choose another network. After confirming your password hit confirm and your	USE THE AUTO SCAN FEAT	TURE TO ADD A PRODUCT	
displayed. Simply add your WiFi password or choose another network. After confirming your password hit confirm and your	USE THE AUTO SCAN FEAT	TURE TO ADD A PRODUCT	
displayed. Simply add your WiFi password or choose another network. After confirming your password hit confirm and your	USE THE AUTO SCAN FEAT	TURE TO ADD A PRODUCT	
displayed. Simply add your WiFi password or choose another network. After confirming your password hit confirm and your	Choose the Auto Scan	The Auto Scan feature will scan your loc	
displayed. Simply add your WiFi password or choose another network. After confirming your password hit confirm and your		The Auto Scan feature will scan your loc network for searching devices. Ensure th is in scan mode (Step 2) and ensure you	
displayed. Simply add your WiFi password or choose another network. After confirming your password hit confirm and your	Choose the Auto Scan Feature from the add	The Auto Scan feature will scan your loc network for searching devices. Insure th	

Indoor	Wi-Fi	Smart	Plug

FUNCTIONS

1. Control you devices from anywhere using your phone with the Smart Plug. You can turn devices on/off, check status, create schedules and set timers using the Link2Home Pro App.

- 2. Add voice control to any plugged device by pairing with Amazon Alexa and Google Assistant.
- Manually turn your plug on or off using the switch. 4. Set up a Timer.
- a) On the individual device screen b) Tap the Timer button or Countdown button to set a timer/
- ountdown for the plug 5 Set up a Smart Setting
- Smart settings allow you to group devices together and set up various triggers such as time of day, location and be trigged by other devices

125V-60Hz 15A 1875W(Resistive) 1250W(Tungsten) Frequency: 2.4GHz (meets the requirements of IEEE802.11/b/g/n standard)



adaptor is used, it must be held in place by the metal screw.

outlet, have a proper outlet installed by a gualified electrician.

FOR GROUNDED, CORD-CONNECTED PLUG RATED LESS THAN 15A

The plug is for use on a nominal 125V circuit, and should be connected

temporary adaptor, which looks like the adaptor illustrated in sketch b,

sketch b if a properly grounded outlet is not available. The temporary

installed by a qualified electrician. The green colored rigid ear, lug, and

the like, extending from the adaptor must be connected to a permanent

adaptor should be used only until a properly grounded outlet can be

ground such as a properly grounded outlet box cover. Whenever the

may be used to connect this plug to a 2-pole receptacle as shown in

AND INTENDED FOR LISE ON A NOMINAL 125V SUPPLY CIRCUIT.

to a grounding outlet that looks like that illustrated in sketch a. A

Indoor Wi-Fi Smart Plug

GROUNDING INSTRUCTIONS

with all local codes and ordinances.

In the event of malfunction or breakdown, grounding provides a path of

least resistance for electric current to reduce the risk of electric shock. The plug must be connected to a cord having an equipment-grounding

appropriate outlet that is properly installed and grounded in accordance

conductor and a grounding plug. The plug must be plugged into an

NOTE: IN CANADA, THE USE OF A TEMPORARY ADAPTOR IS NOT PERMITTED BY THE CANADIAN ELECTRICAL CODE. Ensure that the timer is connected to an outlet having the same configuration as the

plua.

08 -

09 •

Indoor Wi-Fi Smart Plug

FCC CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate

the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that
- to which the receiver is connected -Consult the dealer or an experienced radio/TV technician for help. The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment

The equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

ISED WARNING: This device complies with Innovation, Science and Economic

Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présentappareilestconforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout Indoor Wi-Fi Smart Plug

brouillageradioélectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le fonctionnement

This Class B digital apparatus complies with Canadian ICES-003. Cetappareilnumérique de la classe B estconformeà lanorme NMB-003 du Canada.

Les communications effectuées au moyen de cetappareil ne sont pas nécessairement protégées des indiscrétions.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The equipment should be installed and operated with minimum distance 20cm between the radiator and vour body.

Déclarationd'exposition aux radiations:

Cetéquipementest conforme aux limites d'exposition aux rayonnements ISEDCanada établies pour unenvironnementnon contrôlé. Cetéquipementdoitêtreinstalléetutilisé avec un minimum de20cm de distance entre la source de rayonnement et votre corps.

MANUFACTURE

Ningbo EverFlourish Smart Technology Corp. Ltd. Address: 77 Wuxiang East Road, Yinzhou, Ningbo, 315111, P.R.China



Specifications

ADANGER: Improper connection of the equipment grounding conductor can result in a risk of electric shock. The conductor with insulation having an outer surface that is green with or without vellow stripes is the equipment grounding conductor. If repair or replacement of the cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal. Check with a gualified electrician or service person if the grounding instructions are not completely inderstood, or if in doubt as to whether the plug is properly grounded. Do not modify the plug connected to the plug - if it will not fit the

a) Tap Smart button on the first page to enter Smart scene page b) Tap "+" on the top right to enter setting page
c) You can set your personal routine scene control here