



TREADMILL FOR HOME
MANUAL BA04 V2.0

☎ Support Service: +1 888 625 5777
✉ Email: support@superuntreadmill.com
@ INS: superun_fitness
@ TIKTOK: superun_fitness

☎ Support Service: +1 888 625 5777
✉ Email: support@superuntreadmill.com





TABLE OF CONTENTS

▼

01.SPECIFICATION	01
02.SAFETY PRECAUTIONS	02
03.WARM-UP	03
04.PRODUCT AND ACCESSORIES	04
05.FUNCTION DIAGRAM	06
06.USING THE TREADMILL	08
07.FIRST USE GUIDANCE	10
08.MAINTENCE INSTRUCTION	12
09.FAQs AND SOLUTIONS	14

01. SPECIFICATION

▼ Welcome to use Help you enjoy exercising at home



Specification
Specifications: BA04
Product Size: 45.0"20.3"4.3inches
Product weight: 41.0LBS
Peak horsepower: 2.5HP

Running belt size: 35.5"15.5inches
Rated voltage: 120V
Maximum load: 300LBS
Maximum speed: 3.8MPH

02. SAFETY PRECAUTIONS

✓ Please read all instructions carefully before operating this product.

Basic precautions should always be followed when using the device, including the following safety instructions:

- Please do not use the machine when you are sick, tired or drunk.
- Please wear comfortable clothes and avoid flip-flops or skirts when using this machine.
- Please start from suitable sport as excessive exercise may affect health.
- Load capacity 300LB, overload may cause damage.
- Please ensure that all parts are not damaged and fixed before use. The device should be placed on a flat surface when used.
- Do not attempt any maintenance or adjustments other than those described in this manual.
- The device is for home use only. Do not use the device in a commercial, rental, or institutional environment.
- Only one person is allowed to use the device.
- Keep children and pets away from the device when using it.
- If you experience any chest pain, nausea, dizziness, or shortness of breath, stop exercising immediately and consult your doctor before continuing.

03. WARM-UP

✓ Sports suggestions and guidelines

Warning: Before beginning this or any exercise program, you should consult your physician. Warming up prepares the body for the exercise by increasing circulation, supplying more oxygen to the muscles and raising body temperature. Begin each workout with 5 to 10 minutes of stretching and light exercise to warm up. The photos on this page show several forms of basic stretching you may perform before your workouts. In order to achieve an adequate warm-up, perform each stretch three times.



1.Stretch down:
Bend your knees slightly with your body stretch down slowly, let your back and shoulders relax, and try to extend your hands to touch your toes. Hold for 10-15 seconds and take a break for a few seconds. Repeat 3 times.

2.Hamstring stretch:
Sit down on a light cushion, straighten one leg and place the other leg inward towards the thigh and wrap on the inside of the straightened leg. In that measure, try to touch the toes of your straightened leg with the hand at the same side. Hold for 10-15 seconds and take a break for a few seconds. Repeat 3 times for each leg.


3.Calf and Achilles Tendon Stretches:
Place both hands against the wall while standing with one foot behind the other, keeping your back leg straight and both heels planted on the ground while leaning against the wall. Hold for 10-15 seconds and take a break for a few seconds. Repeat 3 times for each leg.

4.Quadriceps Stretch:
Hold your body steady with your left hand holding against the wall and right hand reaching back to grab your right heel and pull it slowly towards your hip, until you feel the muscle tightness at the front side of your thigh. Hold for 10-15 seconds and take a break for a few seconds. Repeat several times for each leg.

5.Sartorius (muscle of inner thigh) Stretch:
Sit on the floor with your two feet holding against each other and your knees pointing to the opposite directions, grab your feet with your hands and pull them toward your groin. Hold for 10-15 seconds and take a break for a few seconds. Repeat 3 times.


04. PRODUCTS AND ACCESSORIES

▼ Product introduction



04. PRODUCTS AND ACCESSORIES

▼



05. FUNCTION DIAGRAM

▼ The function of the display panel is described




When the machine is running, the display window automatically switches every 5 seconds. The indicator light at the bottom of the full window changes with the display of the window. The information displayed in different Windows is as follows:

- (1). "Speed" window
The current speed value is displayed in the running state, and the speed is on. The display range is 0.0 to 3.8 mph.
- ▲ATTENTION: 0.0-3.8 MPH is the best walking speed, so our default value is 3.8 MPH
- (2). "Time" window
Display exercise time. The time range is 0:00-99:59 minutes.
- (3). "Distance" window
Display the moving distance, the display range is 0.00-99.99 miles.
- (4). "Calories window"
Display the calorie consumption value, the display range is 0.0-8888 kcal.

05. FUNCTION DIAGRAM

▼



- Remote control
- (1). Press the "Speed -" key to reduce the machine speed.
 - (2). Press "Speed +" to increase the speed of the machine.
 - (3). Press the "ON/OFF" button, and the machine will start or stop slowly.
- Remote control
- (1). Press the "-" key to reduce the machine speed.
 - (2). Press the "+" key to increase the machine speed.
 - (3). Press the "ON/OFF" button, and the machine will start or s
 - (4). "Mode" for the mode selective key. In the choice of various modes can use the speed increase and decrease key to set the relevant Countdown value, at the completion of the "ON/OFF" button to start the treadmill. While running, press the "Mode" button to pause the treadmill.

1. In the standby state, directly press the "ON/OFF" button, the treadmill would start to move at the speed of 0.0 miles/hy, other windows start counting up from 0, press "+" "-" button to change the speed.

Window value display range		
Setting Parameter	Initial Value	Display range
Time (minute: seconds)	0:00	0:00-99:59
Speed (mph)	0.0	0.0-3.8
Distance (mile)	0.00	0.00-99.99
Calories (kcal)	0.0	0.0-8888

06.USING THE TREADMILL



Note: System requirements:
ios12 or above / android 5.0
or above



After registration, click the treadmill icon in the upper right corner



01 Waiting for the treadmill to connect
02 Searching for WiFi



Display "Green" to complete the connection

Treadmill supports connection to mobile phone via Bluetooth

1.Download PitPat app on your phone and install it Search for "PitPat" in the app store or scan the following QR code to download and install the app.

2. Configure PitPat app account Open PitPat app and follow the app instructions to log in or register account information.

3. Connect the treadmill

(1) Turn on the Bluetooth function of the mobile phone (the android mobile phone also needs to turn on the positioning function);

(2) Open the PitPat app (if the app prompts for authorization, please grant the app related permissions);

(3) Enter the app home page, click the treadmill icon in the upper left corner of the home page to enter the search interface

your phone will automatically search for nearby devices. Tap your treadmill (devices starting with PitPat-T are your treadmill); to connect.

After the treadmill makes a beep, the connection is successful, and the Bluetooth icon on the treadmill panel lights up.

NOTE: Please make sure your phone is connected to the Internet when connecting the treadmill via Bluetooth.

Please refer to the APP Description for detailed networking configuration.

06.USING THE TREADMILL



Note: If the treadmill is not connected to the mobile app, the Bluetooth icon of the treadmill is off; if the treadmill is successfully connected to the mobile app, the Bluetooth icon of the treadmill is on.

Treadmill WiFi network configuration

After the treadmill is successfully connected to the mobile app, it will enter the treadmill WiFi configuration interface.

NOTE: The treadmill only supports 2.4GHz WiFi (the app also only displays the 2.4GHz WiFi signal that the treadmill can search for), please make sure that your network device can provide 2.4GHz WiFi signal.

(1) Find the network you need to connect to.

(2) Enter your WiFi password according to the prompt. After the treadmill successfully connects to the network, the WiFi icon on the treadmill panel lights up and the app will return to the home page.

NOTE: If the WiFi connection fails, after the WiFi returns to normal, please restart the treadmill so that it can reconnect to the internet.

07. FIRST USE GUIDANCE

1. First, adjust the foot pads, and place them on flat ground and make sure there is a space of 50cm in front and rear.

2. Connect the power supply, turn on the switch.

07. FIRST USE GUIDANCE

3. First check and install the battery, press the "ON/OFF" button, there would be 3 seconds delay displayed on the panel before operating.

4. Start using a walking treadmill.

08. MAINTENANCE INSTRUCTION

▼ Lubricant

- 1.The treadmill is lubricated before it leaves the plant, but frequent inspection of the lubrication status of the treadmill helps keep the treadmill in its best condition. The treadmill must be lubricated after one year of use or 100 hours of operation.
- 2.After using for 30 hours or 30 days, whichever comes first, while the treadmill is stationary, lift the running belt from one side and reach out to the surface underneath the running belt to decide the lubrication status. You do not need to add more lubricant if you can touch the lubricant. But if it's dried up, follow the instructions below to refill the lubricant. (Please only use non-petroleum based lubricant)
- 3 Follow the figure below to properly add the lubricant. Open the refilling cover on the right front side of the side bar, use scissors or a utility knife to cut the lubricant bottle at the portion shown in the figure below, and add the lubricant according to the figure at the bottom. Insert the thin rod at the front end of the lubricant bottle into the filling port on the running board and fill in the lubricant.



08. MAINTENANCE INSTRUCTION

▼



1. When running belt leans to the left, adjusting screw on the left 1-2 turns clockwise. Then, test running. If the running belt still leans to the left, repeat the above steps until the running belt is aligned.



2. When running belt leans to the right, adjusting screw on the right 1-2 turns clockwise. Then, test running. If the running belt still leans to the right, repeat the above steps until the running belt is aligned.



3. When the running belt gets too tight it will cause stronger vibrations. Please adjust both sides screws 1-2 turns counterclockwise, loosen the belt until stopping skidding or pausing. When the running belt too loose, please adjust both sides screws 1-2 turns along the clockwise.

09. FAQs AND SOLUTIONS

▼

Er1: Indicates that the communication between the electronic watch and the electronic control is abnormal		
Er1 problem solution	The communication line of the electronic watch is not connected properly, broken, poor contact.	Please reconnect the communication line
	Electronic watch has no signal output.	Replace the electronic watch, pending repair
	No signal output under control	Replace the lower control, pending maintenance
Er2: Indicates that the down-control motor overvoltage protection information prompts		
Er2 problem solution	The load of the walking machine exceeds the rated working voltage of the motor.	It is recommended to use it within the rated operating voltage range of the motor.
	The motor of the walking machine is abnormal/the speed is too fast due to the failure of the light sensor.	Replace motor/replace photoelectric sensor.
	The overvoltage detection circuit of the lower control board fails.	Replace the lower control, pending repair.
Er4: Indicates that the down-control motor over-current protection information prompt		
Er4 problem solution	The load of the walking machine exceeds the rated operating current of the motor.	It is recommended to be within the rated operating current range of the motor.
	There is a problem with the assembly structure of the walking machine and the motor, which causes motor resistance or blockage.	Check whether the structure of the walking machine is normal.
	The lower control current limiting system is faulty.	Replace the lower control, pending repair.

09. FAQs AND SOLUTIONS

▼

Er5: Indicates that the lower control detects the abnormal phenomenon of motor overload		
Er5 problem solution	The current is too high for a sustained period.	Please check whether the power supply line is normal.
	The detection circuit of the lower control board fails.	Replace the lower control, pending repair
Er6: Indicates that the lower control detects the abnormal phenomenon of speed		
Er6 problem solution	The motor wire is not connected properly.	Please reconnect the motor cable.
	The detection circuit of the lower control board fails or the motor is damaged.	Replace lower control or motor, pending maintenance
Er7: Controller does not receive signal		
Er7 problem solution	The communication line of the electronic watch is not connected properly, broken, and poor contact.	Please reconnect the communication cable.
	The detection circuit of the lower control board fails.	Replace the lower control, pending maintenance.

09. FAQs AND SOLUTIONS

▼ Electric meter fault judgment and solution

S/N	So block code	Old obstacle	Fault diagnosis	solution
1	E83	Motor overvoltage protection	1. The user's power grid voltage is unstable, and the peak voltage is very high; 2. Wheel diameter setting error; 3. The controller is damaged.	1. Need to increase the external filter regulator; 2. Reset the wheel diameter value to try not to exceed the rated voltage of the motor; 3. Replace the controller.
2	E85	Overcurrent protection	1. Heavy load; 2. The motor or roller has a foreign body stack; 3. The roller is not lubricated enough, and the resistance increases; 4. The controller is damaged; 5. Motor damage resistance increases;	1. Reduce the load, try not to exceed the rated load; 2. Remove stack foreign bodies; 3. Add lubricant; 4. Replace the controller; 5. Replace the motor;
3	E82	Main motor open circuit	1. The main motor line is not connected or loose; 2. Main motor open circuit, damaged; 3. The controller is open and damaged.	1. Re-reinforce the main motor connection wire; 2. Replace the motor; 3. Replace the controller.

09. FAQs AND SOLUTIONS

▼

S/N	So block code	Old obstacle	Fault diagnosis	solution
4	E86	Communication error	1. The main cable connector of the upper and lower controller is loose; 2. The main cable of the upper and lower controller is broken; 3. The electronic watch is broken; 4. The controller is damaged.	1. Harden the cable port; 2. Replace the main cable of the upper and lower controller; 3. Replace the electronic watch; 4. Replace the controller.
5	E8C	Power tube breakdown Explosion protection	1. Power transistor breakdown, controller damage.	1. Replace the controller.

TABLA DE CONTENIDOS (ES)

▼	
01. ESPECIFICACIONES	18
02.PRECAUCIONES DE SEGURIDAD	19
03.CALENTAMIENTO	20
04.PRODUCTOS Y ACCESORIOS	21
05.DIAGRAMA DE FUNCIONES	23
06.USO DE CINTAS DE CORRER	25
07.GUÍA DE PRIMER USO	27
08.Instrucciones de procesamiento	29
09.PREGUNTAS FRECUENTES Y SOLUCIONES	31

01. ESPECIFICACIONES

▼ Bienvenido al uso ayudándole a disfrutar del ejercicio en casa



Specification

Especificaciones: BA04
Tamaño expandido: 45.0"20.3"4.3inches
Peso neto del producto: 41.8LBS
Caballos de fuerza máximos: 2.5HP

Tamaño de la correa de rodadura: 35.5"15.5inches
Tensión nominal: 120V
Capacidad máxima: 300LBS
Velocidad máxima: 3.8MPH

02. PRECAUCIONES DE SEGURIDAD

✓ Lea atentamente todas las instrucciones antes de utilizar este producto.

- Siempre se deben seguir las precauciones básicas al usar el dispositivo, incluyendo las siguientes instrucciones de seguridad:
- Por favor, no utilice la máquina cuando esté enfermo, cansado o borracho.
 - Por favor, use ropa cómoda y evite las charcas o baldas cuando use esta máquina.
 - Por favor, comience con un deporte antes usado, ya que el ejercicio nuevo puede afectar la salud.
 - Capacidad de carga 300LBS, la sobrecarga puede causar daños.
 - Verifique de que todas las piezas no estén dañadas y reparadas antes de su uso. El dispositivo debe colocarse sobre una superficie plana cuando se usa.
 - No intente ningún mantenimiento o ajuste que no sea el descrito en este manual.
 - El dispositivo es solo para uso doméstico. No utilice el dispositivo en un entorno comercial, de alquiler o institucional.
 - Solo una persona puede usar el dispositivo.
 - Mantenga a los niños y mascotas alejados del dispositivo cuando lo use.
 - Si experimenta dolor en el pecho, náuseas, mareos o dificultad para respirar, deje de hacer ejercicio de inmediato y consulte a su médico antes de continuar.

03. CALENTAMIENTO

✓ Sugerencias y directrices deportivas

Orientación para el ejercicio

ADVERTENCIA Antes de comenzar este o cualquier programa de ejercicios, debe consultar a su médico. El calentamiento prepara el cuerpo para el ejercicio aumentando la circulación, suministrando más oxígeno a los músculos y elevando la temperatura corporal. Comience cada entrenamiento con 5 a 10 minutos de estiramiento y ejercicio ligero para calentar. Las fotos en esta página muestran varias formas de estiramiento básico que puede realizar antes de sus entrenamientos. Para lograr un calentamiento adecuado, realice cada estiramiento tres veces.



1. Espinar hacia abajo:
Bend your torso slightly with your body stretch down slowly, let your back and shoulders relax, and try to extend your hands to touch your toes. Hold for 10-15 seconds and take a break for a few seconds. Repeat 3 times.

2. Estiramiento de las cuádruplas:
Sit down on a clean surface, straighten one leg and place the other leg inward towards the thigh, and drag on the inside of the straightened leg. In the meantime, try to touch the toes of your straightened leg with the hand at the same side. Hold for 10-15 seconds and take a break for a few seconds. Repeat 3 times for each leg.


3. Estiramientos de la pantorrilla y del tendón de Aquiles:
Place both hands against the wall while standing with one foot behind the other, keeping your back leg straight and both heels planted on the ground while leaning against the wall. Hold for 10-15 seconds and take a break for a few seconds. Repeat 3 times for each leg.

4. Estiramiento de cuadríceps:
Hold your body steady with your left hand holding against the wall and right hand reaching back to grab your right heel and pull it slowly towards your hip, until you feel the muscle tightness at the front side of your thigh. Hold for 10-15 seconds and take a break for a few seconds. Repeat several times for each leg.

5. Estiramiento del sartorio (músculo de la cara interna del muslo):
Sit on the floor with your two feet holding against each other and your knees pointing to the opposite directions, grab your feet with your hands and pull them toward your groin. Hold for 10-15 seconds and take a break for a few seconds. Repeat 3 times.


04. PRODUCTOS Y ACCESORIOS

▼ Introducción del producto



04. PRODUCTOS Y ACCESORIOS

▼



05. DIAGRAMA DE FUNCIONES

Se describe la función del panel de visualización



Cuando la máquina está funcionando, la ventana de visualización cambia automáticamente cada 5 segundos. La luz indicadora en la parte inferior de la ventana también cambia con la visualización de la ventana.

La información que se muestra en diferentes Windows es el siguiente:

(1). Ventana "Velocidad"
El valor de velocidad actual se muestra en el estado de ejecución y la velocidad está actualizada. El rango de visualización es de 0.0-3.0 MPH.


ATENCIÓN: 0.0-3.0 MPH es la mejor velocidad de caminata, por lo que nuestro valor predeterminado es 3.0 MPH.

(2). Ventana "Tiempo"
Muestra el tiempo de ejercicio. El rango de tiempo es de 0:00-99:59 minutos.

(3). Ventana "Distancia"
Muestra la distancia recorrida, el rango de visualización es de 0.00 a 99.99 millas.

(4). "Ventana de calorías"
Muestra el valor de consumo de calorías, el rango de visualización es de 0.0-9999 kcal.

05. DIAGRAMA DE FUNCIONES



Control remoto

(1). Pulse la tecla "Velocidad -" para reducir la velocidad de la máquina.
(2). Presione "Velocidad +" para aumentar la velocidad de la máquina.
(3). Presione el botón "ON/OFF" y la máquina comenzará a ser detenida lentamente.

Control remoto

(1). Presione el botón "+" para reducir la velocidad de la máquina.
(2). Presione el botón "+" para aumentar la velocidad de la máquina.
(3). Presione el botón "on / off" y la máquina comenzará.
(4),(5) "modo" es la tecla de selección del modo; al seleccionar varios modos se puede utilizar las teclas de aumento y disminución de velocidad para establecer la cantidad actual relacionada valor, se puede activar la cinta de correr estableciendo el botón "on / off" al correr, Presione el botón "modo" para suspender la cinta de correr.

6. En el estado de espera, presione directamente el botón "ENCENDIDO/PAUSA", y la cinta de correr comenzará a moverse a una velocidad de 3.0 millas/hora, otras ventanas comienzan a contar desde 0, presione "+", "-" botón para cambiar la velocidad.

Rango de visualización del valor de la ventana

Setting Parameter	Initial Value	Display range
Time (minutes: seconds)	0:00	0:00-99:59
Speed (mph)	0.0	0.0-3.0
Distance (miles)	0.00	0.00-99.99
Calories (kcal)	0.0	0.0-9999

06. USO DE LA CINTA DE CORRER



Nota: Requiere del sistema Android 5.0 o superior



Después de registrarse, haga clic en el icono de la cinta de correr en la máquina superior derecha



B1: Esperando la conexión de la cinta de correr
B2: Buscar wifi



Mostrar "verde" para completar la conexión

La cinta de correr admite la conexión al teléfono móvil a través de Bluetooth

1. Descargue la aplicación FitPac en su teléfono e instálela. Busque "FitPac" en la tienda de aplicaciones o escanee el siguiente código QR para descargar e instalar la aplicación.

2. Configure la cuenta de la aplicación FitPac. Abra la aplicación FitPac y siga las instrucciones de la aplicación para iniciar sesión o registrar la información de la cuenta.

3. Conectar la cinta de correr:

- (1) Encienda la función Bluetooth del teléfono móvil (el teléfono móvil también tendrá que encender la función de posicionamiento).
- (2) Abra la aplicación FitPac (si la aplicación solicita autorización, conceda los permisos relacionados con la aplicación).
- (3) Ingrese a la página de inicio de la aplicación, haga clic en el icono de la cinta de correr en la esquina superior izquierda de la página de inicio para ingresar a la interfaz de búsqueda, su teléfono buscará automáticamente los dispositivos cercanos.
- Taquí su cinta de correr (los dispositivos que comienzan con FitPac) que sus cintas de correr) para conectarse.
- Después de que la máquina para correr emita un pitido, la conexión se establece y el icono de Bluetooth en el panel de la máquina para correr se enciende.

Nota: asegúrese de que su teléfono está conectado a Internet cuando conecte la cinta de correr a través de Bluetooth.

Consulte la descripción de la aplicación para la configuración detallada de la red.

06. USO DE LA CINTA DE CORRER



Nota: Si la caminadora no está conectada a la aplicación móvil, el icono de Bluetooth de la caminadora está apagado; si la cinta de correr se conecta con éxito a la aplicación móvil, el icono de Bluetooth de la cinta de correr está encendido.

Configuración de la red WiFi de la cinta de correr
Después de que la cinta de correr se haya conectado con éxito a la aplicación móvil, ingresará a la interfaz de configuración WiFi de la cinta de correr.

Nota: La cinta de correr solo admite WiFi de 2.4 GHz (la aplicación también solo muestra la señal de WiFi de 2.4 GHz que la cinta de correr puede buscar), asegúrese de que su dispositivo de red pueda proporcionar una señal de WiFi de 2.4 GHz.

- (1) Encuentra la red a la que necesitas conectarte.
- (2) Ingrese su contraseña WiFi de acuerdo con el aviso. Después de que la máquina para correr se conecte con éxito a la red, el icono WiFi en el panel de la máquina para correr se ilumina y la aplicación volverá a la página de inicio.

Nota: Si la conexión WiFi falla, después de que WiFi vuelva a la normalidad, reinicie la máquina para correr para que pueda volver a conectarse a Internet.

07. UGUÍA DE PRIMER USO



1. Primero, ajuste las almohadillas de los pies y colóquelas en plano horizontal y asegurese de que haya un espacio de 50 cm en delantera y trasera.




2. Conecte la fuente de alimentación, encienda el interruptor.

07. GUÍA DE PRIMER USO



3. Primero verifique e instale la batería, presione el botón "ON / OFF", la máquina ingresa a la cuenta regresiva de 3 segundos.



4. Comienza a usar un trenzón para caminar

08.INSTRUCCIONES DE MANTENIMIENTO

▼ Aceite lubricante

1. La cinta de correr se lubrica antes de salir del armazón de fabricación, pero la lubricación de la cinta de correr necesita ser inspeccionada frecuentemente para mantener la cinta en su mejor estado. La cinta de correr debe ser lubricada después de un año de uso o 100 horas de funcionamiento.

2. Después de 30 horas o 30 días de uso, lo que ocurra primero, la cinta de correr está entardecada, usted puede tirar de la cinta de correr hacia un lado y alcanzar la superficie debajo de la cinta de correr para comprobar el nivel de lubricación. Si se detecta aceite lubricante, no es necesario añadir más lubricación. Si está seco, siga las instrucciones siguientes para rellenar el aceite lubricante. (Por favor, utilice sólo aceite lubricante que no esté hecho de petróleo, ya que puede causar daño).

3. Para añadir correctamente el aceite lubricante, actúe como se muestra en la figura de abajo, abra la tapa decorativa de combustible en la parte delantera izquierda de la banda lateral, utilice tijeras o una navaja para cortar la bolsa de aceite lubricante según el tamaño mostrado en la figura de abajo, y luego añada aceite según la figura de abajo. Inserte la varilla fina de la botella de aceite lubricante en el tubo de llenado de la plataforma y, a continuación, rellene el aceite para que se aplique correctamente.



08. INSTRUCCIONES DE MANTENIMIENTO

▼



1. Al correr la correa se inclina hacia la izquierda, ajustando el tornillo a la izquierda 1-2 giro en el sentido de las agujas del reloj. Luego, pruebe la ajusteación. Si todavía se inclina hacia la izquierda, repita los pasos anteriores hasta volver al centro.

2. Al correr la correa se inclina hacia la derecha, ajustando el tornillo a la derecha 1-2 vueltas en el sentido de las agujas del reloj. Luego, pruebe la ajusteación. Si aún se inclina hacia el a la derecha, repita los pasos anteriores hasta volver al centro.

3. Cuando la correa de correr está demasiado apretada, causand una resistencia más fuerte. Ajuste los tornillos de ambos lados 1-2 vueltas a la largo del sentido contrario a las agujas del reloj, afloje la correa hasta que deje de derrapar o hacer una pausa. Cuando el Correo de rodadura demasiado suelta, ajuste los tornillos de ambos lados 1-2 vueltas en el sentido de las agujas del reloj.

09. PREGUNTAS FRECUENTES Y SOLUCIONES

▼

Er1: Indica que la comunicación entre el reloj electrónico y el control electrónico es anormal		
Solución del problema Er1	La línea de comunicación del reloj electrónico no está bien conectada, rota, mal contacto.	Vuelva a conectar la línea de comunicación.
	El reloj electrónico no tiene salida de señal.	Reemplazar el reloj electrónico, pendiente de reparación.
	No hay salida de señal bajo control.	Reemplaza el control inferior, pendiente de mantenimiento.

Er2: Indica que la información de protección contra sobrevoltaje del motor de control descendente solicita		
Solución del problema Er2	La carga de la máquina para caminar excede el voltaje nominal de trabajo del motor.	Se recomienda utilizarlo dentro del rango de tensión nominal de funcionamiento del motor.
	El motor de la máquina para caminar es anormal, la velocidad es demasiado rápida debido a la falta del sensor de luz.	Reemplazar el reloj electrónico, pendiente de reparación.
	El circuito de detección de sobrevoltaje del sistema de control inferior falla.	Reemplaza el control inferior, pendiente de mantenimiento.

Er4: Indica que el indicador de información de protección contra sobrecorriente del motor de control descendente		
Solución del problema Er4	La carga de la máquina para caminar excede la corriente operativa nominal del motor.	Se recomienda estar dentro del rango de corriente operativa nominal del motor.
	Hay un problema con la estructura de ensamblaje del anclador y el motor, lo que provoca resistencia u obstrucción del motor.	Compruebe si la estructura de la máquina para caminar es normal.
	El sistema limitador de corriente de control inferior está defectuoso.	Reemplaza el control inferior, pendiente de reparación.

09. PREGUNTAS FRECUENTES Y SOLUCIONES

▼

Er3: Indica que el control inferior detecta el fenómeno anormal de sobrecarga del motor		
Solución del problema Er3	La corriente es demasiado alta para un período prolongado.	Compruebe si la línea de suministro de energía es normal.
	El circuito de detección del tablero de control inferior falla.	Reemplaza el control inferior, pendiente de reparación.

Er5: Indica que el control inferior detecta el fenómeno anormal de la velocidad		
Solución del problema Er5	El cable del motor no está conectado correctamente.	Vuelva a conectar el cable del motor.
	El circuito de detección del tablero de control inferior falla o el motor está dañado.	Reemplazar control inferior o motor, mantenimiento pendiente

Er7:El controlador no recibe señal		
Solución del problema Er7	La línea de comunicación del reloj electrónico no está conectada correctamente, rota y con mal contacto.	Vuelva a conectar el cable de comunicación.
	El circuito de detección del tablero de control inferior falla.	Reemplaza el control inferior, pendiente de mantenimiento.

09. PREGUNTAS FRECUENTES Y SOLUCIONES

v Juicio y solución del fallo del medidor de correr eléctrico

S/N	Código de identificación	Los discapacitados	Juicio de fallas	solución
1	EEB	Protección contra sobretensión del motor	1. El voltaje de la red del usuario es inestable y el voltaje de pico es muy alto; 2. El valor del diámetro de la rueda se establece incorrectamente; 3. El controlador está dañado;	1. Es necesario agregar un regulador de flujo externo; 2. Intento restablecer el valor del diámetro de la rueda para no exceder el voltaje clasificado del motor; 3. Cambie el controlador;
2	EEB	Protección contra sobrecorriente	1. Carga excesiva; 2. El motor o los rodillos están ensucados con objetos extraños; 3. Los rodillos no están suficientemente lubricados y la resistencia aumenta; 4. El controlador está dañado; 5. Mayor resistencia al daño del motor;	1. Alivie la carga, intente no exceder la carga clasificada; 2. Limpie los cuerpos extraños atascados; 3. Aumente el lubricante; 4. Reemplace el controlador; 5. Cambie el motor;
3	EEG	Circuito abierto del motor principal	1. El cable del motor principal no está conectado o suelto; 2. Circuito abierto del motor principal, dañado; 3. Circuito abierto del controlador, dañado;	1. Reforce el cable de conexión del motor principal; 2. Cambie el motor; 3. Cambie el controlador;

09. PREGUNTAS FRECUENTES Y SOLUCIONES

v

S/N	Código de identificación	Los discapacitados	Juicio de fallas	solución
4	EEB	Error de comunicación	1. La interfaz de línea de conexión principal de control superior y inferior está suelta; 2. La línea de conexión principal de control superior y inferior es mala; 3. El reloj electrónico es nuevo; 4. El controlador está dañado;	1. Refuerza el interfaz del cable de conexión; 2. Reemplazar el cable de conexión principal de control superior y inferior; 3. Reemplazo del reloj electrónico; 4. Reemplazo del controlador;
5	EEC	Fugitiva del tubo del poder. Protección contra explosiones	1. El canal eléctrico del poder está roto y el controlador está dañado;	1. Cambie el controlador;

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.