

<div>US UK</div> <div>Dear user</div> <div>Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.</div> <div><div>1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.</div><div>2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.</div></div>	<div>OS support</div> <div>Windows XP/Vista/Win7/Win8/Win10/Mac OS</div> <div>How to connect the keyboard with a computer</div> <div>Wired Connection</div> <div><div>1. Slide the 2.4G/OFF/BT switch on bottom of the keyboard to OFF.</div><div>2. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer.</div><div>3. The computer will recognize and configure the keyboard automatically.</div><div>4. The keyboard will be ready for use when the configuration is finished.</div><div>5. Once the keyboard is powered up, charging begins. The LED marked with M lights on red. It will turn to white when keyboard is fully recharged</div></div> <div>2.4G Wireless Connection</div> <div><div>1. Slide the 2.4G/OFF/BT switch on bottom of keyboard to 2.4G.</div><div>2. Take out the nano USB receiver and plug it into an available USB port on your computer. The computer will recognize and configure the keyboard automatically.</div><div>3. The keyboard will be ready for use when the configuration is finished.</div><div>4. In some cases, you may need to pair the keyboard. Turn on the keyboard and press [FN]+[4] for about 3 seconds, the LED marked with M flashes quickly in green, plug the USB receiver into any available USB port on your computer within 20 seconds. The keyboard will be paired automatically. Make sure the keyboard has enough power before doing so.</div><div>5. The indicator will flash when the battery is low. Please recharge the keyboard in time or it will turn off automatically soon.</div></div> <div>Bluetooth Connection</div> <div><div>1. Slide the 2.4G/OFF/BT switch on bottom of keyboard to BT.</div><div>2. Press [FN]+[1](or [2]/[3] for other Bluetooth devices), the LED marked with M flashes in blue (or cyan/magenta for the others)</div><div>3. Turn on Bluetooth and scan for available devices on your computer or smart phone. It</div></div>	<div>will find "BT3.0Keyboard or BT5.0 KB" device. Select one of them to get connected with it automatically.</div> <div>Function Introduction</div> <div><div>1. With standard USB and 2.4G/BT connections, the keyboard can be used on computers without any software or driver installation.</div><div>2. There are 20 backlight effects.</div><div>3. Commands of key combinations with [FN] key</div><div>[FN]+[Ins]: Change backlight mode. There are 20 backlight effects.</div><div>[FN]+[Del]: Change back light color.</div><div>[FN] + [PrtSc]: Turn On or Off the backlight.</div><div>[FN] + [+/-]: Slow down the running speed of backlight .</div><div>[FN] + [+&gt;]: Add up the running speed of backlight.</div><div>[FN] + [↑]: Increase the backlight brightness of the keyboard.</div><div>[FN] + [↓]: Decrease the backlight brightness of the keyboard.</div><div>[FN]+[TAB]: Turn the backlight to white.</div><div>[FN] + [Win]: Disable or enable the [Win] key.</div><div>[FN] + [1]: Select Bluetooth device one (for Bluetooth connection).</div><div>[FN] + [2]: Select Bluetooth device two (for Bluetooth connection).</div><div>[FN] + [3]: Select Bluetooth device three (for Bluetooth connection).</div><div>[FN] + [4]: Change to 2.4G wireless connection. Press and hold the [FN]+[4] for 3 seconds to pair the keyboard with its receiver.</div><div>[FN] + [ESC]: Set the keyboard to default setting.</div><div>4. Multimedia keys ([FN]+[F1]~[F12])</div><div>FN+[F1] My computer</div><div>FN+[F2] Home</div><div>FN+[F3] Calculator</div><div>FN+[F4] Multi-media player</div><div>FN+[F5] Previous track</div><div>FN+[F6] Next track</div><div>FN+[F7] Play /Pause</div><div>FN+[F8] Stop</div></div>
---	--	--

<div>FN+[F9] Mute</div> <div>FN+[F10] Volume down</div> <div>FN+[F11] Volume up</div> <div>FN+[F12] E-mail</div> <div>How to recharge the keyboard</div> <div>Find the USB A to USB type C cable in the packaging ,plug the keyboard and connect it with computer for charging, the LED indicator(M) of keyboard will be turn to red.</div> <div>Remark: The LED indicator (M) will turn to red when keyboard is out of battery.</div> <div><div><div></div></div>Warning: Charging Input: 5V ---1A</div> <div>FAQ</div> <div><div>1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly I inserted into the corresponding USB port on the computer, or try another USB port on the computer.</div><div>2. If you spill liquid on the keyboard, please remove keyboards USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.</div></div> <div><div><div></div></div></div>	<div>FCC Statement</div> <div>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div> <div>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div> <div><div>-- Reorient or relocate the receiving antenna.</div><div>-- Increase the separation between the equipment and receiver.</div><div>-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</div><div>-- Consult the dealer or an experienced radio/TV technician for help</div></div> <div>This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div> <div>California Proposition 65</div> <div><div><div></div></div>WARNING: Risk of Cancer from [Name of one or more chemicals known to cause cancer] And Reproductive Harm From [Name of one or more chemicals known to cause reproductive toxicity] Exposure - <a href="http://www.P65Warnings.ca.gov">www.P65Warnings.ca.gov</a></div>	<div><div></div></div> <div>REDRAGON</div> <div>APS PRO</div> <div>MECHANICAL GAMING KEYBOARD</div> <div><div><div></div></div></div> <div>Please scan here to download user manual</div> <div>Mechanical Gaming Keyboard</div> <div>Operating Instructions</div>
---	--	---

型号	红龙K607P=KBS/8499		备注：尺寸：100x100mm (风琴折页) 材质：80g书写纸 印刷：单黑色双面印刷				
名称	说明书						
日期	2022-2-17(修改)						
页码	1 OF 1		文件编号				
绘图	雷国建	审核		核准		版本	

