

2、 模式选择:短按SET旋钮选择CCT模式/FX特效模式

2.1 CCT模式。

 \bigcirc

个电池同时使用)

1、 开关机

	ССТ
2800K	100%
色温	亮度

操作说明

使用电池供电时,开关往" I"按下开机,往中间复位关机。

使用适配器供电时,开关往"II"按下开机,往中间复位关机。

2.1.1色温调节:旋转SET旋钮调节色温,最小变量100K,调节范围2800-7000K。 2.1.2 亮度调节:旋转DIM旋钮,最小变量1%,调节范围0-100%。 2.2、情景特效模式



2.2.1 转动SET旋钮选择灯光特效,短按DIM选择A、B、C档位,转动DIM旋钮调整亮度。

2.2.2 亮度调节:旋转DIM旋钮,最小变量1%,调节范围0-100%。

2.2.3 情景特效模式有12类,用户可以根据需求选择:

序号	显示	场景	显示A	显示B	显示C
1	4	闪电	间歇	频繁	持续
2	¢ر	闪光灯	闪光	发布会	狗仔队
3	.	故障灯	间歇	频繁	持续
4	Ð	电视荧幕	慢速	中速	快速
5	1	蜡烛	间歇	频繁	持续
6	\$	火焰	柴火	篝火	火灾
7	·†_	烟花	短暂	连续	演出
8	4 33	爆炸	间歇	频繁	持续
9	ЯĽ,	色温循环	慢速	中速	快速
10	s∰a a	脉冲	慢速	中速	快速
11	ŝ	电焊	间歇	频繁	持续
12	SDS	SOS	慢速	中速	快速

3、连接手机APP

- 3.1.长按SET打开蓝牙(再次长按SET关闭蓝牙)
- 3.2、扫描二维码下载"SIRUI Light"手机APP
- 3.3、手机打开蓝牙,在"SIRUI Light" APP中连接对应的灯就可通过APP控制灯。





具体操作请参考手机APP使用说明。

4、安装和固定

4.1 通过底部或者侧面1/4螺丝孔可以固定在带1/4螺丝柱的灯架或者桌面支架上 使用。



注意事项 1、请勿将灯放在高温高湿的地方。 2、请勿渴无接触产品。不可把产品。

2、请勿湿手接触产品,不可把产品浸入水中或暴露

3、请使用配套适配器,其他规格有可能导致硬件损坏。如使用其他电源适配器造成的产品故障,不予保修。


维护保养

- 1、灯体在工作时,如发现异常,应立即关掉电源,查明原因。
- 2、灯体稍有发热为正常现象。
- 3、维修由本厂维修部负责。
- 4、本产品保修一年 , 消耗品适配器、电源线等不在一年保修范围内。
- 5、经发现,擅自检修此灯的,将取消一年保修期,维修需要收取相关费用。
- 6、如果本品出现故障或者被水淋湿,在专业人员维修后方可继续使用。
- 7、设计和规格如有变更, 恕不另行通知。

型号	E30B
产品尺寸	264*164*36mm
产品重量	约880g
LED功率	约25W
色温范围	2800K~7000K
特效模式	12类
裸灯100%光照度	1m距离 750lux
TLCI	平均98
CRI	平均96
工作环境温度	-10℃-45℃
控制方式	手机APP
蓝牙无线控制距离	15m

产品参数

设计和规格如有变更, 恕不另行通知。



3 (4) 0000099000009800 (7) 10 Frame 6 DC Power Socket Light Board 7 Thermovent Battery Compartment 8 Display

9

10

DIM Dial

Handle

1

2

3

4

5

SET Dial

Power Switch

batteries in the case.)

Operation

1. Power On/Off


When powered by the battery, hit "I" to turn on the light, press the button in the middle to turn off the light.

When powered by the adapter, hit "II" to turn on the light, press the button in the middle to turn off the light.



2. Mode Selection: Hit the SET dial to switch between the CCT mode and FX special effect mode.

2.1 CCT Mode



- 2.1.1 Color temperature adjustment: turn the SET dial to adjust the color temperature from 2800K to 7000K.
- 2.1.2 Brightness adjustment: turn the DIM dial to adjust the brightness from 0% to 100%.

2.2 Special Effects Mode

		FX
[•]	A	100%
Special Effect	Speed	Brightnes

2.2.1 Turn the SET dial to select a special effect. Hit the DIM dial to adjust the speed (A, B, C). Turn the DIM dial to adjust the brightness.

- 2.2.2 Brightness adjustment: turn the DIM dial to adjust the brightness from 0% to 100%.
- 2.2.3 There are 12 situational special effects for your choice:

No.	Display	Situation	DisplayA	DisplayB	DisplayC
1	4	Lightning	Discontinuous	Frequent	Sustainable
2	ģ	Flash	Flash	Press Conference	Paparazzi
3	÷	Broken Bulb	Discontinuous	Frequent	Sustainable
4	围	TV	Slow	Medium	Quick
5		Candle	Discontinuous	Frequent	Sustainable
6	\$	Fire	Firewood	Campfire	Fire Hazard
7	· † _	Firework	Brief	Continuous	Show
8	4 23	Blast	Discontinuous	Frequent	Sustainable
9	×.	RGB Cycle	Slow	Medium	Quick
10	\$ 9	Impulse	Slow	Medium	Quick
11	ŝ	Welding	Discontinuous	Frequent	Sustainable
12	SDS	SOS	Slow	Medium	Quick

Specifications		
Model	E30B	
Size	264*164*36mm	
Weight	about 880g	
Power	about 25W	
Color Temperature Range	2800K~7000K	
Special Effect	12	
100% Illuminance (LUX)	750 lux at 1m	
TLCI	98 on average	
CRI	96 on average	
Working Temperature	-10℃-45℃	
Control Method	APP Control	
Wireless Bluetooth Control Distance	15m	

* Product design and specifications are subject to change without notice.

3. APP Control

- 3.1 Press and hold the SET dial to turn on Bluetooth. (Press and hold the SET dial again to turn off Bluetooth.)
- 3.2 Scan the QR code to download the "SIRUI Light" App.
- 3.3 Turn on Bluetooth, enter the "SIRUI Light" App. Select "E30B LED Light" from the device list.

Light from the defice i






Scan the QR code to download the App.

For detailed steps, please refer to the APP instruction manual.

4. Installation

4.1 Mount the LED light on a stand via the bottom/lateral 1/4'' screw hole.



Warning

- Always keep this product dry. Do not put it in high-temperature or in damp conditions.
- Do not touch the product with wet hands. As this product doesn't have waterproof capability, please take measures of waterproof in rainy or damp environment.
- 3. Use of unauthorized power adapter may cause damage to the product and void the warranty.

Maintenance

- 1. If there is something wrong with the light when it is working, please turn it off first.
- 2. It is normal that the light gets a bit hot when it is working.
- 3. Maintenance must be performed by the authorized maintenance department which can provide original accessories.
- 4. This product, except for consumables, supports a one-year warranty.
- 5. Unauthorized service will void the warranty.
- 6. If the product had failures or was wetted, do not use it until it is repaired by professionals.
- 7. Changes made to the specifications or designs may not be reflected in this manual.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be u sed in portable exposure condition without restriction