

ZW30 In-Wall Switch (On/Off)

### Meet your new smart switch!



Switch x1

Faceplate x1 wiring x1 screws x2

### **IMPORTANT!**

The fixture controlled by the Z-Wave In-wall Smart Switch must not exceed 960 watts (Incandescent); 1800W (15A) Resistive or 1/2 HP Motor. The switch is designed only for use with permanently installed fixtures.

### **Pre-installation preparation Tools You Will Need**

# Single switch wiring

Before you start; you may wish to change the paddle color to match your wallplate or decor.

Please proceed to <To Change Color Of The Paddle>.

### (1) Shut off power to the circuit at circuit breaker or fuse box.


### IMPORTANT! Verify power is OFF to switch box before continuing.


Turn OFF the power to the branch circuit for the switch and lighting fixture at the service panel. All wiring connections must bmade with the POWER OFF to avoid personal injury and/or damage to the switch.


### (2) Remove wall plate, Remove the switch mounting screws.

(3) Carefully remove the switch from the switch box. DO NOT disconnect the wires.

### **Understanding circuit diagrams**








www.nie-tech.com


ZW30 | In-Wall Switch (On/Off)

# **EVALOGIK®**

# **Dual And Triple Gang Boxes**

When installing the In-wall smart switch in multiple gang boxes it may be necessary to break off one or both sides of the scored tabs on the front yoke. This does not affect the electrical rating of the smart switch (see specifications for details).





### **Triple Gang Boxes**

### Please Note.

line an load must be in the same box for this schematic to work. if your is not, please reach out for a custom schematic.

# (3-WAY SWITCH WIRING)

The Traveler terminal is only used for 3-way wiring.

### Adding your device to a Z-wave network

(1) Follow the instructions for your Z-wave certified controller to include a device to the Z-wave network.



(2) Once the controller is ready to include your device, Quickly, three times press the top or bottom of the wireless smart switch(rocker) to include it in the network.





Now you have complete control to turn your fixture ON/OFF according to groups, scenes, schedules and interactive automations programmed by your controller. If your Z-wave certified controller features Remote Access, you can now control your fixture from your mobile devices.

### To exclude and reset the device

E. TRAVELER - Red/Other

Common

(only in 3-way in stallations)

1. Follow the instructions for your Z-wave certified controller to exclude a device from the Z-wave network. 2. Once the controller is ready to Exclude your device, Quickly, three times press the top or bottom of the wireless smart switch

(rocker) to exclude it from the network.

## To return your switch to factory defaults

1. tap-tap-tap'n'hold the upper paddle for at least 10 seconds.

Note: This should only be used in the event your network's primary controller is missing or otherwise inoperable.

### To Change Color Of The Paddle


This step is optional. Before you start you may want to change the color of the paddle to match your wallplate or decor. 1. Lift the Air Gap tab at the base of the paddle.

2. Push side tabs in on one side and then the other to release paddle. Lift the cover up and off.

3. Simply put the new paddle onto the switch by inserting the air gap and side tabs and snapping securely into place. Once this step has been completed please return to <Single switch wiring>.

### **Basic Operation**

The connected light can be turned ON/OFF in two ways: 1. Manually from the front panel of the In-wall Switch



### **Manual Control**

The Frount Panel Paddle Switch allows the user to: Turn ON/OFF the connected fixture

### **Z-WAVE INTEROPERABILITY**

This product can be included and operated in any Z-Wave network with other Z-Wave certified devices from other manufacturers and/or other applications. All non-battery operated nodes within the network will act as repeaters regardless of vendor to increase reliability of the network.

This Device supports Lifeline (association group 1) supporting 1 node for lifeline communication. Group 1 must be assigned the Node ID of the primary controller where unsolicited notifications will be sent. The Z-Wave controller should set this association automatically after inclusion. Lifeline association only supports the "Device Reset Locally" function. Refer to the instructions of your controller for any available details on how this can be set.

### **Command Class Information**

GRNERIC DEVICE CLASS: 10 - GENERIC\_TYPE\_SWITCH\_BINARY

SPECIFIC DEVICE CLASS:

01 - SPECIFIC\_TYPE\_POWER\_SWITCH\_BINARY

- 5E COMMAND\_CLASS\_ZWAVEPLUS\_INFO 25 COMMAND\_CLASS\_SWITCH\_BINARY
- 85 COMMAND\_CLASS\_ASSOCIATION
- 8E COMMAND\_CLASS\_MULTI\_CHANNEL\_ASSOCIATION 59 COMMAND\_CLASS\_ASSOCIATION\_GRP\_INFO
- 55 COMMAND\_CLASS\_TRANSPORT\_SERVICE 86 COMMAND\_CLASS\_VERSION 72 COMMAND\_CLASS\_MANUFACTURER\_SPECIFIC 5A COMMAND\_CLASS\_DEVICE\_RESET\_LOCALLY
- 73-COMMAND\_CLASS\_POWERLEVEL
- 70 COMMAND\_CLASS\_CONFIGURATION
- 6C COMMAND\_CLASS\_SUPERVISION 9F COMMAND\_CLASS\_SECURITY\_2 7A COMMAND\_CLASS\_FIRMWARE\_UPDATE\_MD

\*The association group supports five nodes and lifeline function

**Parameter Settings** 

- 1: Locally Button function Parameter=1 Size=1 Value=0 Up Button:On Down Button: Off Value=1 Up Button:Off Down Button: On
- Default = 0 2: LED Indicator

Default = 0

- Parameter=2 Size=1 Value=0 On when Off and Off when On Value=1 On when On and Off when Off Value=2 Always Off Value=3 Always On
- 3: Auto Turn-Off Timer Parameter=3 Size=4 Values: 0 - 65535 (M); default 0M
- 4: Auto Turn-OnTimer Parameter=4 Size=4 Values: 0 - 65535 (M); default 0M 5: Restores state after power failure
- Parameter=6 Size=1 Value=0 output off Value=1 output on Value=2 out put the state after power Default=2

# **Special Settings**

Tap 6x on Button (A) = Change LED Status Tap 8x on Button (B) = Invert Switch

### FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class & digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications . However, there is no guarantee that interference wil occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

### Reorient or relocate the receiving antenna

Increase the separation between the equipment and receiver

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected, -Consult the dealer or an experienced radi o/TV tech ni cian for help

**Wiring Instructions - A Few Quick Reminders** A quick note before we give out the wiring schematics. Please do not try installing this device if you are unsure of how electricalcircuits operate within your home. As exciting as it is to have a smart switch installed, it can be dangerous and even life-threatening if you do not install this correctly. Please consult a qualified electrician if necessary. With that said, here are a few other warnings we'd like to point out for

### **CAUTION - PLEASE READ!**

This device (ZW30) is intended for installation in accordance with the National Electric Code and local regulations in the United States, or the Canadian Electrical Code and local regulations in Canada. If you are unsure or uncomfortable about performing this installation consult a qualified electrician.

# **WARNING - SHOCK HAZARD**

TURN OFF THE POWER to the circuit for the switch and lighting fixture at the service panel (circuit breaker) prior to installation.

ALL WIRING CONNECTIONS MUST BE MADE WITH THE POWER OFF to avoid personal injury and/or damage to the switch



# Risk of Fire Risk of Electrical Shock Risk of Burns

# **MEDICAL EQUIPMENT**



Please DO NOT use this switch to congrol Medical or Life Support equipment. Z-Wave devices should never be used to control the On/Off status of Medical and/or Life Support equip-

### **CONTROLLING APPLIANCES**

Please exercise EXTREME CAUTION when using Z-Wave devices to control appliances. Reason being is because the appliance you want to control may be in a separate room and if unintentional behavior occurs (such as adevice turning on or off - either intentionally via schedules, or unintentionally via network error) this event may lead to a hazardous condition. For these reasons, please note the following suggestions:

1) Do not include Z-Wave devices in Groups or Scenes if they control appliances.

2) Do not use Z-Wave devices to control electric heaters or any other appliances which may present a hazardous condition due to unattended, unintentional, or automatic power control

### **SPECIFICATIONS**

Model: ZW30 Power: 120V AC, 60Hz

Signal (Frequency): 908.42 MHz Maximum Load: 960W Incandescent, ½ HP Motor or 1800W (15A) Resistive

Range: Up to 100 feet line of sight Controller (HUB) and the closest Z-Wave Module Operating Temperature Range: 32-104° F (0-40° C)

For indoor use. Specifications subject to change without notice due to continuing product improvement Approval: UL/FCC/IC/Z-Wave Plus Certified

UL: E464831 FCC ID: OXGZW30

REV.2.0 19/03/25





