


RSL wireless remote control

Model: RSL366T

Operating elements

1. Indicator lamp
2. Control keys
3. Sliding key
4. Battery compartment lid



Inserting/replacing battery

1. Remove the battery compartment lid (4) from the back of the remote control.
2. Insert one round cell battery, type 12V/23A, into the battery recess. The positive pole should face upward (see the "+" imprint on the battery). Push the battery all the way into the battery recess.
3. Close the battery compartment. The battery must be replaced when the remote control's range decreases noticeably or when the indicator lamp (1) no longer lights when a button is pushed.

Key functions

- The control keys (2) are arranged in two columns: left column = **ON**/ right column = **OFF**.
- Use the upper four keys on the left column to activate channels 1 to 4 individually.
- Use the upper four keys on the right column to deactivate channels 1 to 4 individually.

The indicator lamp (1) lights up each time a key is pressed.

Operation

Configuration and the dimming function will depend on your radio-controlled power outlet. You can find detailed information in the operating instructions of your radio-controlled power outlet.

The remote control can control an unlimited number of compatible radio-controlled power outlets

Technical data

Battery type12V/23A
Number of channels4 codes+ 4 channels
Transmission frequency.....433.92 MHz
Transmission rangemax. 30 m (in open area)

Notice

Do not ingest battery, Chemical Burn Hazard

This product contains a coin / button cell battery. If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device can be used in 0mm exposure condition, compliance with exposurer equirements.