



Instruction Manual

HL220 Wireless Bluetooth Earphone

Earphone Overview



Wearing




Charging the Earphone

Before using the earphone for the first time, you need to charge it with the micro-USB charging dock. The normal charging time is about 2 hours.

1. Remove the battery from the earphone.




2. Put the battery in the charging dock, the battery is fully charged approximately 2 hours.



*** NOTE!**

1. It is not possible to use the earphone during charging.
2. The Earphone will emit a beep sound when the battery is running low and requires recharging.
3. When the battery is put on charge, keep them at the temperature range from 0 °C ~ 45 °C (32 °F ~ 113 °F).

Inside Package




*** NOTE!**

Don't twist the ear hook and battery.

Turning On or Off

■ To turn on the earphone

To turn the earphone on, press and hold power (⏻) button until emit "power on" sound, as well as both the blue and red indicator light lit.



■ To turn off the earphone

To turn the earphone off, press and hold power (⏻) button 1 seconds, then it emit "power off" sound, as well as both the blue and red indicator light shut off.

Pairing the earphone

■ Pairing the earphone with a phone

To use the earphone with a phone, you need to pair the earphone with the phone. After successful pairing, the earphone connects automatically to the phone as soon as the earphone is turned on and within range.

To pair the earphone with a phone:

1. Make sure the earphone is turned off.
2. Keep your earphone and phone within 33 feet of each other during the pairing process. Turn on the Bluetooth function in the phone. For instructions, see the phone User guide.
3. Press and hold power (⏻) button until the blue and red indicator flash in an alternating fashion.
4. Choose the device's name "True Open" in the phone. Earphone emit "pairing to the phone" sound.

5. When the red indicator light shuts off and emits "your earphone connected" sound, the earphone is now successful pairing.



■ Pairing the earphone with each other

Before using the earphone for the first time, you need to make sure the earphone paired with each other correctly.

To pair the earphone with each other:

1. Make sure the earphone is turned on.
2. Keep your both side of the earphone within 33 feet during the pairing process.
3. **Right Earphone:** Press power (⏻) button and previous play button at the same time for 1 second until emit "pairing" sound, as well as the blue and red indicator light alternately lit.
4. **Left Earphone:** Press power (⏻) button and volume up button at the same time for 1 second until emit "discovering" sound, as well as the blue and red indicator light alternately lit.
5. When the blue indicator light shuts off, both of the earphone is now successful pairing.

*** NOTE!**

The earphone is paired with each other before out of the factory.

Calling (use the left side of earphone only)		Listening to music	
<div>Answering / Ending a call</div> <div><div><div></div><div>A beep indicates an incoming call. To answer a call, press power (⏻) button.</div></div><div><div></div><div>To end a call, press power (⏻) button.</div></div></div> <div><div>* NOTE!</div><div>Only one of the paired devices can be selected as a calling device at the same time.</div></div>		<div>Playing / Pausing the music</div> <div><div><div></div><div>Before using the earphone to listen to the music, you need to start the media player in your phone.</div></div><div><div></div><div>To play the music, press power (⏻) button.</div></div><div><div></div><div>To pause the music, press power (⏻) button.</div></div><div><div></div><div>To move between tracks, press (Previous / Next) button</div></div></div> <div><div>* NOTE!</div><div>Only one of the paired devices can be selected as a music source at the same time.</div></div>	
<div>Adjusting the volume</div> <div>To change the ear speaker or music volume:</div> <div>During a call, or when listening to music, press the volume up / volume down button to increase / decrease the volume.</div> <div><div>* NOTE!</div><div>1. You may also adjust the volume from your mobile phone’s volume control. 2. If you first time to turn on the HL220, suggesting adjust volume to the minimum to prevent the excessively loud sounds.</div></div>			
Troubleshooting			
<div><div></div><div>Radial does not work</div><div><div>✓</div><div>Make sure the correct calling device is selected.</div></div><div><div>✓</div><div>Make sure your phone supports the Bluetooth hands-free profile.</div></div></div>	<div><div></div><div>The sound is distorted</div><div><div>✓</div><div>Make sure the earpiece is no any visible dirt.</div></div><div><div>✓</div><div>Check that the battery is charged enough.</div></div></div>	<div><div></div><div>The music does not play in the earphone</div><div><div>✓</div><div>Make sure your phone is paired with the earphone.</div></div><div><div>✓</div><div>Restart the media player and select to use the earphone.</div></div><div><div>✓</div><div>Make sure the correct music source is selected.</div></div></div>	<div><div></div><div>Volume control does not work</div><div><div>✓</div><div>Restart the earphone.</div></div></div>
<div><div></div><div>The earphone is automatically turned off</div><div><div>✓</div><div>Check that the battery is charged enough.</div></div></div>	<div><div></div><div>No connection to the phone</div><div><div>✓</div><div>Make sure the earphone is charged.</div></div><div><div>✓</div><div>Make sure the earphone within range of the phone, maximum distance of 10 metres (33 feet) with no solid objects in between. Pair the earphone with the phone again.</div></div></div>	<div><div></div><div>The sound is weak</div><div><div>✓</div><div>Make sure the volume on your earphone and mobile phone is turned up.</div></div><div><div>✓</div><div>Check that the battery is charged enough.</div></div></div>	<div><div></div><div>The earphone is no connection with each other</div><div><div>✓</div><div>Refer to “Pairing the earphone with each other” section.</div></div><div><div>* NOTE!</div><div>If your earphone still does not function properly after taking the solution mentioned above, please contact the retailer from which you purchased the product.</div></div></div>

Specifications			Precautions
<div>Physical Specifications</div> <div>Battery</div> <div>Connectivity</div>	Earphone Style	Ear Hook Type	<ul style="list-style-type: none">Driving while talking on your mobile phone is dangerous, and illegal in many states. Although this device enables drivers to conduct hands-free conversation. It is still dangerous to drive and use a mobile phone at the same time.Do not use Wireless Bluetooth Earphone in a low (less than 32 °F / 0°C) and high (more than 113°F / 45°C) temperature, nor in a place outside humidity ranges (15% ~ 93% R.H.), or Wireless Bluetooth Earphone may not function properly.Do not drop Wireless Bluetooth Earphone, and avoid any strong impact.Do not use Wireless Bluetooth Earphone on any body part other than your auricle.If any damage on the sensor inside the microphone, or on the unit itself, please return the goods to our local distributor.Keep Wireless Bluetooth Earphone away from children. Do not let them use Wireless Bluetooth Earphone on their own either. They may choke on earphone or tiny component parts by accident.The battery is built-in Wireless Bluetooth Earphone; please do not attempt to dismantle the Wireless Bluetooth Earphone.Check your local laws or regulations to find out whether a specific protection level is mandated in your area.
	Weight	Approx. 14.0 g (included battery)	
	Item Size	43.5 mm x 67 mm x 23.5 mm	
	Battery Type	Rechargeable Lithium Battery	
	Battery Capacity	120 mAh	
	Charging Time	2 hrs	
	Standby Time	30 hrs (full charged)	
	Talk Time	5 hrs	
	Streaming Time	Up to 6 hrs	
	Bluetooth Version	Bluetooth 4.0	
	Compatible Bluetooth Profile	HFP, A2DP	
	Maximum Communication Range	Approx. 10 meters	
	Frequency Range	2.4 GHz (2.402 GHz ~ 2.480 GHz)	
Maintenance			Limited Warranty
<ul style="list-style-type: none">Power off the earphone when not in use.Do not expose this product to water or other liquids.Do not use detergent or any strong chemicals to clean the earphone.Do not attempt to disassemble or change any parts of the earphone, including main unit, battery, and earpiece, due to substitution of a component different from that supplied might result in functionality error.If you will not use the earphone for long periods, be sure to store it in a dry place, free from extreme temperature humidity and dust.Use a piece of cloth with water or mild cleansing agent to wipe the earphone and dry it immediately with a dry cloth.If any suggestion or service is requested, please consult your service station.			<ul style="list-style-type: none">Warranty For One Year from the purchasing date <p>Please note that this warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; improper installation; unauthorized repairs or modifications; improper use of electrical/power supply; loss of power; dropped product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; transportation damage; theft; neglect; vandalism; or environmental conditions; loss of use during the period the product is at a repair facility or otherwise awaiting parts or repair; or any other conditions whatsoever that are beyond the control of importers or distributors.</p>
FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT			
<p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">Reorient or relocate the receiving antenna.Increase the separation between the equipment and the receiver.Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.Consult the dealer or an experienced radio/TV technician for help. <p>CAUTION:</p> <p>To assure continued FCC compliance:</p> <ul style="list-style-type: none">Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment. <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p>			

FCC Information

This device (HL202[BT Personal Sound Amplification Product]) complies with Part 15 of the FCC Rules.

NOTE: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

NOTE: The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no grantee that interference will not occur in a particular installation. If this equipment dose cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on , the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Wireless Bluetooth Earphone

Warranty Card for 1 Year

Name		Birthday (year/month/date)		Phone:	
Address					
Product Name:			Date of Purchase: (year/month/date)		
<p>© Within 1 year since the purchasing date:</p> <p>Thank you for purchasing our product! Our products must undergo the careful check before out of the factory. Please feel free to use.</p> <p>During the warranty period, HEALTH & LIFE CO., LTD. is responsible the product defects under normal use for free maintenance.</p> <p>© Disclaimer:</p> <p>We don't cover any repair or alterations carried out by parties other than HEALTH & LIFE CO., LTD.</p>			(Distributor Stamp)		



Discard the used product to the recycling collection point according to local regulations.

IP22—Degrees of protection provided by enclosures

HEALTH & LIFE CO., LTD.

9F, No. 186, Jian Yi Road, Zhonghe District, New Taipei City, Taiwan

www.healthandlife.com.tw