


Front

55 X 440 MM 80g 超白哑粉纸 黑白双面印刷 风琴折


55

Smart
Button



zigbee Bluetooth V1.5A

1 Dimension




2 Specification

Power supply: Battery CR2032 3V DC
Communication: ZigBee 3.0*
Control distance: 25m open area
Ingress Protection: IP55
Dimensions: 45 X 45 X 12.5mm
Operating temperature: -10 °C~45 °C
Working Humidity: <90%RH
Life of battery: 1 years (General use)

*Available for selected model


3 Install the battery / Reset / Pairing



1. Remove the screw 2. Install the CR2032 battery
3. Hold "RESET" to 6s, LED will start flashing 4. Install the cover

4 Connet to Network


Scan the QR code to download APP




Gateway is required to connect device

5 Add Device

ZigBee model




Bluetooth model



5.1 Add Device

5.2 Remote mode (Default mode)


ZigBee model Only




Rear

5.3 Remote mode

ZigBee model Only




UI or functions may change according to firmware or APP version




5.4 Remote mode

ZigBee model Only


B. Control description under remote mode




Single Press
On



Single Press
Change preset
light mode
when light up



Dual Press
Off




Long Press >3s
Dimming

Note: The above functions may be different depending on the model of the smart bulb



5.5 Mode swap

ZigBee model Only





Remote mode ↔ Scene mode


5.6 Scene mode



5.7 Scene mode



5.8 Scene mode



5.9 FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

6 FCC Warning

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).