



1 The device weight is less than 1 kg. The installation height of less than 2 m is recommended.

B

Smart Scene

for S40TPR

This is a smart plug. After pairing it with eWeLink App, you can turn on/off the connected devices via the smart phone wherever you are, schedule its on/off, share it with your families to control together, etc.










Щ

Inching Mode Power Monitoring Over-load Protection O Power monitoring and over-load protection are only available

eWeLink App pairing

1. Download the eWeLink App □ | eWeLink



After powering on, the device will enter the Bluetooth Pairing Mode during the first use. The WI-Fi LED indicator changes in a cycle of two short and one long flash and release.

The device will exit the Bluetooth Pairing Mode if not be paired within 3mins. If you want to enter this mode again, please long press the pairing button for about 5s until the Wi-FLED indicator changes in a cycle of two short and one long flash and release.

3. Add device



Tap "r" and select "Buetooth Fairing", then operate following the prompt on the App.

FFS setup instruction

Prostruction free Serup has less different modes of operation Jano-Youch Satur-2755 and Barcody Satur-BCSs. The HTLprocess fruit attempts 275 to setup a device, and falls back to BCS if 275 is not possible.

. Zero-Touch Setup (ZTS)

Download the latest Ameron Riesa App and pair it with Ameron Scho.



re required to check "Save password to Amazon" to make FFS setup flow complete

2. Download the eWeLink App

3. Rind accounts







If your eWeLink App has been binded with Alexa App, please ignore the above processes.

Ensure the account you sign up Alexa App is same with that



After powering on, the device will enter the FFS pairing mode, the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release. Then wait for 1-2 mins to fresh the device list on Alexa App and eWeLink App, and the added device will appear in the device list. To control it, say "Alexa, turn on First Plug"



New arrival

Promotion

How-to videos



① The device will exit the FFS pairing mode if not paired within 3mins. If you want to enter this mode, please long press the pairing button for about 5s until the WI-FLED indicator changes in a cycle of two short and one long flash and release.

① If your device is not able to successfully setup using Zero-Touch Setup (ZTS), which probably because it is not purchased on Amazon.com, you can attempt Barcode Setup (BCS) to complete FFS setup.

Barcode Setup (BCS)

Please refer to the first 3 steps of Zero-Touch Setup (ZTS) for Barcode Setup (BCS) setup

Scan the bar code near the "key" icon on the side of the package by Alexa App and then add the device according to the prompt on the App. Power on your smart device and fresh the device list in both Alexa App and eWeLink App after it is added successfully. then you will see it in the device list. To control it, say "Alexa, turr

① Barcode Setup (BCS) is not available now. You can pay attenti to our website (sonoff.tech) or consult our customer service for the available time.

\$

Model	S40TPB, S40TPB Lite
Input	120V~ 60Hz
Max. Load	15A/1800W
Wi-Fi,BLE	IEEE 802.11 b/g/n 2.4GHz/BLE
App operating systems	Android & IOS
Color	White
Working temperature	-10-40°C
Shell material	PC V0
Dimension	76x40x32mm

Wi-Fi LED indicator status instruction

Flashes (one long and two short): Bluetooth pairing mode Keeps on: Device is online

Flashes quickly once: Fail to connect to router

Flashes quickly twice: Connected to router but fall to connect to Serv Flashes quickly three times: Firmware updating

Switch Network

Specifications

Select the "Wi-Fi Settings" in the "Device Settings" interface on th eWeLink App to change

Factory Reset

Deleting the device on the eWeLink App indicates you restore it t factory setting.

Common Problems

Fail to pair Wi-Fi devices with eWeLink App

 Make sure the device is in pairing mode.
 The device will automatically exit the pairing mode if not paired. 2. Please turn on the location service on your mobile phone and

Please turn on the location service on your mobile phone and give the permission. Before choosing the Wi-Fi network, the location service should be turned on and the permission is given. Location in formation permission is used to obtain Wi-Fi list information. If you tap 'Disable', the device will not be added.
 Make sure you Wi-Fi network rus on the 2-46H band.
 Make sure you entered a correct Wi-Fi SSID and password, no special characters contained. A worm gassword is exprey common reason for pairing failure.
 reason for pairing failure.
 reason while pairing.
 Please try to pair the device in the compatible mode.

Wi-Fi devices "Offline" issues

Please check the following issues by the Wi-Fi LED indicator status The LED indicator blinks once every 2s means you fail to connect

Maybe you entered a wrong Wi-Fi SSID and password.

 Make sure your Wi-Fi SSID and password don't contain special characters, for example, the Hebrew, Arabic characters, Our system can't recognize these characters so that fail to connect to

the Wi-Fi.

3. Maybe your router has a lower carrying capacity.

4. Maybe the Wi-Fi signal strength is weak. Your router is too far away from your device, or there may be some obstacles between the router and the device so that the signal transmission is blocked 5. Be sure that the MAC of the device is not on the blacklist of your

The LED indicator flashes twice on repeated means you fail to

connect to the server.

1. Make sure the Internet connection is normal. You can use you phone or PC to connect to the Internet, and if you fail to access, please check the availability of the Internet connection.

 Maybe your router has a low carrying capacity. The number of devices connected to the router exceeds its maximum value. Please check the maximum number of devices that your router Please check the maximum number of devices that your router can carry. If the number of connected devices exceeds the maximum value, please delete some devices or change a lager router and try again.

3. Please contact your ISP and confirm our server address is not

shielded: cn-disp.coolkit.cc (China Mainland)

as-disp.coolkit.cc (in Asia except China) au-dien coolkit ee (in ELD

eu-aisp.coolkit.cc (in U) us-disp.coolkit.cc (in US) If none of the above methods solved this problem, please submit your issue via help & feedback on the eWeLink App.

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions; (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

FLC Kadiation exposure statement. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance20m between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note:

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the ECC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment interference in a residential installation. This equipment installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turnion, which can be determined by turnion.

- Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

 Consult the dealer or an experienced radio/TV technician for help.

10

Scan the QR code or visit the website to check the lastest user manual and help.



Shenzhen Sonoff Technologies Co., Ltd. 3F & 6F, Bld A, No. 663, Bulong Rd, Shenzhen, GD, China Website: sonoff.tech ZIP code: 518000

11







