

128g铜版纸

英语


英语

英语

英语

英语

YT04



Mobile power bank

5000mAh




USER MANUAL









Please read this instructions completely and keep it properly.

Warning


Please follow the above safety instructions otherwise it will cause fire, electric shock, damage and other damage.

1. Specifications

English   

Model Number: YT04
Product Name: Mobile power bank
Battery(Power Bank): 3.7V/5000mAh
Type-C (Power Bank) Input: 5V  3A, 9V  2A, 12V  1.5A
Type-C (Power Bank) Output: 5V  3A, 9V  2.22A, 12V  1.67A
Wireless Charging (Power Bank) Output: 5w, 7.5W, 10W, 15W
Type-C (Base) Input: 5V  3A, 9V  2A
iPhone 12/13/14/15/16 has pop ups (supports 17.2.1 software or above)
iPhone 13/14/15/16 supports 15W, iPhone 12 does not support 15W

2. At a Glance




1.Power Button


2.USB-C Port

3.Battery Level Indicator

3.Using a charging cable to charge your phone




4. Using the power bank to charge your phone




5. Charging the iPhone 12 Series or Later

Place your device on the charger as illustrated below. It will be held in place magnetically and start charging wirelessly



6. Charging Your Device and Recharging Your Portable Charger Simultaneously



7.Important safety instructions

When using this product,basic precautions should always be followed, including the following:

1.Store the product in a cool, dry place.

2.Do not store the product in a hot or humid environment.

3.Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of injury to persons.

4.Operating temperature should be between 0°C to 40°C.

5.Do not disassemble the product.Take it to a qualified service person when service or repair is required.Incorrect reassembly may result in a risk of fire or injury to persons.

6.If the product is not used for long periods of time,you should charge and discharge it once every three months.

7.When charging a device,the product may feel warm.This is a normal operating condition and should not be a cause for concern.

8.In normal conditions, the battery performance will decline over several years.

9.Do not dispose of the product in heat or fire.

10.Do not clean the product with harmful chemicals or detergents.

11.Misuse, dropping,or excessive force may cause product damage.

12.When disposing of secondary cells or batteries,keep cells or batteries of different electrochemical systems separate from each other.

13.Please note that discharged batteries may cause fires or smoke.
Please apply tape to the positive and negative poles to achieve insulation

8.FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.