
Face recognition temperature measurement terminal




ITC080

User manual






3) Product size (mm)-Column style




4) Product size (mm)-Wall hanging style



1) Power on settings network and device activation

(WiFi network selection)









(Device activation)









 $2\)$ Set server, company, community name, installation location and access mode




1) Face input of local device (click the face mark in the lower right corner with the cursor)




2) Select the gate settings - click "open face management"



3) Face registration




4) Select single person registration & batch import face for registration





Take photos, input name and card number for single registration




2 0 p 0 4 0

(Choose a single local photo)




Batch registration: in batch registration mode, first use the U disk to name the employee's picture (such as "Zhang San. JPG") under a folder. Then click the batch import function on the face recognition machine. Select the picture folder under the U disk to import.

1) Mask mode(When the mask mode is on, the device recognizes the user without the mask, and prompts to wear the mask. The device flashes red status light to indicate early warning!)



2) Stranger mode(Turn on stranger mode, the device will flash red status light for unregistered face users to show early warning! Don't open the door!)



CE NB

Herby, AXIOMTEK Co., Ltd declares that this Face recognition temperature

measurement terminal, ITC080 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product allowed to be used in all EU member states.

Use the Face recognition temperature measurement terminal in the environment with the temperature between -20 $^{\circ}$ and 35 $^{\circ}$.

Adapter shall be installed near the equipment and shall be easily accessible.

The plug considered as disconnect device of adapter

Adapter Model: TDX-1202000

Input: AC 100-240V, 50/60Hz, 0.6A Output: DC 12V, 2.0A

Operation Frequency: For WIFI: 2412MHz~2472MHz (802.11b/802.11g/802.11n(HT20))

For BT: 2402MHz~2480MHz

Max output power: For WIFI: 0.0555W

For BT: 0.003W

Manufacturer: AXIOMTEK Co., Ltd

Address: 8F., No.55, Nanxing Road, Xizhi District, New Taipei City 221026, Taiwan

Tel: 886-2-86462111-3221 Fax: 886-2-26918683

E-mail: jesse.wang@axiomtek.com.tw

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

DECLARATION OF CONFORMITY

I hereby declare that the product

Product:	e: Face recognition temperat	ura magaurament terminal		
	[1]	XXXXXXXX (x can be 0-9, A-Z, a-z,	e: n	
	nk; for marketing purpose)	^^^^^^ (x can be 0-5, A-2, a-2,		
	// RXIOMTEK			
Hardware Ver				
	sion: AD-i8-32-7-sw0.2-2020	0615		
Accessor	실실하는 것이 없는 사람들이 되었다면 이 경기를 받는다면 되었다. 사람들이 있는 것이 되었다면 하는데 하는데 되었다면 하는데 되었다면 되었다면 하는데 되었다면 하는데 되었다면 되었다면 되었다면 하는데 되었다면 하는데 되었다면 되었다면 되었다면 되었다면 되었다면 하는데 되었다면 되었다면 되었다면 되었다면 되었다면 되었다면 되었다면 되었다면			
Adapter Info	rmation:			
Model: TDX-1				
	0-240V, 50/60Hz, 0.6A			
Output: DC 12				
Manufacturer	Shenzhen Teng Da Xing El	ectron Co., Ltd.		
(Name of product,	type or model, batch or serial numb	ber)		
Directives 2014/53		e to the product within the scope of (/30/EU:and declare that the same ap		
EN 62368-1 :201	4+A11:2017			
EN62311:2008				
	01 489-17 V3.2.2 (2019-12)			
	89-1 V2.2.3 (2019-11)			
ETSI EN 300 328	3 V2.2.2 (2019-07)			
575 Boulder Co Pleasanton, Ca	No. of the Contract of the Con			
USA	20104-900000-903-0-U-			
Identification N	lumber: 2280			
MANUFACTURE - Address:	R or AUTHORISED REPRE	SENTATIVE:		
AXIOMTEK Co	o., Ltd			
8F., No.55, Na	nxing Road, Xizhi District, N	ew Taipei City 221026, Taiwan		
representative	s issued under the sole respo	onsibility of the manufacturer and, if	applicable, his authorised	
Point of cor		Shiven Wang		
Jesse W	2020-07-09 (Place, date of issue)	(Signature)		
(Name, tele		Shiwen Wang, Engineer		
		(Name and title in block letters)		
		grown and the fit block reactor		
	2020-12-16	42	N.	
(Place, date of issue)		/Sign	(Signature)	
V	and all mean any distributed in	76 5307 59	Jesse Wang, Section Manager	
		(Name and title in blo	(Name and title in block letters)	