











<div><div>智能桌面式 多功能无线充</div><div></div><div>使用说明书</div></div>	<div><div>1.包装清单及参数说明</div><div>产品名称：智能桌面式多功能无线充 功率：15W/10W/7.5W/5W/2.5W 无线充有效传输距离：0-6mm 整机尺寸：15.6cm×7.4cm×14.6cm 电源供电接口：USB TYPE-C</div><div>包装清单： 智能主机×1，使用说明书×1 电源数据线×1，包装盒×1</div><div>2.功能组件示意图</div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div>3.规格参数</div><div>■重量：产品净重约283g ■材质：ABS+PC+硅胶+喷涂丝印镭雕 ■输入电压/电流：5V/3A,9V/2A,12V/1.5A ■输出功率：15W/10W/7.5W/5W自动识别 ■充电频率：110K-205KHz ■充电距离：0-6mm ■支持规格：符合Qi无线协议充电 ■苹果手表无线充电器产品规格参数： 产品名称：苹果手表无线充电器 1.发射功率：2w/2.5W(MAX) 2.手表输出电流：5V 0.4A 3.传输距离：2mm 4.充电效率：73% 5.工作频率：110K-205KHz ■支持无线充手表充电型号： Apple Watch Series1/Apple Watch Series 2/ Apple Watch Series3/Apple Watch Series4/ Apple Watch Series5/Apple Watch Series6/ Apple Watch Series7/Apple Watch Series8/ Apple Watch SE/Apple Watch Ultra/ ■支持无线充耳机充电型号： Airpods二代 /Airpods Pro二代 / Airpods三代</div></div>	<div><div>■支持QC无线充的设备 HUAWEI: P40 Pro/Mate 30/MATE 20/Mate RS IPHONE: iPhone 14/14Pro/14 Pro Max/13/13 Pro Max/ 12/12 Pro/12 Pro Max/iphone 11/iphone 11 Pro/ iphone 11 Pro Max/iphone X/iphone XS Max/ iphone XR/iphone 8/iphone 8X/ SAMSUNG:Note20/Note10+5G/Note10/Note9/Note8/S20/ S10+/S10/S9+/S9/S8+</div><div>4.使用说明 一、开机，冰蓝灯亮起，线圈电机复位； 二、无线充电 1.手机无线充电——把带支持无线充电手机放置于无线充电平台位置线圈检查识别移动扫描会根据手机的线圈中心位置移动寻找充电最佳对位，对位后停止，手机无线进入快速充电，同时尾部灯光转换成绿灯。 2.手表充电——将无线充电手表放置于指定手表充电平台，手表无线充电。 3.耳机充电——将支持无线充电耳机放置产品座里的无线充电平台，耳机识别充电，同时尾部灯光转换成蓝色灯。 4.手机和耳机同时放置无线充电时，尾部灯转换成紫色灯光（备注：手表充电无灯光转换） 三、尾部氛围灯 上电默认长亮冰蓝灯，按一下灯控制开关切换绿色灯，按2次切换蓝色，再按1次切换紫色，按第4次关闭灯光，按第5次重新开启灯光冰蓝色，以此顺序循环。</div></div>	<div><div>光敏感应 数码管显示屏的亮度随环境光亮度变化而变化，当环境光变亮时，显示屏也变亮，当环境光变暗时，显示屏也变暗。 四、时间设置：（只调时/分） 1.双击按两下“左”键，进入时间设置模式，小时的十位开始闪烁。 2.短按“右”键，数字加1，如数字大于2，则回到0，如此循环。 3.如果任何数字在闪烁的时候，超过10S未有按键操作，则取消设置，且当前设置数据为无效，如果有按键被按下过，则重新计时。 4.如果在设置模式下，再按一次“右”键，进入下一位数字的设置；当小时和分钟数字均已设置好后，会发出“滴---”的一声长音。即表示循环闹钟设置成功。 五、闹钟设置：（分单次闹钟和循环闹钟设置） A. 单次闹钟设置 1.双击按两下“右”键，进入单次闹钟设置模式，小时的十位，闹钟图标开始闪烁。 2.短按“左”键，数字加1，如数字大于2，则回到0，如此循环。 3.如果任何数字在闪烁的时候，超过10S未有按键操作，则取消设置，且当前设置数据为无效，如果有按键被按下过，则重新计时。 4.如果在设置模式下，再按一次“右”键，进入下一位数字的设置；当小时和分钟数字均已设置好后，会发出“滴---”的一声长音。即表示闹钟设置成功。</div><div>B.循环闹钟设置 1.长按“右”键，进入循环闹钟设置模式，小时的十位开始闪烁。闹钟图标点亮。 2.短按“左”键，“数字加1，如数字大于2，则回到0，如此循环。 3.如果任何数字在闪烁的时候，超过10S未有按键操作，则取消设置，且当前设置数据为无效，如果有按键被按下过，则重新计时。 4.如果在设置模式下，再按一次“右”键，进入下一位数字的设置；当小时和分钟数字均已设置好后，会发出“滴---”的一声长音。即表示循环闹钟设置成功。 六、闹钟清除： 1.长按“左”键，所有闹钟数据从内存中清除（包括单次闹钟和循环闹钟），如有闹钟图标显示，则清除该图标显示。注意：如有闹钟贪睡启动，也将清除贪睡设置。 七、其他功能 A.闹钟 1.当单次闹钟的时间到达时，闹钟图标常亮，蜂鸣器间歌发出“滴、滴、滴、滴---”滴、滴、滴、滴.....持续1分钟后，将自动停止蜂鸣，闹钟图标熄灭。如果在闹钟期间，有任意按键按下，将立即结束。 2.当闹钟结束后，单次闹钟的数据会从内存中清除，即不会再次产生闹钟动作。 3.当循环闹钟的时间到达时，闹钟图标常亮，蜂鸣器间歌发出“滴、滴、滴、滴、滴、滴、滴、滴.....”持续1分钟后，将自动停止蜂鸣，如果在闹钟期间，有任意按键按下立即结束。</div></div>	<div><div>4. 当闹钟结束后，循环闹钟的数据会在内存中保留，即下一次时间到来时仍会产生闹钟动作。 5. 无论是单次闹钟还是循环闹钟，只要内存中存在闹钟的设置，闹钟图标将一直会显示在屏幕上，除非闹钟设置被清除或只设置了单次闹钟，且单次闹钟已经结束。 注意：请正确使用输入充电器5V/3A，9V/2A的支持协议快充充电器，使用低于5V/3A或者不支持快充协议的充电适配器，可能会导致充电慢，断充等情况。</div><div><div>⚠警告</div><div>1.请勿自行拆开或改装本产品 2.请勿将本产品放在潮湿环境中 3.请勿将本产品靠近热源或热源附近充电 4.请勿将水或其他液体流入本产品界面内部，导致产品损坏 5.请尽量避免本产品跌落，碰撞或过分挤压 6.本产品弃置在明火中可能会引起爆炸</div></div><div>感谢您对本产品的使用！</div></div>
--	--	--	---	--	--	---

<div><div>Smart Desktop Multifunctional Wireless Charging</div><div></div><div>Instruction Manual</div></div>	<div><div>1. Packaging list and parameter description</div><div>Product Name: Intelligent Desktop Multifunctional Wireless Charging Power: 15W/10W/7.5W/5W/2.5W Effective transmission distance of wireless charging: 0-6mm Overall size: 15.6cm × 7.4cm × 14.6cm Power supply interface: USB TYPE-C</div><div>Packaging list: Smart host × 1. User manual × 1 Power data cable × 1. Packaging box × 1</div><div>2. Functional component diagram</div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div>3. Specification parameters</div><div>■Weight: The net weight of the product is approximately 283g ■Material: ABS+PC+silicone+spray screen laser engraving ■Input voltage/current: 5V/3A, 9V/2A, 12V/1.5A ■Output power: 15W/10W/7.5W/5W automatic recognition ■Charging frequency: 110K-205KHz ■Charging distance: 0-6mm ■Supporting specifications: Charging according to Qi wireless protocol ■Apple Watch Wireless Charger Product Specifications: Product Name: Apple Watch Wireless Charger 1. Transmission power: 2w/2.5W (MAX) 2. Watch output current: 5V/0.4A 3. Transmission distance: 2mm 4. Charging efficiency: 73% 5. Working frequency: 110K-205KHz ■Supports wireless watch charging models: Apple Watch Series1/Apple Watch Series 2/ Apple Watch Series3/Apple Watch Series4/ Apple Watch Series5/Apple Watch Series6/ Apple Watch Series7/Apple Watch Series8/ Apple Watch SE/Apple Watch Ultra/ ■Supports wireless headphone charging models: Airpods Second generation /Airpods Pro Second generation / Airpod Three generations</div></div>	<div><div>■Devices that support QC wireless charging HUAWEI: P40 Pro/Mate 30/MATE 20/Mate RS IPHONE: iPhone 14/14Pro/14 Pro Max/13/13 Pro Max/ 12/12 Pro/12 Pro Max/iphone 11/iphone 11 Pro/ iphone 11 Pro Max/iphone X/iphone XS Max/ iphone XR/iphone 8/iphone 8X/ SAMSUNG:Note20/Note10+5G/Note10/Note9/Note8/S20/ S10+/S10/S9+/S9/S8+</div><div>4. Instructions for use 1.Turn on the machine, the ice blue light comes on, and the coil motor resets; 2.Wireless charging (1). Wireless charging of mobile phones - Place the phone with wireless charging support on the wireless charging platform for coil inspection, recognition, and movement scanning. The scan will move according to the center position of the phone's coil to find the best charging alignment. After alignment, it will stop, and the phone will enter rapid charging wirelessly. At the same time, the tail light will switch to a green light. (2). Watch charging - Place the wireless charging watch on a designated watch charging platform for wireless charging. (3). Headphone charging - Place the wireless charging platform that supports wireless charging headphones in the product seat, recognize the charging of the headphones, and convert the tail light into a blue light. (4). When the phone and earphones are placed for wireless charging at the same time, the tail light will switch to a purple light (note: there is no light conversion during watch charging) 3.Rear ambient light By default, the ice blue light will remain on when powered on. Press the light control switch once to switch to green light, press twice to switch to blue, press once again to switch to purple, press the fourth time to turn off the light, and press the fifth time to turn on the ice blue light again, and cycle in this order.</div></div>	<div><div>Photosensitive sensing The brightness of the Nixie tube display screen changes with the ambient light brightness. When the ambient light becomes bright, the display screen also becomes bright, and when the ambient light edge is dark, the display screen also becomes dark. 4. Time setting: (only adjust hours/minutes) (1). Double click and press the "left" button twice to enter the time setting mode, and the ten digits of the hour will start flashing. (2). Short press the "right" button, add 1 to the number, and if the number is greater than 2, return to 0, and cycle like this. (3). If any number flashes for more than 10 seconds without any key operation, the setting will be cancelled and the current setting data will be invalid. If any key has been pressed, the timing will be reset. (4). If in setting mode, press the "left" button again to enter the next digit setting; When both the hour and minute numbers have been set, a long sound of "drip" will sound. This indicates that the time setting was successful. 5. Alarm settings: (divided into single alarm and circular alarm settings) A. Single alarm setting (1). Double click and press the "right" button twice to enter the single alarm setting mode. The alarm icon will start flashing at the tenth digit of the hour. (2). Short press the "left" button, add 1 to the number, and if the number is greater than 2, return to 0, and cycle like this. (3). If any number flashes for more than 10 seconds without any key operation, the setting will be cancelled and the current setting data will be invalid. If any key has been pressed, the timing will be reset. (4). If in setting mode, press the "right" button again to enter the next digit setting; When both the hour and minute numbers have been set, a long sound of "drip" will sound. This indicates that the alarm clock has been successfully set.</div><div>B. Loop alarm settings (1).Long press and hold the "right" button to enter the circular alarm setting mode. The tenth digit of the hour will start flashing and the alarm icon will light up. (2). Short press the "Left" key, "Number plus 1. If the number is greater than 2, return to 0, and cycle like this. (3). If any number flashes for more than 10 seconds without any key operation, the setting will be cancelled and the current setting data will be invalid. If any key has been pressed, the timing will be reset. (4). If in setting mode, press the "right" button again to enter the next digit setting; When both the hour and minute numbers have been set, a long sound of "drip" will sound. This indicates that the circular alarm clock has been successfully set. 6. Alarm clear: 1. Long press and hold the "left" button to clear all alarm data from the memory (including single alarm and circular alarm). If there is an alarm icon displayed, clear the icon display. Note: If the alarm clock is activated, the snooze setting will also be cleared. 7. Other functions A. Alarm clock (1).When the time of a single alarm clock reaches, the alarm clock icon remains on, and the buzzer emits "beep, beep, beep, beep..." "beep, beep, beep, beep..." intermittently. After 1 minute, the beep will automatically stop and the alarm clock icon will go out. If any button is pressed during the alarm clock period, it will immediately end. (2). After the alarm clock ends, the data of a single alarm clock will be cleared from the memory, and no alarm action will be generated again. (3). When the time for the circular alarm clock reaches, the alarm clock icon remains on, and the buzzer intermittently emits "beep, beep, beep, beep, beep, beep..." After 1 minute, the beep will automatically stop. If any button is pressed during the alarm clock period, it will immediately end.</div></div>	<div><div>4. After the alarm clock ends, the data of the circular alarm clock will be retained in the memory, that is, when the next time comes, the alarm clock action will still be generated. 5. Whether it is a single alarm or a circular alarm, as long as there is an alarm setting in the memory, the alarm icon will always be displayed on the screen, unless the alarm setting is cleared or only a single alarm is set, and the single alarm has ended. Attention: Please use the input chargers 5V/3A and 9V/2A that support protocol fast charging chargers correctly. Using a charging adapter that is lower than 5V/3A or does not support fast charging protocol may cause slow charging, disconnection, and other situations.</div><div><div>⚠WARNING</div><div>1. Do not disassemble or modify this product by yourself 2. Do not place this product in a damp environment 3. Do not charge this product near or near heat sources 4. Do not allow water or other liquids to flow into the interface of this product, which may cause damage to the product 5. Please try to avoid dropping, colliding, or excessively squeezing this product as much as possible 6. Discarding this product in an open flame may cause an explosion</div></div></div> <div>FCC Warning Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. FCC Radiation Exposure Statement: The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be located for operation in conjunction with any other antenna or transmitter. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.</div> <div>Thank you for using this product!</div>
---	--	--	--	---	---	---