尺寸: 60x90mm 材质:100克书写纸 印刷:双面单色(风琴折)

MONSTER



Monster Airstar T103 真无线蓝牙耳机 使用说明书

产品参数

• 蓝牙版本: V5.4 •传输距离: 10m •喇叭直径: Φ12mm 喇叭阻抗: 16Ω

•灵敏度: 108.5db±3db

• 电池容量(充电盒): 300mAh 3.7V • 电池容量(耳机): 40mAh 3.7V 充电时间(充电盒): ≈1.5 小时

• 充电时间(耳机): ≈ 1.5 小时 播放时间(耳机):≈6小时 •配合充电盒播放时间: ≈ 20小时

耳机 *2 充电盒 *1 使用说明书*1 Type-C充电线 *1

模式	描述	语音提示
开机	蓝灯闪3下, 开机进入红蓝交替	Power on
关机	红灯长亮1秒	Power off
配对	配对之前,红蓝灯交替。 配对成功,主耳红灯蓝灯 交替,副耳灯熄灭	Paring
连接	指示灯熄灭	Connected
断开	主机红蓝交替,副机灭灯	Disconnected
耳机低电	左/右低电耳机红灯慢闪	BATTERY LOW
充电盒给耳机充电	耳机充电中蓝灯常亮, 充满后灯灭	/
充电盒低电	蓝灯闪耀	/
充电盒充电	红灯闪烁	/
充电盒充满	红灯常亮	/

1.开机 方式一: 打开充电盒上盖,耳机自动开机;

方式-·长按左/右耳机的MFR按键约3秒。耳机开机。

2.关机

方式一: 将耳机放回充电盒中合盖, 耳机自动关机; 方式二:与蓝牙设备断开连接3分钟后,自动关机。

3.配对

步骤一: 打开充电盒上盖, 取出耳机自动开机;

步骤二:打开智能设备的蓝牙列表,搜索"Monster Airstar T103" 进行配对,连接成功后,你会听到提示音 "Connected"。 *超出距离,在断开连接3分钟内,回到有效距离,自动连接设备。

*如果产品长时间不使用,应先充满电,并确保设备处于关机状态。 * 充电完成后,请将充电线拔出,避免长时间充电造成设备损坏。

音乐播放模式





恢复出厂设置

耳机连接蓝牙设备状态下,左/右耳机连击5次(5击后不做动作红灯 熄灭), 3S内单耳长按10S, 清除耳机连接设备信息, 然后关机。

- 1.从充电盒取出耳机,不需按任何按键,耳机自动开机,连接或配对,耳机放入充电盒,充电盒将自动
- 2 堂清法 表示长 机长期不用 建议15天存由1次 征长由池表示 耳机尾窝 存由部分经堂用棉签 酒精擦拭,能够帮助充电顺畅,避免接触不良,影响使用体验。
- 3.电池(电池组或电池组合)不得暴露在照明、烘烤或类似过热的环境中;禁止拆解、撞击、挤压或投人 火中,若出现严重鼓胀、切勿继续使用;切勿置于高温环境中;浸水后禁止使用。 4.由于本款产品采用无线连接方式,在日常使用过程中,受到环境、手机品牌、使用行为等因素影响, 可能在播放音乐过程中,会出现短暂、轻微的声音卡顿属于正常现象。

 长时间以高音量使用耳机可能会损害您的听力。建议只使用适当音量收听、通话和听音乐。 2.请不要冲洗或将产品浸入水中,以免造成故障。 3.不要自行拆卸产品及配件,以免导致损坏及保修失效。

5.请勿使用化学溶剂或清洗剂清洗产品。

Name of the Parts				s Substance 事物质	s	
部件名称	Pb 铅	Hg 汞	Cd 镉	Cr(VI) 六价铬	PBB 多溴联苯	PBDE 多澳二苯醚
Housing 外壳	0	0	0	0	0	0
Loudspeakers 喇叭单元	0	0	0	0	0	0
PCBA 电路板组件	х	0	0	0	0	0
Accessories 电源线,连接线	х	0	0	0	0	0

This table is compiled according to SJ/T 11364. 本表格依据SJ/T 11364的规定编制。

- O: 表示法有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的测量要求以下。
- Indicates that was returned to the limit requirement in GB/T 26572.

 本形式有實物授至少在该部件的第一均质材料中含量超过 GB/T 26572 标准规定的限量要求。

保修卡 尊敬的用户,本保修卡是您将来申请保修的凭证,请您配合销售商填写并妥善保管备用! 田户姓名 由子邮件 群系由活 邮政编码 通讯地址 产品信息 产品型号 产品名称 产品条码/编号/批号 名 称 地 址 联系电话 邮政编码 销售日期 发票号码 备 注 合格证 产品编号: 生产日期: 检验员:

MONSTER



Monster Airstar T103 True wireless Bluetooth headphone instruction manual

Product parameters

- Product parameters
- Bluetooth version: V5.4 Transmission distance: 10m
- Speaker diameter: Φ12mm
- Speaker impedance: 16Ω Sensitivity: 108.5db±3db
- Frequency response range: 20Hz-20kHZ
- Battery capacity (charging case): 300mAh 3.7V
- · Battery capacity (headphones): 40mAh 3.7V
- Charging time (charging case): \approx 1.5 hours
- Charging time (headphones): ≈ 1.5 hours Playback time (headphones): ≈ 6 hours
- Playback time with charging case: ≈ 20 hours

Packing List



Mode	Description	Voice prompt	
Power On	Blue light flashes 3 times, power on into red and blue alternation	Power on	
Power O	Red light constant for 1 second	Power off	
Pairing	Before pairing, red and blue alternating; pairing success, left ear main unit red and blue alternating, right ear vice light off	Paring	
Connected	Indicator light off	Connected	
Disconnect	Red and blue alternating for main unit, light off for secondary unit	Disconnected	
Low Battery	Red light flashes slowly for left/right low battery headphones	BATTERY LOW	
Headphones placed in charging case	Blue light constant when the headphones is charging, light goes out when it is full	/	
Charging case low power	Blue light flashing	/	
Charging case charged	Red light flashing	/	
Charging casefully charged	Red light constant	/	

Product Operation Guide

1.Power On

Way 1: Open the lid of the charging case, and the headphones will automatically turn on. Way 2: Press and hold the MFB button on the left/right headphone for about 3 seconds to power on the headphones.

2.Power Off

Way 1: Put the headphones back into the charging case and close the lid, and the headphones will automatically shut

Way 2: After being disconnected from the Bluetooth device for 3 minutes, the headphones will power off by themselves.

3.Pairing

Sten 1: Onen the lid of the charging case, take out the headphones, and they will start up automatically. Step 2: Open the Bluetooth list of the smart device, search for "Monster Airstar T103" to pair. Once the connection is successful, you will hear the prompt "Connected". * If the headphones go out of range, within 3 minutes after disconnection, when they get back to the effective range, they will reconnect to the device automatically.

If the product is not used for a long time, charge it fully first and make sure the device is powered off. After charging is done, unplug the charging cable to avoid damaging the device due to over - charging.

Music Playback Mode

Pause/Play: Double - click the MFB on the left/right headphone. Previous Track: Triple - click the MFB on the left

headphone. Next Track: Triple - click the MFB on the right headphone.

Volume +: Click the MFB on the right headphone Volume -: Click the MFB on the left headphone



Answer: Double - click the MFB on the left/right headphone.

Hang up: Double - click the MFB on the left/right headphone

Reject: Press and hold the MFB on the left/right headphone for 2 seconds.

Restore Factory Settings

When the headphones are connected to a Bluetooth device, click the left/right headphone 5 times in a row (the red light will go out after 5 clicks without further operation). Then, press and hold one headphone for 10 seconds within 3 seconds to clear the connection information of the headphones with the device and then power off.

- 1. Take out the earphone from the charging box, without pressing any button, the earphone will automatically turn on, connect or pair, put the earphone into the charging box, and the charging box will automatically Charge your headphones. Turn them off.
- Coffee clean, long life, if not used for a long time, it is recommended to charge once every 15 days to extend battery life, and the charging part of the headset is often used with cotton wabs Alcohol wipe, can help smooth charging, avoid bad contact, affect the use experienc 3. The battery [battery pack or battery combination] shall not be exposed to lighting, baking or similar overheating environment; Do not disassemble, knock, squeeze or throw in the fire
- If there is serious swelling, do not continue to use: Do not place in high temperature in their is sentials swelling, do not contained to use; to not place in right temperature environment. Do not use after solking water.

 4. Because this product adopts wireless connection mode, it is affected by environment, mobile phone brand, usage behavior and other factors in daily use. It may be normal to have a brief, slight sound delay during the playing of music.

- Do not use headphones at high volume for an extended perios of time. Keep the headphones away from dust and water.
- 3. Do not disassemble the headphones and accessories, otherwise warranty will be voided Keep headphones away from any impact or vibration.
 Do not use any chemical solvents or cleaning agent on the headphone.

Name of the Parts			Hazardous Substances			
Name of the Parts	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	0	0	0	0	0	0
Loudspeakers	0	0	0	0	0	0
PCBA	Х	0	0	0	0	0
Accessories	Х	0	0	0	0	0

This table is compliled according to SJ/T 11364 O : Indicates that this bazardous substance contained in all of the homogeneous materials for

U indicates that this hazardous substance contained in all of the homogeneous materials this part is below the limit requirement in GB/T 26572.
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

Warranty Service

Product barcode / Serial number / Batch number

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info			
User name		Email	
Contact number		Postal code	
Mailing address			
Product info	rmation		
Product name		Product number	

ndor infor	mation		
ne			
iress			
tact number		Postal code	
es date		Invoice number	

M MONSTER	
ificate of Approval	
uct No:	
uction Time: (PASS)	



FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.