

Accompanied your eye digital your life

SMART AUDIO
SPORT SUNGLASSES

User Manual

CE

RE

www.hisense.com

Statement

Thank you for using our products. Please read the manual before use. The manual might change because of hardware or software update.

Model name

Smart Eyewear with open directional audio, this product is a bluetooth glasses with stereo super mini speakers, easy operation, easy carrying.

Product characteristics

Frame color	Black
Frame material	TR
Lens material	Polycarbonate Blue light blocking lens TAC polarized sunglasses lens
Bluetooth	5.0
Charging time	90min
Batery capacity	95mAh (typical)
Charging voltage	DC5V
Speakers	Dual stereo speakers

*compatible with mainstream brands of mobile phones, tablets and other Bluetooth devices.

●Support AAC audio decoding technology, achieve CD-level sound quality.

●Left and right speakers, audio directed all around you, to give high quality stereo sound effect.

Packing list

Smart Eyewear *1
Charging cable *1
Cleaning cloth *1
User manual *1

Instructions

1.How to switch on and off

a) **Switch on the device:** when charging, unplug the charger and it will switch on automatically. When its off, press the touch sensor area of both arm for 3 seconds to turn on. By hearing "power on" , then accompanied with "Pairing" , your device is on.

b) **Switch off the device:** Plug in the charger, the device will switch off automatically, when the device is on long press the touch sensor area of both arm for 3 seconds to turn off. By hearing "Power off" and a beep sound the device is now off.

2.How to connect

Switch on the device, right temple starts pairing, red and blue light flash alternately. When pairing is completed, lights are off and hear a beeping tone.
a) First time connection: Click "setting" on your mobile phone or any smart device, click and turn on Bluetooth on your mobile phone or smart device, search for Bluetooth name: "Tide BT" , click to connect.
b) Second time connection, when you switch on the smart eyewear on, it will connect automatically to your mobile phone or smart devices.

How to operate

1) Play music: double tap the touch control zone to play or to pause.
2) Answer phone call: double tap touch control area.
3) Hang up phone call: double tap touch area.
4) Play next song: triple tap the tap control zone.

About charging

1) Low Battery alarm, will hear indicating tone "low battery" twice.
2) when device runs out of power it will power off automatically.
3) 3)When charging, the indicator is always red, when fully charged the red and blue light flashes for 10 seconds before the indicator light turns off.

Notice

1) Please read the user manual carefully before using this product and keep this manual well.
2) For first time use charge fully charge the product.
3) If the product is not charged for a long time (more than 2 weeks), please fully charge before use.
4) Use the cleaning cloth provided inside the pouch to clean lens. Other cloth might damage the lens.
5) When battery temperature exceeds -10°C -60°C, the product will automatically shut down.

Attention

1) Do not disassemble and repair the product for any reason, otherwise it might cause fire, electronic breakdown, or even complete damage to the product.
2) Do not put the equipment in an environment with too low or too high temperature (below -10°C or above 60°C).
3) Do not put the product under water or other liquid or humid environment.
4) Do not expose to sun for long time, otherwise they will be easily deformed, aged and broken.
5) Do not put the chargers magnetic suction close to any metal.

Important safety information

●Before using the device, please read all the safety information to ensure correct and safe use.
●Use of power supply, chargers or batteries not certified by the manufacturer may cause fire and explosion or other hazards.
●Please use the accessories approved by the manufacturer and compatible with the type of device.
●Please use the equipment within the temperature range of 0-45°C and store the equipment and accessories within the temperature range of -20°C-45°C. When the temperature is too high or too low, it may cause equipment failure.
●The device uses a non-removable built-in battery, do not replace the battery to avoid damage.
●After full charge disconnect the charger from the device and unplug charger from power source. Do not charge for more than 12 hours.

●Do not disassemble battery, or bump, squeeze or put the battery into fire. If serious expansion occurs, please do not continue to use.
●Do not put in a high temperature environment, battery overheating may cause explosion.
●Please keep in a dry place.
●Do not repair the product by yourself when it is not working properly.
●When connecting other devices, please refer to the user manual for the connection method, do not purposely connect to equipment that does not match.

To avoid hearing loss do not use high volume for long time.

WARNING

Please follow the relevant laws and regulations Do not use in the mentioned environment below:
For example, gas stations, oil warehouses and other places where inflammable and explosive oil, gas or chemical are stored.

●Do not use the equipment in the operating room, emergency room, intensive care department.
In order to avoid interference with the medical devices, please keep the device away from pacemaker, a distance of at least 15 meters.

●If there is need to use the device near a personal medical device, consult a physician and device seller.
●Do not use outside in thunderstorm to avoid lightning strike.
●Do not use the charger in the bathroom were there is high humidity, this may lead to electric shock, personal injury, fire, and damage to charger.
●Please comply with the relevant laws that clearly prohibit use in any environment.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.