


说明书要求:4C印刷
1.印刷方式: 折页
2尺寸:76.2X76.2mm
3.材质:90g铜版纸
5.请按照页数正确排版(如:123.....)

76.2mm

<div>Bradford Bluetooth® Headphones</div> <div>IC ID: 21530-101128 FCC ID: 2AGR4-101128</div> <div>BC</div> <div>Instruction Manual</div>	<div>OVERVIEW</div> <div></div> <div>1. Power/Multi-function Button 2. Volume Up / Next Track Button 3. Volume Down / Previous Track Button 4. 3.5mm AUX Port 5. LED Indicator Light 6. Mic 7. Type C USB Charging Port</div>	<div>SPECIFICATION</div> <div>Bluetooth specifications: Bluetooth® version 5.0 Support profile: A2DP, AVCTP, AVDTP, AVRCP, HFP, SPP, SMP, GAP, GATT, RFCOMM, SDP, 12CAP PROFILE Transmission distance: up to 10m (This may vary based on environmental factors or the type of Bluetooth® device being used) Built-in battery: 500 mAh Lithium Battery USB Recharge voltage: 3.7V Frequency Response: 20hz-20Khz Sensitivity: 100dB ± 3 Product dimensions: 165.3x83x189.3mm Playback time: 30 hours Charging time: 3 hours</div> <div>PACKING LIST</div> <div><ul style="list-style-type: none">• Bluetooth® Headphones• USB Charging Cable• 3.5mm AUX cable• Travel Case• User Manual</div>	<div>BLUETOOTH® OPERATION</div> <div>1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device. 2. Turn the headphones on by pressing the power/multi-function button until the LED indicator light begins to flash. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode. 3. "GEMLINE HP" will appear on the Bluetooth device list, select "GEMLINE HP" to establish pairing. 4. When you want to play audio from another Bluetooth device, disconnect the headphones from the original device and follow steps 1-3 to re-pair the headphones with a new Bluetooth enabled device.</div> <div>BUTTON CONTROL</div> <div><ul style="list-style-type: none">• Power On/Off: Press and hold the power/multi-function button for approximately 4 seconds.• Play/Pause: Press the power/multi-function button once to Play/Pause.</div>	<div>• Volume Up/Previous Track: Press + button once to increase volume, press and hold for next track. • Volume Down/Next Track: Press - button once to decrease volume, press and hold for previous track. • Hands-free Phone Use: Press the power/multi-function button once to answer an incoming call. While on a call, press the power/multi-function button once to end the call. • Reject a call: Press the power/multi-function button twice to reject an incoming phone call. • Redial the last number: Press the power/multi-function button twice.</div> <div>AUX PLAYBACK OPERATION</div> <div>1. Connect the headphones to a smartphone, audio device, or laptop with the 3.5mm AUX cable (included). 2. The next/previous song button can only be adjusted on the device that is connected through the 3.5mm AUX cable.</div>	
封面		1	2	3	4

<div>CHARGING THE HEADPHONES</div> <div>1. When the battery is low, please charge via the included USB cable. Charging time is approximately 3 hours and provides up to 30 hours of continuous operation. 2. The LED indicator light will be red during charging and will turn off once it is fully charged. When the battery is low, the LED indicator light will flash red.</div> <div>WARNING</div> <div>1. Do not disassemble, repair, or modify the headphones. 2. Do not place product in or near fire to avoid danger, as it uses a lithium battery. 3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the headphones. 4. Keep the headphones dry and do not store the headphones in damp areas to avoid damage to the headphones. 5. Avoid dropping the headphones as it may cause damage to the product.</div>	<div>KIND REMINDER</div> <div>1. To prolong the headphones life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time. 2. When an error occurs with the headphones, please turn off the headphones and restart it to troubleshoot. 3. When the headphone power is low, the Bluetooth range may be affected. Please charge the headphones to avoid disruptions during use.</div> <div><table><tr><th>PROBLEM</th><th>TROUBLESHOOTING METHOD</th></tr><tr><td>Unable to pair the headphones with a mobile device</td><td>1. Inspect whether the headphones are searching for a Bluetooth enabled device to connect to. If not, restart the headphones. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the headphones.</td></tr></table></div>	PROBLEM	TROUBLESHOOTING METHOD	Unable to pair the headphones with a mobile device	1. Inspect whether the headphones are searching for a Bluetooth enabled device to connect to. If not, restart the headphones. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the headphones.	<div><table><tr><th>PROBLEM</th><th>TROUBLESHOOTING METHOD</th></tr><tr><td>The music stops from time to time</td><td>1. Inspect the distance between the headphones and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the headphones and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the headphones.</td></tr><tr><td>The sound is low or distorted</td><td>1. Inspect the volume of the connected headphones or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the headphones.</td></tr><tr><td>The Bluetooth indicator light remains OFF</td><td>1. The power of the battery is insufficient, please recharge the headphones. 2. Restart the headphones.</td></tr></table><div>The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners. PMN : Bradford Bluetooth Headphones</div></div>	PROBLEM	TROUBLESHOOTING METHOD	The music stops from time to time	1. Inspect the distance between the headphones and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the headphones and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the headphones.	The sound is low or distorted	1. Inspect the volume of the connected headphones or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the headphones.	The Bluetooth indicator light remains OFF	1. The power of the battery is insufficient, please recharge the headphones. 2. Restart the headphones.	<div>English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B). French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de la licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes: (1) Cet appareil ne doit pas provoquer d'interférence. (2) Cet appareil doit accepter toute interférence, y compris les interférences nuisibles. L'appareil numérique conforme aux normes canadiennes peut émettre des ondes radio à faible puissance. This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance. Cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du titre 102 et conformément avec les limites d'exposition aux champs électromagnétiques. This equipment complies with Canadian radiation exposure limits set forth for an uncontrolled environment. Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada énoncées pour un environnement non contrôlé. Portable RF Exposure Statement The device has been evaluated to meet general RF exposure requirement. This</div> <div>equipment should be installed and operated with minimum distance 0mm between the radiator and your body. L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. Cet équipement doit être installé et utilisé avec une distance minimale de 0 mm entre le radiateur et votre corps. FCC Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. RF Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used with minimum distance 0mm between the radiator and your body.</div>
PROBLEM	TROUBLESHOOTING METHOD														
Unable to pair the headphones with a mobile device	1. Inspect whether the headphones are searching for a Bluetooth enabled device to connect to. If not, restart the headphones. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the headphones.														
PROBLEM	TROUBLESHOOTING METHOD														
The music stops from time to time	1. Inspect the distance between the headphones and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the headphones and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the headphones.														
The sound is low or distorted	1. Inspect the volume of the connected headphones or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the headphones.														
The Bluetooth indicator light remains OFF	1. The power of the battery is insufficient, please recharge the headphones. 2. Restart the headphones.														
5		6	7	8	封底										

76.2mm