


ALLOY REMOTE CONTROL

DIE-CAST EXCAVATOR

Front/reverse digging
Alloy bucket
Console rotation
2.4G remote control
Lithium battery
lights/sound





INSTRUCTION MANUAL

Thank you very much for purchasing our products.
Engineering Series :Alloy version 12 channel remote control excavator.
Before using this product, please read the user's manual carefully for correct and safe use.
Be sure to save the instructions for your reference.

Remote Control Introduction

12-CHANNEL FUNCTION: that is, 12 independent keys, each key corresponds to a function, with independent programming demonstration function.





USE 2x1.5V"AA" NON-RECHARGEABLE BATTERY(NOT INCLUDED)

Charging Method

- Turn to open the buttonlock, lift the battery cover of the excavator, and press the clamp to remove the battery.
- Press the battery charging port into the configured charger jack.
- When connected to the socket, the light indicates that the battery is charging.
- When the light goes out, the rechargeable battery is fully charged.
- Turn to open the button lock, lift the battery cover of the excavator, and install the rechargeable battery.
- Open the switch ON the base of the excavator to "ON". Start playing with the alloy excavator.

Function Introduction



FCC Caution.

(1) § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.