NOISE

Pro 6 Please refer to this User Manual before using the product.

• Open the NoiseFit app and allow the Bluetooth and GPS positioning to be turned on.

• Go to the 'Pair Device' page in the app, select the watch name and MAC address and link the watch.

Power On

• Press and hold the side button for a few seconds to turn on the watch.

Power Off

- Press and hold the side button for a few seconds.
- Select 'Power off' and confirm to power off.

Waking Up the Watch

To preserve the battery, the watch screen turns off when not in use.

To turn the screen back on, you can wake up the watch by:

- -Pressing the rotating crown
- -Turning on the wrist sense

Charging the watch

Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket. (Power adaptor not included) Place the magnetic charger on the magnetic charging points of the watch. While your watch is charging, the screen will show its progress. Once the battery is fully charged, remove the charger.


Contents











• Select Pair with device and wait for it to pair.

• Feed in your personal information and health goals in the app.

*Scan the QR code for more information on the latest Lumi features.

USER MANUAL

Noise User manual

Pairing the watch

Turn on the watch.

Or you can follow these steps:

To access the detailed User Manual, scan the QR code.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference installed and user in accordance with the instructions, may cause namiful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

 Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly

approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to

computer or peripheral devices).
This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including interference that

may cause undesired operation. RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

