




ONIKUMA



OPERATION MANUAL



WIRELESS INTELLIGENT KARAOKE
RGB LIGHT SPEAKER



Function Introduction



1. Previous song/volume-button: Short press once to decrease the volume, long press to go to the previous song.
2. Mode switching button: Manually switch playback mode, Bluetooth/TF card/U disk, etc.
3. Next song/Volume + button: Short press once to increase the volume, long press to play the next song.
4. Light key: Short press to switch LED lighting effects, long press for 2 seconds to turn off LED lighting effects.
5. Power on/off button: long press for three seconds to turn on/off, short press to play/pause.
6. Original sound key: Short press to turn on/off original sound muting.
7. Power on/off button: Press and hold for three seconds to turn the microphone on and off, and press once to mute the microphone.
8. Volume + button: Short press the microphone volume to increase, double click to increase the reverberation.
9. Volume-button: Short press the microphone volume to decrease, double-click to decrease the reverberation.
10. Mode switch button: short press to turn on/off the original sound, long press to switch the magic sound.
11. Indicator light: Microphone indicator light, the blue light flashes when not connected, the blue light stays on when the connection is successful, the red light turns on when charging, and the red light goes out when fully charged.
12. Charging port: Microphone Type-C 5V charging port.
- 13.AUX jack: Use the audio cable to plug into the AUX jack of the speaker, and play the music AUX jack of the external audio device.
14. TF card insertion: Insert MP3 audio files and automatically switch to TF mode.
15. Charging port: Audio Type-C 5V charging port.
16. USB port: Insert MP3 audio files and automatically switch to USB mode.
17. Indicator light: Audio indicator light, the blue light flashes when not connected, the blue light stays on when the connection is successful, the red light turns on when charging, and the red light goes out when fully charged.

Specifications

Bluetooth version	5.3
Frequency response	120HZ - 18KHZ
Transmission distance	≤1 5m
Output power	5W
Audio lithium battery	18650/1500mAh/3.7v
Microphone battery	14500/500mAh/3.7v
Speaker size	120*180*90mm
Speaker weight:	About 461g
Microphone size:	Width 37.5*height 136mm
Microphone weight	Approximately 74g
Microphone Standard	Wireless microphone (two)
Main functions	Karaoke, U disk, Bluetooth, TF card, AUX
	Double mic duet
	LED 3 light modes
Process materials	Transparent ABS, iron mesh, lanyard
	Silicone buttons, rubber bass diaphragm
Related parameters	Power supply, built-in 18650 lithium battery
	Supply current Type-C USB 5V
	Charging time 2 - 3H
	Playing time 2H-3H (3-5H medium volume)

Frequently Asked Questions

1. If the indicator light does not light up after powering on, please check whether the speaker has sufficient power, or connect the speaker to a 5V/1A power supply for charging. The charging time is about 2-3 hours.
2. There is no sound from the microphone. It may be that the power is not turned on, the mode is incorrect, or the volume is not adjusted. Please adjust the microphone volume.
3. If the speaker has no reverberation, the reverberation switch may be turned off. Please turn on the reverberation switch.
4. If there is noise from the microphone, it may be due to environmental noise, signal interference, the microphone is too close to the speaker, etc. Please re-adjust the direction of the microphone.
5. If Bluetooth playback is interrupted, it may be because the Bluetooth distance is too far, or there are obstacles between the mobile phone and the loudspeaker, which affects signal transmission. Please move closer to the connected mobile phone to avoid obstacles.
6. If Bluetooth cannot be connected, it may be because the distance is too far, there are obstacles, or it is connected by other mobile phones. Please move closer to the mobile phone to avoid obstacles and disconnect the connected mobile phone.
7. If it cannot be charged, check whether the charger is normal and whether the red indicator light of the charging port lights up when the speaker is charging.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.