

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Statement:


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

SARINA




3-IN-1 WONDER DOCK

User Manual
SA-MACC

MADE IN CHINA

CE RoHS



1- Function Overview

Wireless charger
Digital alarm clock
Multicolor night light

2- Digital Alarm Clock

2.1- Function Keys



2.2- Set Time

- Long press **[M]**: To change the 12/24 hour format by pressing **<** or **>**. Then short press **M** to set hour, press **<** or **>**. To set the minutes, press again **M**.

- Short press **<**: add hours/minutes
- Short press **>**: decrease hours/minutes

2.3. Set Alarm

- Short press **[M]**: to select ALARM (possible to set three alarms).
- Press **<** to turn ALARM on and off;
- When ALARM is displayed, long press **M** to set the ALARM time (A1, A2, A3 in sequence), and press **<** or **>** to set the ALARM time.

Notice:

The alarm rings for about 20s, and stops automatically. After about 10s of snoozing, the alarm rings again for about 20s, and the alarm sound ends after the ringing.

During the ringing period, you can press other keys to interrupt, after the interruption, the alarm will end.

2.4.Display brightness (br)

- When the time is displayed, short press **>**, to enter the display brightness (**br**) setting.
- Short press **>** to change brightness (**br**) level (5 levels).
- Press **M** to exit.

2.5.Display brightness (br) levels:

- **br 0**: Display brightness according to time;
- **br 1-4**: The brightness increases in turn;
- **br 5**: 5s screen-off mode.

3- Multicolor Night Light

- Tap: Switch LED color/Turn on the LED light
- Long press: Turn off LED light
- Double tap: automatic color-changing mode

4- Specifications

Materials: ABS+Acrylic
Dimension: 187x91x64(mm)
Input: 5V=3A 9V=3A (QC/PD)
Wireless Output: 15W Max.
Support: 3W/5W/7.5W/10W/15W
Compatibility: all Qi®-enable phones
Working Distance: ≤8mm
Charging Efficiency: 75%-85% alarm will end.
FCC ID: 2AANZMACC

⚠WARNING:

- This is not a toy, keep away from children.
- Don't use it while the temperature over 113°F/45°C.
- Don't put it in fire or other high temperature place.

⚠WARNING: Cancer risk from Lead Exposure –
www.P65Warnings.ca.gov

Company name: DGL Group, Ltd.
Address: 2045 Lincoln Highway, Edison, NJ 08817
www.dglusa.com