



1、Parameter

Model	E	Type	Headset
wireless	V5.0-EDR	Protocol	A2DP, AVRCP, HSP, HFP
Frequency range	2.4-2.4835G	TX power	Class B
CVCTMDSP	Support	Effective	10Meter
FM Radio	Support	Frequency	87-108MHz
Mico SD/TFCard	Support	Max support	32G
Speaker material	NSFeB	Specification	40mm
Sensistance	103±3dB	Distortion	≤ 1% at 1KHz
Power To Bear	30mW	Frequency	20-20KHz
Resistance	32 Ω	Recognition	Capacitance
Microphone	Support	Frequency	30-16KHz
Sensitivity	58±3dB	Recognition	Capacitance
Life time	≥ 10hours	Charge port	USB
Standby time	≥ 180hours	Charge time	≥ 2-3hours
Standby	0.5-0.6mA	Charge time	500mA
Battery type	Lithium	Charge voltage	5V
Battery capacity	500mAh	Temperature	15° CT035° C

1、参数

型号	E	类型	头戴式
蓝牙	V5.0-EDR	协议	A2DP, AVRCP, HSP, HFP
频率范围	2.4-2.4835G	发送功率	Class B
CVCTMDSP	支持	有效距离	10米
FM收音机	支持	频率范围	87-108MHz
Mico SD/TF卡	支持	最大支持	32G
扬声器材料	钕铁硼	规格	40mm
灵敏度	105±3dB	失真率	≤ 1% at 1KHz
承受功率	30mW	频率范围	20-20K Hz
电阻	32 Ω	识别	动圈
麦克风	支持	频率范围	30-16K Hz
灵敏度	58±3dB	识别	电容
播放时间	≥ 10小时	充电端口	USB
待机时间	≥ 180小时	充电时间	≥ 2-3小时
待机电流	0.5-0.6mA	充电电流	500mA
电池类型	锂电池	充电电压	5V
电池容量	500mAh	工作温度	15° CT035° C

2.Button,interface,switch

M/	wireless/FM/TF	Function key to switch to each other,M English full name(Mode)/Long press to turn off the light.
+	Next/Volume-	Short press, under a song/the next station.According to the long, The volume increase
-	On a /Volume-	Short press, a song/On a radio.According to the long, The volume increase
🔊	boot TO turn it off/Hang up	Short press on / Long press 3 sec onds to hang up /Press 3 times to switch between Chinese and English.
📄	TF Card slot	Insert TF card playing card MP3 Songfiles.
I/O	Audio I/O interface	External ear airport speaker audio input, Headphones audio output to external speakers.
USB	Charging	Connect the charger USB charging.

3.By using tutorial
Indicator—light(green) straight flash card reader, wireless(blue/ green light),FMradio(green),State of charge(red).

3.1. wireless

🔊 Switch, Hold down the, The 🔊 headset will then start. Light blue light and green light flashing in each other. Headset wireless is on. Waiting for connection state. wireless headset has place at this time in the state can be found.

2)Click on the wireless Settings in the phone Settings, select "open". This is opened Mobile phone wireless function.

2.按键、接口、开关

M/	蓝牙/FM/TF	功能键互相切换，英文全称(Mode)/长按关闭灯光。
+	下一首/音量+	短按，下一首歌/下一电台。长按，音量加大。
-	上一首/音量-	短按，上一首歌/上一电台。长按，音量减小。
🔊	开机/关机/接通/挂掉	短按接通/长按3秒挂掉/ 连接3次切换中英文。
📄	TF卡槽	插入TF卡，播放卡内存储的MP3歌曲文件。
I/O	Audio I/O接口	外部设置音频输入耳机扬声器，耳机音频输出至外部扬声器。
USB	充电	连接充电器USB充电。

3.使用教程按
指示灯——读卡（绿灯）直闪，蓝牙（蓝/绿灯），FM收音（绿灯），关机状态充电（红灯）。

3.1. 蓝牙

🔊 开关，按住 🔊 耳机将随之启动。指示灯蓝灯与绿灯交替闪烁。耳机蓝牙功能已经开启，正在等待连接状态。此时蓝牙耳机已处于可被查找状态。
2) 点击手机设置中的蓝牙设置，选择“开启”完成。这就打开了手机的蓝牙功能。

3) Open the phone's bluetooth option, to find, search to waitfor matching success Bluetooth,shown on the list ofequipment available for[E] click [E] connection, atthis time Headphones light flashing,sayst has the connections successful. Note: the partof the mobile phoneconnection, instructions Need to enter the password(0000).

2.3.TF Card Play
Insert TF to headphones in the card slot, long press the M key switch to the cardread mode, indicatorlight,Flashing. System automatically decoded audio format file, at this point your favorite melodious songs Gently.

3.3.FMRadio
Long press the M key switch to read card module, indicator light green light flashing. At this point may be heard the hiss. It said there was no radio. Short press the M Key, theheadset will automatically search radio show. Blue lights flashing until no flash, searching. Short press the + key and key can switch electric up and do wn Channel,

3.4.Switch on/ hang up %
Short by answering the telephone, long press for 3 seconds to hang up the phone.

4.Charging
Beforecharging, theheadset off, to make the charging line headset with computer USB connection.The headset indicator lights red, the headset is charging.

The built-in battery capacity test and fire protection.Don't have to worry about charging time of the battery impact. Light automatically extinguished said charging has been completed.

Low—power low battery automatically shut down,please charge as soon as possible, so as to meet the bluetooth requirements.

Note: please don't open the headset in the process of charging, otherwise damage the headset battery hardware life.

5.Matters needing attention

- 1) this headset is not waterproof, please pay attention to waterproof and moisture proof, to ensure that the system can be positive often use.
- 2) it is the main support computer USB charging don't change or connect to the outside charging power supply.
- 3) headset can not be placed for a long time, please charge and discharge once a week, so as to extend the electricity The pool of life.
6. To record the line connection phone listening to music, please turn off the power supply, lest cause noise.

3) 打开手机上的蓝牙选项，进行查找，成功搜索到等待匹配的蓝牙，可用设备列表上显示 E ，点击 E 即可连接，此时耳机上指示灯闪烁，表示已经连接成功。注意：部分手机连接，指示需要输入密码（0000）。

2.3.TF卡播放
将TF插入到耳机卡槽中，长按键切换至读卡模式，指示灯，闪烁不停。

系统自动解码可播放的音频格式文件，此时你钟爱的悠扬歌声轻轻响起。

3.3.FM电台
长按键切换至读卡卡槽，指示灯绿灯闪烁。此时可能听到微弱声，这表示没有电台，只需要短按键，耳机将会自动搜索电台节目。蓝灯一直闪烁到不闪，现台完成。短按+键和-键可以切换上下电台频道。

3.4.接通/挂掉
短按接听电话，长按3秒挂断电话。

4.充电
充电前，关闭耳机电源，将充电线使耳机与电脑USB连接，

此时耳机灯为红色，耳机正在充电。系统内置电池容量检测与过载保护，无需担心充电时间过长对电池的影响。指示灯自动熄灭，表示充电已经完成。电量低——电量低时会自动关机，请尽快充电，这样才能满足蓝牙耳机系统需求。

注意：充电过程中请不要打开耳机电源，否则损失耳机硬件电池寿命。

5.注意事项
1) 这款耳机不防水，请注意防水与防潮，以确保该系统可以正常使用。

2) 它不支持电脑USB接口充电，不要改变或将其连接到外部其它电源充电。

3) 耳机不可以长期放置，请每周一次充电和放电，从而延长电池寿命。

6. 对连线连接手机听歌时，请关掉电源，以免引起杂音。

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.