


In order to ensure users' safety and prevent damages to the product due to any improper use, please carefully read the "Warnings" below and properly keep this User Manual for future reference.

### Warnings

- Please read this User Manual carefully.
- Please do not use the product in water.
- The product contain electronic components, do not let the product fall to the ground, be hit, or suffer a violent impact.
- Please do not use the product in a completely closed environment. It may increase the internal temperature of the product, which causes product failure, ignition, or other accident.
- Never remove the non-detachable lithium battery in the product without permission.
- When the battery of the product is not in use for a long time, please charge and discharge the battery every six months, and provide it with about 60% of the electric quantity to prolong its service life.
- Since there are some hazardous substances in the battery of the product, please do not discard it. Instead, dispose of the product that contains hazardous substances in accordance with the waste management measures.
- When the product is not in use, it should be stored in a dry and clean place. Avoid high temperature, high humidity, and strong magnetic field.



- Please read this User Manual carefully, especially the "Warnings".
- Please use or store the product in the environment mentioned herein.
- Failure to use the product as per this User Manual or under the specified working and storage conditions will be deemed as improper use.

- Wireless Shooting Grip×1
- USB type-C Charge Cable×1
- User Manual×1

**Sony with Bluetooth**

ZV-1 / ZV-E10 / RX100 VII / RX0 II / Alpha 6100 / Alpha 6400 / Alpha 6600 / Alpha 7C / Alpha 7 III / Alpha 7R III / Alpha 7R IV / Alpha 7S III / Alpha 9 / Alpha 9 II

**Canon**

EOS M6 Mark II / EOS M50 / EOS M50 II / EOS M200 / EOS R / EOS R5 / EOS R6 / PowerShot G5X II / G7X III

A detailed line drawing of the Smoothing Iron. The device has a cylindrical body with a control panel on the front. The brand name 'Smoothing' is printed on the upper part of the panel. The control panel includes a power switch with 'ON' and 'OFF' positions, a temperature dial with a '15' mark, and two circular buttons labeled 'C' and 'G'. The top of the device features a wide, flat soleplate with a textured surface. A small rectangular button is located on the side of the soleplate. Numbered callouts (1-10) point to various components: 1 points to the soleplate, 2 to the side button, 3 to the top housing, 4 to the front panel, 5 to the 'Smoothing' logo, 6 to the power switch, 7 to the temperature dial, 8 to the 'C' button, 9 to the 'G' button, and 10 to the bottom housing.

1. 1/4" Camera Screw
2. Rotate Button
3. Tilt Button
4. Battery Level and Charging Indicator
5. Bluetooth Indicator
6. TW: Zoom Button
7. FOCUS/PHOTO Button
8. REC Button
9. ON/OFF Button
10. C1 Button
11. Charging Port

\* FOCUS/PHOTO button: Half press to focus, fully press to take photo.

Diagram illustrating the camera's range of motion:

- Pan 360° / Tilt 180°**: The camera can rotate 360 degrees horizontally (pan) and 180 degrees vertically (tilt).
- Extendable up to 15cm/5.9inch**: The gimbal arm can be extended to a maximum length of 15cm (5.9 inches).

\* Please do not use the grip as tripod when extended.


1. Turn on the remote control.
2. Pairing the unit with the mounted camera.
  - Select MENU—Network—[Bluetooth Settings]—[Bluetooth Function]—[On].
  - Select MENU—Network—[Bluetooth Rmt Ctrl]—[On].
  - Select MENU—Network—[Bluetooth Settings]—[Pairing].
3. Press the REC button and C1 button until the indicator light on the right side flashes stably.
4. When a confirmation message SR-RG1 appears on the camera's screen, select [OK].
5. When pairing is complete, [Paired] appears, select [OK].

1. Turn on the remote control.
2. Set the camera drive mode to [Remote] or [Self-timer:10 sec/remote or 2 sec remote].
3. Select MENU→Network→[Bluetooth Settings]→[Enable].
4. Select MENU→Network→[Wi-Fi/Bluetooth connection]→[Connect to Wireless Remote]→[Add a device to connect to].
5. Press the REC button and C1 button until the indicator light on the right side flashes stably.
6. When a confirmation message "Paired with SR-RG1" appears on the camera's screen, select [OK].

\* Depending on the camera, the setup method for remote control shooting may differ, please refer to the instruction manual for your camera.

- flicker four bars at battery level of 75%~100%
- flicker three bars at battery level of 50%~75%
- flicker two bars at battery level of 25%~50%
- flicker one bars at battery level of 1%~25%

### Product Specification

Remote Range:	10m/32.8ft
Load Capacity (Folded):	1.5kg
Load Capacity (Extended):	0.5kg
Battery Capacity:	3.7V/200mAh/0.74Wh
Charging Input:	5V  A
Net Weight:	193±5g
Product Dimensions:	174.8 x 46 x 39.4mm

Please keep your original purchase receipt and warranty card, including your purchase date, product serial number, etc., which are required for the warranty service.

1. 7 Days DOA Return Policy: Within 7 Days from the package receipt date, return or replacement can be done if the item received is malfunctioning or physically damaged (non-artificial damage), return shipping cost will be on SmallRig's charge.
2. 30 Days Free-Reason Return Policy: Within 30 Days from the package receipt date, return or replacement can be done if the item is in good condition (without any malfunction or physical damage). The return shipping cost will be on the customer's charge.
3. 1-Year Warranty: Within 1-year from the package receipt date, the defective product (non-artificial damage) is eligible to get repair/ replacement for free. The defective product (artificial damage) will be charged for repairing/replacement based on the damage level.

1. Defect caused by users' violation of the "Warnings" and "Intended Use".
2. The product identification or SN label is removed or defaced in any way.
3. The product is serviced or repaired by anyone other than our company or the service agency authorized by our company.

Serial No.	
Item Name	
Purchase Date	
User Name	
Mobile	
Address	
Receipt	

Made in China

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of FCC rules. This equipment generates, uses, and can radiate radio frequency energy and, if not properly installed and used, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The FCC has authorized the use of this equipment on the basis of the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be caused by radio frequency energy that is received. RF Exposure Information

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

French: Cet appareil conforme les émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Science et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes :

- (1) Cet appareil ne doit pas provoquer d'interférence.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil numérique du cdm conforme candien peut : (b) - (b) / nmb - (b) - (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du crnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des renseignements supplémentaires sur l'exposition aux ondes radiofréquences.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.  
Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. Cet équipement doit être installé et utilisé avec une distance minimale de 0 mm entre le radiateur et votre corps.