

蓝牙发射器/接收器/USB三合一 说明书




参数

蓝牙版本:	高通5.3
蓝牙协议:	A2DP, HFP, HSP
频率范围:	2.402GHz-2.480GHz
频率响应:	20Hz-20kHz
传输距离:	20米
连接设备数:	2
信号处理:	VPOB
发射接口:	USB/TX3.5mm接口
接收接口:	RX3.5mm接口
支持音频格式:	SBC/APTX/APTXLL/APTXHD/APTX Adaptive
接收音频格式:	SBC/AAC/APTX/AptX HD/AptX Adaptive
USB驱动支持系统:	Win-ALL/Linux/苹果电脑/PS4-5/安卓


一：默认发射模式优先

1. 当USB接口插入时，设备会自动进入默认发射模式。打开蓝牙设备/接收器/发射器，设备会自动搜索并连接成功。设备的LED灯亮起，表示第一设备连接成功。注：打开设备时，设备会自动进入默认发射模式。当设备进入默认发射模式后，再次按下按钮，设备将进入接收模式。进入第二设备连接成功，连接成功的设备将接收模式。
2. 再次按下按钮，设备将进入接收模式。再次按下按钮，设备将进入默认发射模式。
3. 11Pin USB接口连接设备/接收器，插入3.5mm音频线，设备将自动切换到3.5mm音频模式。
4. 当设备工作正常时，设备将自动切换到默认模式。设备工作正常时，设备将自动切换到默认模式。




二：接收模式

1. 当USB接口插入时，设备将自动切换到3.5mm音频模式。当设备进入接收模式时，设备将自动搜索并连接成功。设备的LED灯亮起，表示第一设备连接成功。注：打开设备时，设备将自动进入接收模式。当设备进入接收模式后，再次按下按钮，设备将进入默认发射模式。再次按下按钮，设备将进入接收模式。
2. 再次按下按钮，设备将进入接收模式。再次按下按钮，设备将进入默认发射模式。
3. 11Pin USB接口连接设备/接收器，插入3.5mm音频线，设备将自动切换到3.5mm音频模式。
4. 当设备工作正常时，设备将自动切换到默认模式。设备工作正常时，设备将自动切换到默认模式。



Bluetooth transmitter/receiver/ USB three in one manual




Parameters

Bluetooth version:	Qualcomm 5.3
Bluetooth protocol:	A2DP, HFP, HSP
Frequency range:	2.402GHz-2.480GHz
Frequency response:	20Hz-20kHz
Transmission distance:	20 meters
Number of connected devices:	2
Signal to noise ratio:	>90dB
Transmission interface:	USB/TX3.5mm interface
Receiving interface:	RX3.5mm interface
Transmit audio format:	SBC/APTX/APTXLL/APTXHD/APTX Adaptive
Received audio format:	SBC/AAC/APTX/AptX HD/AptX Adaptive
USB drive free support system:	Win-ALL/Linux/Apple/PS4-5/Android


1: Default emission mode priority

1. When the USB is inserted, the device will automatically enter the default emission mode. Turn on the Bluetooth device such as Bluetooth speaker/headset, and the device will automatically search and connect successfully. The device's LED light will turn on, indicating that the first device connection is successful. Note: When the device is turned on, it will automatically enter the default emission mode. When the device enters the default emission mode, pressing the button again will enter the receiving mode. Pressing the button again will enter the default emission mode.
2. Press the button again, and the device will enter the receiving mode. Pressing the button again will enter the default emission mode.
3. Connect the 11Pin USB cable to the adapter for power supply, insert a 3.5mm audio cable, and the device will automatically switch to the 3.5mm audio mode.
4. The device will automatically switch to the default mode when it works normally. When the device works normally, it will automatically switch to the default mode.



2: Receiving mode

1. When the USB is inserted, the device will automatically switch to the 3.5mm audio mode. When the device enters the receiving mode, it will automatically search and connect successfully. The device's LED light will turn on, indicating that the first device connection is successful. Note: When the device is turned on, it will automatically enter the receiving mode. When the device enters the receiving mode, pressing the button again will enter the default emission mode. Pressing the button again will enter the receiving mode.
2. Press the button again, and the device will enter the receiving mode. Pressing the button again will enter the default emission mode.
3. Connect the 11Pin USB cable to the adapter for power supply, insert a 3.5mm audio cable, and the device will automatically switch to the 3.5mm audio mode.
4. The device will automatically switch to the default mode when it works normally. When the device works normally, it will automatically switch to the default mode.



Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.