

Double Sided, Black and White Copy

76 mm

 <h2>5 IN 1 MULTI-DEVICE CHARGING STATION</h2> <p>WITH WIRELESS CHARGING PAD</p>  <p>MANUAL</p> <p>Introduction Thank you for purchasing our Sin1 Multi-Device Charging Station. Save space while charging 5 devices simultaneously.</p> <p>Features</p> <ul style="list-style-type: none"> - Space saving, charge up to 5 devices simultaneously (Max 3.4 Amp shared output) - Charging multiple devices simultaneously may increase time needed for charging - Compatible with wireless charging smartphones, USB devices, Apple Watch™, and Apple AirPods® (Generation 1, Generation 2 and AirPods Pro™) - Built-in wireless charging pad with 5W output - Connect your Apple Watch™ and AirPods™ charging cables (not included) to charge your devices - LED indicator illuminates blue and red when charging - Includes 2ft 3.5Amp USB Type-C cable to power station <p>Wireless Charging Compatible Smartphones: (including but not limited to):</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 33%;">iPhone 8</td> <td style="width: 33%;">Samsung Galaxy S9 Edge Plus</td> <td style="width: 33%;">Samsung Galaxy S9</td> </tr> <tr> <td>iPhone X</td> <td>Samsung Galaxy S9</td> <td>Samsung Galaxy S9 Plus</td> </tr> <tr> <td>iPhone Xs</td> <td>Samsung Galaxy S9+ Plus</td> <td>Samsung Galaxy S9+</td> </tr> <tr> <td>iPhone Xs Max</td> <td>Samsung Galaxy S8</td> <td>Samsung Galaxy S8 Plus</td> </tr> <tr> <td>iPhone Xr</td> <td>Samsung Galaxy S8+</td> <td>Samsung Galaxy S8+</td> </tr> <tr> <td>iPhone 11</td> <td>Samsung Galaxy S7</td> <td>Samsung Galaxy S7 Edge</td> </tr> <tr> <td>iPhone 11 Pro</td> <td>Samsung Galaxy S7 Edge</td> <td>Samsung Galaxy S7 Edge</td> </tr> <tr> <td>iPhone 11 Pro Max</td> <td>Samsung Galaxy S7 Plus</td> <td>Samsung Galaxy S7 Plus</td> </tr> <tr> <td>iPhone 12 (5G)</td> <td>Samsung Galaxy S6</td> <td>Samsung Galaxy S6</td> </tr> <tr> <td>Google Nexus 4</td> <td>Samsung Galaxy S6 Edge</td> <td>Samsung Galaxy S6 Edge</td> </tr> <tr> <td>Google Nexus 5</td> <td>Samsung Galaxy S6 Edge+</td> <td>Samsung Galaxy S6 Edge+</td> </tr> <tr> <td>Google Nexus 6</td> <td>Samsung Galaxy S6</td> <td>Samsung Galaxy S6</td> </tr> <tr> <td>Google Pixel 1</td> <td>Samsung Galaxy S6 Plus</td> <td>Samsung Galaxy S6 Plus</td> </tr> <tr> <td>Google Pixel 2 XL</td> <td>Samsung Galaxy S6 Edge</td> <td>Samsung Galaxy S6 Edge</td> </tr> <tr> <td>Google Pixel 3</td> <td>Samsung Galaxy S6 Edge+</td> <td>Samsung Galaxy S6 Edge+</td> </tr> <tr> <td>Google Pixel 3 XL</td> <td>Samsung Galaxy S6 Edge</td> <td>Samsung Galaxy S6 Edge</td> </tr> <tr> <td>Google Pixel 4</td> <td>Samsung Galaxy Note 8</td> <td>Samsung Galaxy Note 8</td> </tr> <tr> <td>Google Pixel 4 XL</td> <td>Samsung Galaxy Note 9</td> <td>Samsung Galaxy Note 9</td> </tr> <tr> <td>Samsung Galaxy S9</td> <td>Samsung Galaxy Note 8</td> <td>Samsung Galaxy Note 8</td> </tr> <tr> <td>Samsung Galaxy S9 Active</td> <td>Samsung Galaxy Note 9</td> <td>Samsung Galaxy Note 9</td> </tr> <tr> <td>Samsung Galaxy S10 Edge</td> <td>Samsung Galaxy S10</td> <td>Samsung Galaxy S10</td> </tr> </table>	iPhone 8	Samsung Galaxy S9 Edge Plus	Samsung Galaxy S9	iPhone X	Samsung Galaxy S9	Samsung Galaxy S9 Plus	iPhone Xs	Samsung Galaxy S9+ Plus	Samsung Galaxy S9+	iPhone Xs Max	Samsung Galaxy S8	Samsung Galaxy S8 Plus	iPhone Xr	Samsung Galaxy S8+	Samsung Galaxy S8+	iPhone 11	Samsung Galaxy S7	Samsung Galaxy S7 Edge	iPhone 11 Pro	Samsung Galaxy S7 Edge	Samsung Galaxy S7 Edge	iPhone 11 Pro Max	Samsung Galaxy S7 Plus	Samsung Galaxy S7 Plus	iPhone 12 (5G)	Samsung Galaxy S6	Samsung Galaxy S6	Google Nexus 4	Samsung Galaxy S6 Edge	Samsung Galaxy S6 Edge	Google Nexus 5	Samsung Galaxy S6 Edge+	Samsung Galaxy S6 Edge+	Google Nexus 6	Samsung Galaxy S6	Samsung Galaxy S6	Google Pixel 1	Samsung Galaxy S6 Plus	Samsung Galaxy S6 Plus	Google Pixel 2 XL	Samsung Galaxy S6 Edge	Samsung Galaxy S6 Edge	Google Pixel 3	Samsung Galaxy S6 Edge+	Samsung Galaxy S6 Edge+	Google Pixel 3 XL	Samsung Galaxy S6 Edge	Samsung Galaxy S6 Edge	Google Pixel 4	Samsung Galaxy Note 8	Samsung Galaxy Note 8	Google Pixel 4 XL	Samsung Galaxy Note 9	Samsung Galaxy Note 9	Samsung Galaxy S9	Samsung Galaxy Note 8	Samsung Galaxy Note 8	Samsung Galaxy S9 Active	Samsung Galaxy Note 9	Samsung Galaxy Note 9	Samsung Galaxy S10 Edge	Samsung Galaxy S10	Samsung Galaxy S10	<p>Step 1 Insert official Apple Watch™ charger into the cavity.</p>  <p>Press firmly into mold.</p>  <p>Step 2 Insert official Apple Lighting™ cable for your AirPods into the silicone holder.</p>  <p>Step 3 Insert the USB end into the USB ports on the inside of the charging station, and organize cables as shown.</p>  <p>Be sure to organize and tuck the cables in so that they are not protruding or the holder may not sit on the charging base properly. Due to the limited space, it is suggested that the original cables provided with your Apple devices should be used.</p>
iPhone 8	Samsung Galaxy S9 Edge Plus	Samsung Galaxy S9																																																														
iPhone X	Samsung Galaxy S9	Samsung Galaxy S9 Plus																																																														
iPhone Xs	Samsung Galaxy S9+ Plus	Samsung Galaxy S9+																																																														
iPhone Xs Max	Samsung Galaxy S8	Samsung Galaxy S8 Plus																																																														
iPhone Xr	Samsung Galaxy S8+	Samsung Galaxy S8+																																																														
iPhone 11	Samsung Galaxy S7	Samsung Galaxy S7 Edge																																																														
iPhone 11 Pro	Samsung Galaxy S7 Edge	Samsung Galaxy S7 Edge																																																														
iPhone 11 Pro Max	Samsung Galaxy S7 Plus	Samsung Galaxy S7 Plus																																																														
iPhone 12 (5G)	Samsung Galaxy S6	Samsung Galaxy S6																																																														
Google Nexus 4	Samsung Galaxy S6 Edge	Samsung Galaxy S6 Edge																																																														
Google Nexus 5	Samsung Galaxy S6 Edge+	Samsung Galaxy S6 Edge+																																																														
Google Nexus 6	Samsung Galaxy S6	Samsung Galaxy S6																																																														
Google Pixel 1	Samsung Galaxy S6 Plus	Samsung Galaxy S6 Plus																																																														
Google Pixel 2 XL	Samsung Galaxy S6 Edge	Samsung Galaxy S6 Edge																																																														
Google Pixel 3	Samsung Galaxy S6 Edge+	Samsung Galaxy S6 Edge+																																																														
Google Pixel 3 XL	Samsung Galaxy S6 Edge	Samsung Galaxy S6 Edge																																																														
Google Pixel 4	Samsung Galaxy Note 8	Samsung Galaxy Note 8																																																														
Google Pixel 4 XL	Samsung Galaxy Note 9	Samsung Galaxy Note 9																																																														
Samsung Galaxy S9	Samsung Galaxy Note 8	Samsung Galaxy Note 8																																																														
Samsung Galaxy S9 Active	Samsung Galaxy Note 9	Samsung Galaxy Note 9																																																														
Samsung Galaxy S10 Edge	Samsung Galaxy S10	Samsung Galaxy S10																																																														

<p>Step 4</p> <ul style="list-style-type: none"> - To power the station, plug the included USB-C cable into the Type-C port labeled "Input" and plug the other end of the usb cable into a USB Wall Adapter. Then plug the USB wall charger into power outlet. - The transparent divider LED lights will illuminate blue and the wireless charging LED indicator will flash blue and red, indicating that the charging station is powered on. - See below for USB Charger power requirements.  <p>Note: For optimal charging, a 5V 3.1Amp rated USB Wall adapter should be used. Charging more devices at the same time may cause longer charging times. For best charging performance and faster charging times an 18W QC 3.0 USB wall adapter should be used. Using a USB wall adapter that is below 3.1Amp rating may result in improper charging</p> <p>Wireless Charging Place device on wireless charging area to initiate wireless charging. LED indicator will illuminate red indicating the device is charging.</p>	<p>Wall/Home Charger Requirements See chart below for the most suitable wall/home charger (not included) to use with your Sin1 Charging Station.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Input</th> <th>Output(Shared)</th> <th>Charging Speed</th> </tr> </thead> <tbody> <tr> <td>5V 1A (5W)</td> <td>5V 0.9A Max</td> <td>Inufficient</td> </tr> <tr> <td>5V 2A (10W)</td> <td>5V 1.9A Max</td> <td>Slower</td> </tr> <tr> <td>5V 3A (15W)</td> <td>5V 2.9A Max</td> <td>Slow</td> </tr> <tr> <td>5V 3.3A (15.5W)</td> <td>5V 3.0A Max</td> <td>Medium</td> </tr> <tr> <td>5V 3.4A (17W)</td> <td>5V 3.3A Max</td> <td>Fast</td> </tr> <tr> <td>5V 3.5A (17.5W)</td> <td>5V 3.4A Max</td> <td>Faster</td> </tr> </tbody> </table> <p>Removing Your Airpods Use both hands to properly remove Airpods from the cradle. Hold down the airpod cradle while pulling up on the Airpods to prevent lifting.</p> 	Input	Output(Shared)	Charging Speed	5V 1A (5W)	5V 0.9A Max	Inufficient	5V 2A (10W)	5V 1.9A Max	Slower	5V 3A (15W)	5V 2.9A Max	Slow	5V 3.3A (15.5W)	5V 3.0A Max	Medium	5V 3.4A (17W)	5V 3.3A Max	Fast	5V 3.5A (17.5W)	5V 3.4A Max	Faster	<p>Important Safety Information</p> <p>CAUTION: Use this only as intended. To prevent fire or shock hazard, do not expose this unit to rain or moisture. Do not use within a meter of any water such as swimming pools, bathtubs or sinks. To avoid electrical shock, do not disassemble. Refer servicing to qualified personnel only. Never insert objects of any kind, other than authorized items into the product as they may touch dangerous voltage points or short out parts that could result in fire or electrical shock. Do not dispose of this product in fire. Refer to local country, state and city guidelines for appropriate methods of battery disposal. This product contains small parts that may cause choking if swallowed. Not intended for use by children under 3 years of age.</p> <p>- Warning: Changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> - Relocate or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>Specifications: Input: 5V = 3.5A Output: 5V + 3.4A Max</p> <p>Distributed by Jerr Accessories, Inc.</p> <p>FC </p>
Input	Output(Shared)	Charging Speed																					
5V 1A (5W)	5V 0.9A Max	Inufficient																					
5V 2A (10W)	5V 1.9A Max	Slower																					
5V 3A (15W)	5V 2.9A Max	Slow																					
5V 3.3A (15.5W)	5V 3.0A Max	Medium																					
5V 3.4A (17W)	5V 3.3A Max	Fast																					
5V 3.5A (17.5W)	5V 3.4A Max	Faster																					