

165mm

Wireless Charging Mouse Pad

Instruction Manual
W205



85mm

Features:

1. Wireless Charging Dock
2. LED Indicator
3. Type-C Input Port

What's included:

- 1 x Wireless charging mouse pad
- 1 x 100cm Type-C to Type-C charging cable
- 1 x Instruction Manual

Tech Specifications

- Input Power: 9.0V~2.0A
- Wireless Output: 15W max.

Instructions:

Wirelessly charging a wireless enabled smartphone using the mouse pad

1. Make sure your smartphone has integrated wireless capability or is equipped with wireless charging adapter
 2. Insert the Type-C output of charging cable into the input port(3) of the mouse pad & connect Type-C input of charging cable to certified wall adapter, if no loading after detection, the RED indicator(2) will remain on
 3. Place the phone flat on the wireless charging area (with the bottom center of the phone aligned with the wireless charging area) to charge the phone, the BLUE indicator(2) will remain on
 4. The safety protection will be activated when abnormal metal objects are detected or the input voltage is abnormal. The RED and BLUE indicator(2) will flash alternately, and the output will be shut off to ensure safety.
 5. To stop charging, remove your electronic device from the icon on mouse pad and disconnect the charging cable
- NOTE:**
- Only smartphones equipped with wireless charging capabilities are able to use the wireless charging of the mouse pad
 - The wireless charging dock of mouse pad will activate only when it connected to a certified A/C adapter (not included)

SAFETY PRECAUTIONS:

WARNING—When using this product, basic precautions should always be followed, including the following:

1. Read all the instructions before use
2. Never store or use this product in temperatures below 32 °F (0 °C) or above 115 °F (45 °C)
3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for more than 7 hours at a time.
4. To reduce the risk of injury, close supervision is required when the product is used near children.
5. Do not exposed the device to moisture
6. Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
7. Do not use the device if damaged or modified
8. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
9. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury
10. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 104 °F (40 °C) may result in explosion.
11. To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
12. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. You must remove attachments from the phone before charging on this device

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation



MADE IN CHINA

165*85mm



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.