3 in 1 Magnetic Wireless Charger

User Guide (Model:B-17)


Material

USB Cable

Product Size

Net Weight

Color



(2) Wireless Charger for earphone

(4) LED Light (3 Brightness Modes)

(3) Wireless Charger for iWatch

(5) Trouch Switch for LED Light

(6) Type-C Input


ABS+PC Fireproof Material

120cm Type-C to USB-A


L114.5*W82.5*H142mm

Black /White /Silver /Pink...

252g



How to Use:



4. Charge your devices.

(3)


(1) Plug in the type-C plug input cable (2) Connect the QC3.0 (or PD) guick charger (3) Charge your (Phone 12/13) (4) Charge your earphone (5) Charge your iWatch

5. LED light status:

- (1) Power on and standby: The LED light is off.
- (4) Turn on the light: Press the touch switch (5).
- (5) Adjust the brightness: Pressing touch swich (5) to adjust the 3
- brightness modes.

FCC Information

- This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation
- This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause
- harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna
- --Increase the separation between the equipment and receiver. --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Radiation Exposure Statement
- This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.



(3) Phone/earphone/watch charging status: The LED light is off.

Safety Tips:

Please adhere to these basic precautions while using this product, as follows:

1. Read all the instructions before use

2. This product can be normal used between the temperatures of 32°F (0°C) to 95°F(35°C).

3. Do not expose the device to fire or excessive temperature. Exposure to fire or excessive temperatures may cause an explosion.

4. Do not expose the device to moisture.

5. Keep away from water or other liquids which may lead to short circuit while using the product.

6. Close supervision is necessary when the product is used near children.

7. Do not use this wireless charger if damaged or modified.

8. Do not disassemble the device. Incorrect reassembly may result in risk of fire or injury.

9 Ensure that qualified service professionals use only identical replacement perts to ensure product safety.

10. Accessories placed on the back of your smart phone can impede the effectiveness of the wireless charger, and lead to overheating Please remove accessories from the phone before attempting wireless charging.

11 Remove your phone /watch /earchone when it is fully charged Please unplug the power adapter when your devices are fully charged.

